



Changes for the Better

MITSUBISHI Communication Software for CNC

FCSB1224W000

Reference Manual



INTRODUCTION

Thank you for purchasing the Mitsubishi CNC communication software FCSB1224W000. This user's reference manual describes how to use the OLE/COM interface of FCSB1224W000.

Read this manual before use to get familiar with and correctly use the functions of FCSB1224W000.

Precautions for Safety

(Read carefully before use.)

Before using the product, read the user's reference manual and other related manuals. Pay careful attention to safety when using the product.

The safety instructions in this manual are intended for this product. Do not use this product until you have a full knowledge of general and safety information and precautions about the computerized numerical controller.

In this manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



When there is a great risk that the user could be subject to fatalities or serious injuries if handling is mistaken.



When the user could be subject to medium or slight injuries or when physical damage could occur if handling is mistaken.

Note that even items ranked as , may lead to major results depending on the situation. In any case, important information that must always be observed is described.

Keep this manual in a safe place for future reference.

[Mechanical precautions]



- When connecting the product with the computerized numerical controller, consider the risk of external power supply failure and computer malfunction, and install the external safety circuit as fail-safe of the entire system.
- There is a risk of accident due to output error or malfunction.
- Writing to the computerized numerical controller will directly be reflected in machine control.
- Input error of setup or other parameter may cause accidental operation.
- Check all things before execution.

[Startup and maintenance precautions]



- Operation error may cause machine damage or accident.
- Some functions may be different or unavailable depending on the version of the computerized numerical controller.

Trademarks

MELDAS, MELSEC, EZSocket, EZMotion, iQ Platform, MELSOFT, GOT, CC-Link, CC-Link/LT and CC-Link IE are either trademarks or registered trademarks of Mitsubishi Electric Corporation in Japan and/or other countries.

Ethernet is a registered trademark of Xerox Corporation in the United States and/or other countries.

Microsoft®, Windows, Visual C++® and Visual Basic® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

CompactFlash and CF are either trademarks or registered trademarks of SanDisk Corporation in the United States and/or other countries.

SD Logos are trademarks or registered trademarks of SD-3C, LLC in the United States, other countries or both.

Other company and product names that appear in this manual are trademarks or registered trademarks of the respective companies.

CONTENTS

1. OUTLINE

1.1 Features	1-1
1.2 Applicable Models	1-1
1.3 Connection Configuration	1-1
1.3.1 Connection with M700 series	1-2
1.3.2 Connection with M800 series	1-2
1.3.3 Connection with C70	1-3
1.4 Development Environment	1-5
1.5 Installation	1-6
1.6 Preparation for Use	1-6
1.7 Interface	1-7
1.7.1 Custom interface	1-7
1.7.2 Automation interface	1-8
1.8 Program Flow	1-9
1.8.1 VC++ program flow	1-9
1.8.2 VB program flow	1-10

2. I/F DETAILED SPECIFICATIONS

2.1 Common Items	2-1
2.2 Method List	2-3
2.3 IEZNCCommunication3 Interface	2-6
2.4 IEZNCSystem Interface	2-20
2.5 IEZNCPosition Interface	2-25
2.6 IEZNCCommand2 Interface	2-45
2.7 IEZNCProgram2 Interface	2-51
2.8 IEZNCTime Interface	2-58
2.9 IEZNCAxisMonitor Interface	2-68
2.10 IEZNCRunStatus Interface	2-91
2.11 IEZNCFile6 Interface	2-98
2.12 IEZNCCommonVariable2 Interface	2-123
2.13 IEZNCLocalVariable2 Interface	2-129
2.14 IEZNCTool3 Interface	2-132
2.15 IEZNCATC3 Interface	2-165
2.16 IEZNCParameter3 Interface	2-175
2.17 IEZNCOperation Interface	2-183
2.18 IEZNCDevice Interface	2-186
2.19 IEZNCSubFunction3 Interface	2-196

3. ERROR CODE LIST

4. API OPERATING PROCEDURE

4. API OPERATING PROCEDURE	4-1
4.1 API Operating Procedure	4-1
4.2 Initialization for Enabling OLE/COM Interface	4-2
4.3 Object Creation	4-3
4.4 Include Files	4-3
4.5 Overview of VB Programming of Automation Interface	4-4
4.5.1 Using OLE automation interface with VB	4-4
4.5.2 VB program flow (1)	4-6
4.5.3 VB program flow (2)	4-7

5. APPLICATION INSTALLATION PROCEDURE

5.1 Overview.....	5-1
5.2 Distribution Method with Redistribution Installer	5-2
5.2.1 Location where redistribution installer is stored.....	5-2
5.2.2 Destination where redistribution installer is installed	5-2
5.2.3 Specifications for redistribution installer INI file	5-2
5.2.4 Processing flow and specifications of redistribution installer.....	5-3
5.2.5 Troubleshooting	5-6
5.2.6 Precautions	5-7
5.3 Terms of Redistribution.....	5-8
5.3.1 Redistributable modules	5-8
5.3.2 Redistributable files.....	5-8
5.4 Installation Procedure.....	5-9
5.4.1 Version upgrade of redistributable files.....	5-9
5.4.2 x86 platform	5-9
5.4.3 x64 platform	5-13

6.SAMPLE APPLICATION

6.1 Overview of the Sample Application.....	6-1
6.2 Position Data Display Application	6-1
6.2.1 Operating requirements	6-1
6.2.2 Installation and uninstallation.....	6-1
6.2.3 Executing the sample application	6-2
6.2.4 Function list.....	6-2
6.2.5 Screen structure and functions.....	6-3
6.2.6 Setting project workspaces	6-6
6.2.7 IEZNCCommunication object	6-6
6.2.8 IEZNCPosition object	6-6
6.3 Monitoring Application	6-7
6.3.1 Operating requirements	6-7
6.3.2 Installation and uninstallation.....	6-7
6.3.3 Executing the sample application	6-7
6.3.4 Function list.....	6-8
6.3.5 Screen structure and functions.....	6-9
6.3.6 Setting project workspaces.....	6-10

7. CONSOLE PROGRAM SAMPLE

7.1 Console Program to Connect Mitsubishi CNC C70 (via Ethernet).....	7-1
---	-----

1. OUTLINE

The Mitsubishi CNC communication software FCSB1224W000 is designed to help development of an application with Windows interface for Mitsubishi computerized numerical controller CNC M700/M800 series and CNC C70 series. (Hereinafter referred to as the product.)

The product can accelerate development by eliminating necessity to know about internal processing of the computerized numerical controller and enabling use of the common OLE interface on the Mitsubishi computerized numerical controller.

1.1 Features

- Functions of Mitsubishi CNC M700/M800 series and CNC C70 series can be used on the Windows application with VC++, VB or VBA macro language.
- Communication and other complex processing with Mitsubishi CNC M700/M800 series and CNC C70 series will be conducted by the product so that the user can focus on development of the value-added Windows application.
- As the product will be upgraded in accordance with new models in the future, upgrading of the user-created application will also be easy.

1.2 Applicable Models

The product is applicable to the following models. Check compatibility before use.

- Mitsubishi CNC M700 series (M700/M700V series, M70/M70V series and E70) (hereinafter referred to as M700)
- Mitsubishi CNC M800 series (M800/M80 series) (hereinafter referred to as M800)
- Mitsubishi CNC C70 (hereinafter referred to as C70)

1.3 Connection Configuration

This section explains about connection configuration between the Mitsubishi computerized numerical controller and personal computer. Prepare the computerized numerical controller, personal computer, cable and other necessary equipment for communication using this product. For connection of equipment, see the instruction manual of the computerized numerical controller used.

1.3.1 Connection with M700 series




Figure 1-1 Connection with M700 series

1.3.2 Connection with M800 series




Figure 1-2 Connection with M800 series

1.3.3 Connection with C70

See the connection path between C70 and personal computer.

Table 1-1 C70 Connection path

Model	Connection path	Connection module	Figure
C70	Ethernet connection	C70	Figure 1-3
	Ethernet connection via QJ71E71	QJ71E71	Figure 1-3
	Ethernet connection via QnUDE	QnUDE	Figure 1-3
	USB connection via QnUD	QnUD	Figure 1-4
	RS-232C connection via QnUD	QnUD	Figure 1-4
	USB connection via QnUDE	QnUDE	Figure 1-4
	GOT (bus connection) transparent	Base unit	Figure 1-5
	GOT (Ethernet) transparent	C70 QJ71E71 QnUDE	Figure 1-6




Figure 1-3 Ethernet connection with C70




Figure 1-4 QnUD connection with C70




Figure 1-5 C70 and GOT (bus connection) transparent




Figure 1-6 C70 and GOT (Ethernet) transparent

1.4 Development Environment

Environmental requirements for application development with this product are as below.

Table 1-2 Development and operating environment

Item	Specifications
Personal computer	Personal Computer AT compatible machine (x86 processor) Personal Computer AT compatible machine (x64 processor)
CPU (*2)	-
OS	Microsoft Windows 7 Home Basic SP1 or later, Japanese/English Microsoft Windows 7 Home Premium SP1 or later, Japanese/English Microsoft Windows 7 Professional SP1 or later, Japanese/English Microsoft Windows 7 Ultimate SP1 or later, Japanese/English Microsoft Windows 7 Enterprise SP1 or later, Japanese/English Microsoft Windows 7 Home Premium x64 SP1 or later, Japanese/English Microsoft Windows 7 Professional x64 SP1 or later, Japanese/English Microsoft Windows 7 Ultimate x64 SP1 or later, Japanese/English Microsoft Windows 7 Enterprise x64 SP1 or later, Japanese/English } (*3)
Required memory (*2)	-
Disc space (*2)	-
Peripheral equipment (*2)	-
Development language (*2)	Microsoft Visual C++.NET 2003, 2005, 2008, 2010 (*1) Microsoft Visual C++ Ver.5.0, Ver.6.0 Microsoft Visual Basic Ver.5.0, Ver.6.0 Microsoft Visual Basic for Applications Ver.5.0 (Excel 97 VBA equivalent), Ver.6.0 (Excel 2000 VBA equivalent)
Note	(*1) Development with native code (VC++) only. Development with managed code is not supported. (*2) See the Windows operating environment recommended by Microsoft Corporation. (*3) As the product is 32 bit module, it will run on the Windows 32-bit On Windows 64-bit (WOW64) subsystem if executed on x64 platform. It does not support 64 bit native operation.

1.5 Installation

Dynamic link library (DLL) of the product is necessary to use its functions.

See the "release note" for how to install the product.

When installing the product on x64 platform, specify the destination folder as below.

C:\Program Files (x86)\EZSocket

1.6 Preparation for Use

To create an application using this product with VC++, VB or VBA, the following appropriate include files or modules are required. The table below shows the default folders of when the installation is made in the C drive from DVD-ROM.

Table 1-4 Include files according to development language

	VC++	VB or VBA
Installation destination folder	%ProgramFiles%\EZSocket\EZSocketNc\include\Vc	%ProgramFiles%\EZSocket\EZSocketNc\include\Vb
File	EZSocketNc.h EZSocketNcStr.h EZSocketNc_i.c EZSocketNcDef.h EZSocketNcErr.h EZSocketCommonErr.h	EZNcDef.bas EZNcErr.bas EZComErr.bas

To use the product with C70, the MELSEC programmable controller load module needs to be installed beforehand. See the release note for how to install it.

1.7 Interface

The product provides two types of interface as DLL inprocess server: custom interface and automation interface. The two types of interface have similar data access functions.

The custom interface works well with VC++ and the automation interface works well with VB and VBA.

The interface can be selected according to the development language.

As the interfaces of the product are based on Microsoft Component Object Model (**COM**), general knowledge about **COM** will be necessary to use the interfaces from the application. Note that general explanation about **COM** is not described in this manual.

1.7.1 Custom interface

See the custom interface list in Table 1-5.

Table 1-5 Custom interface list

Component	Interface	Category
EZNcCommunication	IEZNcCommunication3	Communication
	IEZNcSystem	NC System
	IEZNcPosition	Position
	IEZNcCommand2	Command
	IEZNcProgram2	Program
	IEZNcTime	Time
	IEZNcAxisMonitor	Axis monitor
	IEZNcRunStatus	Operation status
	IEZNcFile6	File
	IEZNcCommonVariable2	Common variable
	IEZNcLocalVariable2	Local variable
	IEZNcTool3	Tool
	IEZNcATC3	ATC
	IEZNcParameter3	Parameter
	IEZNcOperation	Operation
IEZNcDevice	Programmable controller device	
EZNcSubFunction	IEZNcSubFunction3	Subfunction

(Note 1) Though the interface name may change due to version upgrade, the former interface can still be used since the new interface inherits its former version.

Example) IEZNcFile5 → IEZNcFile6

Note that the former interface is for backward compatibility and the new interface is required to use the latest version of product.

(Note 2) C70 does not support automation interface.

1.7.2 Automation interface

See the automation interface list in Table 1-6.

They are handy for use with VB since all functions are contained in a single automation interface.


Table 1-6 Automation interface list

Component	Interface	Category
DispEZNcCommunication	IDispEZNcCommunication	Communication
		NC System
		Position
		Command
		Program
		Time
		Axis monitor
		Operation status
		File
		Common variable
		Local variable
		Tool
		ATC
		Parameter
Programmable controller device		
Operation		
DispEZNcSubFunction	IDispEZNcSubFunction	Subfunction

1.8 Program Flow

1.8.1 VC++ program flow

This section explains the program flow outline to create an application for M700/M800 series or C70 using the custom interface with VC++.



*1 In the thread using this product, call the COM library function `CoInitialize()` before using this product and `CoUninitialize()` after using this product. When finishing the use of the objects of this product, call `Release()` to release the objects (decrement the reference count).


*2 When creating an M700/M800 series application, call `SetTCPIPProtocol` before `Open`. When creating a C70 application, call `SetMelsecProtocol` instead of `SetTCPIPProtocol`.

1.8.2 VB program flow

This section explains the program flow outline to create an application for M700/M800 series using the automation interface with VB.


(1) Early binding call

Early binding requires reference of type library of the automation interface to be set in advance.



(2) Late binding call

Late binding does not require reference setting. Note that the object browser function with VB cannot be used.



2. I/F DETAILED SPECIFICATIONS

2.1 Common Items

(1) Character code

All character string parameters in the interface of this product use UNICODE.

(2) Character string handling

With the method for handling character string data, if returning the character string data to the application, memory is allocated on the product side. Character string data memory that is no longer needed is freed up on the application side. If it is not freed up, a memory leak may occur.

To develop applications with custom interfaces for use with VC++, use **CoTaskMemFree()** to explicitly free up character string area memory.

To develop applications with automation interfaces for use with VC++, use **SysFreeString()** to explicitly free up character string area memory.

(3) Handling of common error codes

The method return value will be either for successful completion (**S_OK**) or failure (**S_FALSE**) of the method.

A detailed method error is returned as an argument.

Commonly used error messages include the following.

EZ_ERR_NOT_OPEN: Communication lines are not open.

EZ_ERR_DOUBLE_OPEN: Double open error

EZ_ERR_DATA_TYPE: Invalid argument data type

EZ_ERR_DATA_RANGE: Invalid argument data range

EZ_ERR_NOT_SUPPORT: Not supported

EZ_ERR_NULLPTR: Argument is **NULL** pointer

(4) Error handling when calling an I/F incompatible with the model

If the I/F of a function not supported by the model is called, **EZ_ERR_NOT_SUPPORT** is output as an unsupported error code.

(5) Notations used in Chapter 2.3 and later in this document

The meaning of notations used on pages describing individual method detailed specifications in Chapter 2.3 and later are as follows.

"□ **Argument**" section: Describes the argument specifications of the method.

"□ **Return value**" section: Describes the return values of the method.

"□ **Function**" section: Describes the general function of the method.

"□ **Reference**" section: Describes the methods related to the method.

"□ **Specification**" section: Indicates that specification of the system number (including PLC axis systems) and axis numbers is necessary when executing the method. If used without specifying, note that operation will not be guaranteed.

Required specification details are abbreviated with the following marks.

System: Set the part system number. Use SetHead() for the part system number setting.

PLC axis: Set the PLC axis system number. Use SetHead() for PLC axis system number setting.

Axis number: Set the axis number.

In addition, even if the **System** mark is listed, sometimes system specification is not required according to the argument value, as with the method in Chapter 2.12.1. For more information, see the supplementary information described in the "□ Specification" section on an individual method's page.

(6) Restrictions on methods that require part system setting

For disabled systems, if a method that requires part system setting is executed, the method's execution result will be null. Check beforehand whether the set system is an enabled system.

In addition, system 1 will be set after a line opens.

(7) File name specification

In this product, the Mitsubishi CNC (*1) is regarded as a single drive, and the various data on the NC control unit (machining program, tool offset, etc.) are treated as a file. To access an NC control unit file, set the file name according to the following form unless otherwise noted.

Drive name + ":" + \directory name + \file name

Make sure to set the file name with an absolute path.*2

Also, the drive name should correspond to an NC control unit number as follows.

NC control unit number	Drive name (NC memory)
01	M01
02	M02
03	M03
:	:
:	:
FF	MFF

*1: Described in the following sections of this manual as "NC control unit".

*2: Set the file name with upper-case characters.

In English-version operating systems, set by changing "¥" to a backslash.

(8) Restrictions on calls from multiple threads of the C70

With the C70, if the number of threads the product uses exceeds 1000, error codes may no longer be output correctly.

Keep in mind the number of threads the product uses when creating a C70 application.

2.2 Method List

Table Interface list

○: Supported, -: Not supported

Chapter number	Function class	Interface (operation)	Function	Target		
				M700 series	M800 series	C70 ¹
2.3.1	IEZNCCommunication3 (Communication)	Open2	Open NC control unit system line	○	○	○
2.3.2		Close	Close NC control unit system line	○	○	○
2.3.3		SetHead	Set system number	○	○	○
2.3.4		GetHead	Get system number	○	○	○
2.3.5		SetTCPIPProtocol	Set TCP/IP communication settings	○	○	-
2.3.6		SetMelsecProtocol	Set MELSEC communication settings	-	-	○
2.4.1	IEZNCSystem (NC System)	GetVersion	Get system number, name, and control S/W version	○	○	○
2.4.2		GetSystemInformation	Get NC system information	○	○	○
2.4.3		GetAlarm	Get alarm information	○	-	○
2.4.4		GetAlarm2	Get alarm information	○	○	○
2.5.1	IEZNCPosition (Position)	GetWorkPosition	Get workpiece coordinate position (skip ON-compliant)	○	○	○
2.5.2		GetWorkPosition2	Get workpiece coordinate position (skip ON-compliant)	○	○	○
2.5.3		GetMachinePosition	Get machine position (skip ON-compliant)	○	○	○
2.5.4		GetMachinePosition2	Get machine position (skip ON-compliant)	○	○	○
2.5.5		GetCurrentPosition	Get current position	○	○	○
2.5.6		GetDistance	Get command remaining distance (skip ON-compliant)	○	○	○
2.5.7		GetDistance2	Get command remaining distance (skip ON-compliant)	○	○	○
2.5.8		GetNextDistance	Get next travel distance	○	○	○
2.5.9		GetFeedSpeed	Get feed speed	○	○	○
2.5.10		GetTCPSpeed	Get tip speed	○	○	-
2.5.11		GetManualOverlap	Get manual interrupt amount	○	○	○
2.5.12		GetManualOverlap2	Get manual interrupt amount	○	○	○
2.5.13		GetProgramPosition	Get program position	○	○	○
2.5.14		GetProgramPosition3	Get program position	○	○	○
2.5.15		GetTCPMachinePosition	Get tip machine position	○	○	-
2.5.16	GetTCPWorkPosition	Get tip workpiece position	○	○	-	
2.5.17	GetFeedbackPosition	Get feedback position	○	○	-	
2.5.18	GetTableCoordinationPosition	Get table coordinate system counter	○	○	-	
2.5.19	GetWorkInstallationPosition	Get workpiece installation coordinate system counter	○	○	-	
2.5.20	GetInclinedSurfacePosition	Get inclined surface coordinate system counter	○	○	-	
2.6.1	IEZNCCommand2 (Command)	GetGCodeCommand	Get G code modal command value	○	○	○
2.6.2		GetToolCommand	Get tool compensation number	○	○	○
2.6.3		GetFeedCommand	Get feed speed command value	○	○	○
2.6.4		GetCommand2	Get M/S/T/B function command modal value	○	○	○
2.6.5		SetCommand2	Set manual numerical value command settings (M, S, T, B)	○	○	○
2.7.1	IEZNCProgram2 (Program end)	CurrentBlockRead	Read current block	○	○	○
2.7.2		GetProgramNumber2	Get program number (main, sub)	○	○	○
2.7.3		GetSequenceNumber	Get sequence number (main, sub)	○	○	○
2.7.4		GetBlockNumber	Get block number (main, sub)	○	○	○
2.7.5		GetSubProLevel	Get subprogram call level	○	○	○
2.7.6		GetInformation	Get user machining program information	○	○	○
2.7.7		GetCurrentBlockByByte	Get number of bytes from start of program	○	○	-
2.8.1	IEZNCTime (Time)	GetClockData	Get date and time	○	○	○
2.8.2		SetClockData	Set date and time settings	○	○	○
2.8.3		GetAliveTime	Get power-on time	○	○	○
2.8.4		SetAliveTime	Set power-on time settings	○	○	○
2.8.5		GetRunTime	Get automatic operation time	○	○	○
2.8.6		SetRunTime	Set automatic operation time settings	○	○	○
2.8.7		GetStartTime	Get automatic start time	○	○	○
2.8.8		SetStartTime	Set automatic start time settings	○	○	○
2.8.9		GetEstimateTime	Get external integration time (1, 2)	○	○	○
2.8.10		SetEstimateTime	Set external integration time settings (1, 2)	○	○	○

chapter number	Function class	Interface (operation)	Function	Target		
				M700 series	M800 series	C70 ¹
2.9.1	IEZNCAxisMonitor (Axis monitor)	GetServoMonitor	Get servo monitor	○	○	○
2.9.2		GetServoVersion	Get servo version information	○	○	○
2.9.3		GetServoDiagnosis	Get servo diagnostics information	○	○	○
2.9.4		GetPowerVersion	Get power supply version information	○	○	○
2.9.5		GetPowerDiagnosis	Get power supply diagnostics information	○	○	○
2.9.6		GetSpindleMonitor	Monitor spindle	○	○	○
2.9.7		GetSpindleVersion	Get spindle version information	○	○	○
2.9.8		GetSpindleDiagnosis	Get spindle diagnostics information	○	○	○
2.9.9		GetAbsPositionMonitor	Get absolute position monitor information	○	○	○
2.9.10		GetAuxAxisMonitor	Get auxiliary axis monitor information	○	○	-
2.9.11		GetAuxAxisDiagnosis	Get auxiliary axis diagnostics information	○	○	-
2.9.12		GetAuxAxisVersion	Get auxiliary axis version information	○	○	-
2.9.13		GetDowelTime	Get remaining dwell time	○	○	○
2.9.14		GetPowerConsumption	Get current power consumption	-	○	-
2.9.15		GetIntegralPower	Get integral power	-	○	-
2.10.1	IEZNCRunStatus (Operation status)	GetInvalidStatus	Get disabled status	○	○	○
2.10.2		GetCommandStatus	Get operation command status	○	○	○
2.10.3		GetCuttingMode	Get cutting mode status	○	○	○
2.10.4		GetAxisStatus	Get axis status	○	○	○
2.10.5		GetRunStatus	Get operation status	○	○	○
2.11.1	IEZNCFile6 (File)	FindDir2	Search directory	○	○	○
2.11.2		FindNextDir2	Search next directory	○	○	○
2.11.3		ResetDir	Terminate directory search	○	○	○
2.11.4		Copy2	Copy file	○	○	○
2.11.5		Delete2	Delete file	○	○	○
2.11.6		Rename2	Change file name	○	○	○
2.11.7		GetDriveInformation	Get drive information	○	○	○
2.11.8		GetDriveSize	Get free drive space	○	○	○
2.11.9		GetDriveSize2	Get free drive space	-	○	-
2.11.10		OpenFile3	Open file	○	○	○
2.11.11		CloseFile2	Close file	○	○	○
2.11.12		AbortFile2	Force close file	○	○	○
2.11.13		ReadFile2	Read file	○	○	○
2.11.14		WriteFile	Write file	○	○	○
2.11.15	OpenNCFile2	Open NC program file	○	○	-	
2.11.16	CloseNCFile2	Close NC program file	○	○	-	
2.11.17	AbortNCFile2	Force close NC program file	○	○	-	
2.11.18	ReadNCFile2	Write NC program file	○	○	-	
2.11.19	WriteNCFile	Read NC program file	○	○	-	
2.12.1	IEZNCCommonVariable2 (Common variable)	CommonVRead	Read common variables (#100, #500)	○	○	○
2.12.2		CommonVWrite	Write common variables (#100, #500)	○	○	○
2.12.3		GetSize	Get number of sets for common variables (#100, #500)	○	○	○
2.12.4		GetName	Get names of common variables (#500 to 519)	○	○	○
2.12.5		SetName	Set name settings for common variables (#500 to 519)	○	○	○
2.12.6		GetCVNullData	Get value when no numerical value is set	○	○	○
2.13.1	IEZNCLocalVariable2 (Local variable)	LocalVRead	Read local variable	○	○	○
2.13.2		GetMacroLevel	Get macro subprogram execution level (level 0 to 4)	○	○	○
2.13.3		GetLVNullData	Get value when no numerical value is set	○	○	○

Chapter number	Function class	Interface (operation)	Function	Target			
				M700 series	M800 series	C70*1	
2.14.1	IEZNCtool3 (Tool)	GetToolSetSize	Get number of sets for tool offset	○	○	○	
2.14.2		GetType	Get tool offset type	○	○	○	
2.14.3		GetOffset	Get tool offset data	○	○	○	
2.14.4		GetOffset2	Get tool offset data	○	○	○	
2.14.5		SetOffset	Set tool offset data settings	○	○	○	
2.14.6		GetToolWorkOffset	Get workpiece coordinate system offset (#54 to 60)	○	○	○	
2.14.7		GetToolWorkOffset2	Get workpiece coordinate system offset (#54 to 60)	○	○	○	
2.14.8		SetToolWorkOffset	Set workpiece coordinate system offset settings (#54 to 60)	○	○	○	
2.14.9		SetToolWorkOffset2	Set workpiece coordinate system offset settings	○	○	○	
2.14.10		GetSurface	Get reference surface height	○	○	○	
2.14.11		GetSurface2	Get reference surface height	○	○	○	
2.14.12		SetSurface	Set reference surface height settings	○	○	○	
2.14.13		GetToolLifeType2	Get tool life control type 2	○	○	○	
2.14.14		SetToolLifeType2	Set tool life control type settings 2	○	○	○	
2.14.15		GetToolLifeGroupList	Get tool life control group number list	○	○	○	
2.14.16		ChangeToolLifeGroup	Change tool life control group number	○	○	○	
2.14.17		DeleteToolLifeGroup	Delete tool life control group number	○	○	○	
2.14.18		GetToolLifeToolNoList	Get list of tools within tool life control group	○	○	○	
2.14.19		AddToolLifeToolNo	Add tool number to tool life control group	○	○	○	
2.14.20		ChangeToolLifeToolNo	Change tool life control tool number	○	○	○	
2.14.21		DeleteToolLifeToolNo	Delete tool life control tool number	○	○	○	
2.14.22		GetToolLifeValue	Get tool life control data	○	○	○	
2.14.23		SetToolLifeValue	Set individual tool life control data settings	○	○	○	
2.14.24		SetToolLifeValue2	Set tool life control data settings	○	○	○	
2.15.1	IEZNCATC3 (ATC)	GetMGNControl	Get ATC tool registration control parameter	○	○	○	
2.15.2		GetMGNSize	Get total number of sets of magazine pots for ATC tool registration	○	○	○	
2.15.3		GetMGNSize2	Get number of sets of pots for each magazine for ATC tool registration	○	○	○	
2.15.4		GetMGNReady2	Get tool number for ATC tool registration	○	○	○	
2.15.5		GetMGNPot	Get tool number for magazine pot for ATC tool registration	○	○	○	
2.15.6		GetMGNPot3	Get tool number for each magazine pot for ATC tool registration	○	○	○	
2.15.7		SetMGNPot	Set tool number settings for magazine pots for ATC tool registration	○	○	○	
2.15.8		SetMGNPot3	Set tool number settings for each magazine pot for ATC tool registration	○	○	○	
2.15.9		GetMGNAux	Get user programmable controller interface for ATC tool registration	○	○	○	
2.15.10		SetMGNAux	Set user programmable controller interface settings for ATC tool registration	○	○	○	
2.16.1	IEZNCparameter3 (Parameter)	GetParameterData2	Get parameters	○	-	○	
2.16.2		GetParameterData3	Get parameters	○	○	○	
2.16.3		SetParameterData2	Set parameter settings	○	-	○	
2.16.4		SetParameterData3	Set parameter settings	○	○	○	
2.17.1	IEZNCoperation (Operation)	Search	Operation search	○	○	○	
2.17.2		Run	Start programmable controller program	○	○	○	
2.17.3		Stop	Stop programmable controller program	○	○	○	
2.18.1	IEZNCdevice (Device)	SetDevice	Set device settings	○	○	-	
2.18.2		DeleteDeviceAll	Delete all device settings	○	○	-	
2.18.3		ReadDevice	Read device	○	○	-	
2.18.4		WriteDevice	Write device	○	○	-	
2.18.5		ReadBlockDevice	Batch read devices	○	○	-	
2.18.6		WriteBlockDevice	Batch write devices	○	○	-	
2.19.1	IEZNCsubFunction3 (Subfunction)	ChangeInit2	Initialize subfunction	○	○	○	
2.19.2		GetToolWorkOffsetOffFile	Get workpiece coordinate system offset data from workpiece offset file	○	○	○	
2.19.3		SetToolWorkOffsetOffFile	Set workpiece coordinate system offset data settings for workpiece offset file	○	○	○	

*1) C70 does not support automation interface.



2.3.1 IEZNCCommunication3::Open2 **Open line**

□ Custom call procedure

```
HRESULT      Open2 (
                LONG ISystemType,           // (I) NC system type
                LONG IMachine,             // (I) NC control unit
                LONG ITimeOut,             // (I) Communication time-out value
                LONG* pIRet                  // (O) Error code
            )
```

□ Automation call procedure

```
Open2 (
    ISystemType As LONG           // (I) NC system type
    IMachine As LONG              // (I) NC control unit
    ITimeOut As LONG              // (I) Communication time-out value
    IpcwszHostName As STRING     // (I) Host name
) As LONG                         // (O) Error code
```

□ *ISystemType*: Sets the NC system type.

Argument	Value	Meaning
	EZNC_SYS_MELDASC70	With the C70, performs a line connection.
	EZNC_SYS_MELDAS700M	With M700 M systems, performs a line connection.
	EZNC_SYS_MELDAS700L	With M700 L system, performs a line connection.
	EZNC_SYS_MELDAS800M	With M800 M systems, performs a line connection.
	EZNC_SYS_MELDAS800L	With M800 L system, performs a line connection.

IMachine: Sets the NC control unit number. When connecting to multiple Mitsubishi CNCs, specify the different NC control unit numbers for each Mitsubishi CNC. Value: 1 to 255

ITimeOut: Sets the communication time-out value. However, with C70, this value is disabled. The C70 communication time-out is set by *ITimeOut* in **SetMelsecProtocol()**.

Value	Meaning
1 to 3000	Time-out value (unit: 100 ms) (M700/M800 series is 10 or more, and if a time-out error occurs, increase the value.)

IpcwszHostName: Sets the NC system host name to connect. The IP address can also be specified.

When connecting to a local host, set "**EZNC_LOCALHOST**" as the character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

- S_OK**: Normal termination
- EZ_ERR_DATA_TYPE**: Invalid argument data type
- EZ_ERR_DATA_RANGE**: Invalid argument data range
- EZNC_SYSFUNC_IOCTL_ADDR**: Invalid NC control unit number
- EZNC_SYSFUNC_IOCTL_NOTOPEN**: Device is not open
- EZNC_SYSFUNC_IOCTL_DATA**: Invalid communication parameter data range
- EZNC_COMM_NOTSETUP_PROTOCOL**: TCP/IP communication has not been set (M700/M800 series only)
- EZNC_COMM_NOTMODULE**: No submodule
- EZNC_COMM_CREATEPC**: EZSocketPc objects cannot be created (C70 only)
- EZNC_COMM_CANNOT_OPEN** : When connecting to local host with automation call, host name EZNC_LOCALHOST has not been set.

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	<p>Executes connection of the communication line for an IEZNCCommunication3 object.</p> <p>For the M700/M800 series, before open, make sure to execute SetTCPIPProtocol() to configure the communication settings. Also, for the C70, before open, make sure to execute SetMelsecProtocol() to configure the communication settings. If it is not executed, an error will occur when Open2() is executed.</p> <p>(Note 1) The existing interface IEZNCCommunication2::Open (()) can be used as a backward compatible model. Use this method when newly starting use of EZSocket.</p>	
□ Reference	<p>Close(), SetTCPIPProtocol(), SetMelsecProtocol()</p>	
□ Specification		

2.3.2 IEZNCCommunication3::Close

Close line

□ Custom call procedure

```
HRESULT      Close (
                LONG* pIRet                                // (O) Error code
            )
```

□ Automation call procedure

```
Close ( ) As LONG                                // (O) Error code
```

□ *pIRet*: Returns an error code. (Upon automation, the return value is used.)

□ **Argument** **S_OK**: Normal termination

EZNC_SYSFUNC_IOCTL_NOTOPEN: Device is not open

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Failure

□ **Function** The communication lines of **IEZNCCommunication3** objects connected by **Open2()** will be disconnected.

For the M700/M800 series, even if the line is closed, the content set by **SetTCPIPProtocol()** is maintained, so **Open2()** can be performed again.

For the C70, even if the line is closed, the content set by **SetMelsecProtocol()** is maintained, so **Open2()** can be performed again.

□ **Reference** **Open2()**, **SetTCPIPProtocol()**, **SetMelsecProtocol()**

□ **Specification**

2.3.3 IEZNCCommunication3::SetHead

Set part system number

□ Custom call procedure

```
HRESULT      SetHead(
                LONG IHead,                // (I) Part system number
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
SetHead(
    IHead As LONG                // (I) Part system number.
) As LONG                       // (O) Error code
```

□ **Argument** *IHead*: Sets the part system number. or the PLC axis system. Value: The range is determined by Mitsubishi CNC specifications (optional) and the machine manufacturer setting values (parameter). A value of 0 means "Not setting". When setting the PLC axis system, sets **EZNC_PLCAxis**.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Failure

□ **Function** Set the NC axis / PLC axis system number.

Set the part system number before executing a method that requires system number. setting. The set part system remains enabled until it is changed. System 1 is set after a line opens.

□ **Reference** **GetHead()**

□ **Specifica-
tion**

2.3.4 IEZNCCommunication3::GetHead

Get part system number

□ Custom call procedure

```
HRESULT      GetHead(
                LONG* pIHead,           // (O) Part system number.
                LONG* pIRet            // (O) Error code
            )
```

□ Automation call procedure

```
GetHead(
    pIHead As LONG*           // (O) Part system number.
) As LONG                   // (O) Error code
```

□ **Argument** *pIHead*: Returns the part system number. or the PLC axis system. Value: The range is determined by Mitsubishi CNC specifications (optional) and the machine manufacturer setting values (parameter). A value of 0 means "Not setting".
The PLC axis system returns **EZNC_PLCAXIS**.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Failure

□ **Function** Gets the NC axis / PLC axis system number. The PLC axis system number gets **EZNC_PLCAXIS**.

□ **Reference** **SetHead()**

□ **Specifica-
tion**

2.3.5 IEZNCCommunication3::SetTCP/IPProtocol

Set TCP/IP communication protocol

□ Custom call procedure

```

HRESULT      SetTCPIPProtocol (
                LPCOLESTR IpCwszIPAddress,           // (I) IP address
                LONG IPort,                          // (I) Port number
                LONG* pIRet                          // (O) Error code
            )

```

□ Automation call procedure

```

                SetTCPIPProtocol (
                    IpCwszIPAddress As STRING          // (I) IP address
                    IPort As LONG                    // (I) Port number
                ) As LONG                             // (O) Error code

```

□ **Argument** *IpCwszIPAddress*: Sets the IP address of the M700/M800 series connection destination.
(Example: "192.168.1.1")

IPort: Sets the M700/M800 series connection destination port number.
For the port number, check the settings on the Mitsubishi CNC side. For the M700/M800 series, the port number becomes 683.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_COMM_ALREADYOPENED: Cannot be set because communication is already in progress

EZ_ERR_DATA_RANGE: Invalid IP address or port number

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets TCP/IP communication protocol.

For the M700/M800 series, call before performing **Open2()**. If it is not called, an error will occur when **Open2()** is executed.

The setting details are retained until the object is released by **Release()**.

Temporarily, until **Close()** is performed if **Open2()** is performed, re-setting with

SetTCPIPProtocol() cannot be done. An error will occur.

This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)

□ **Reference** **Open2(), Close()**

□ **Specification**

2.3.6 IEZNCCommunication3::SetMelsecProtocol

Set Melsec communication settings

□ Custom call procedure

```

HRESULT      SetMelsecProtocol (
                EZNCST_OPEN* pstOpen,           // (I) Line
                LONG* plRet                     // (O) Error code
            )

```

- **Argument** *pstOpen*: A pointer referring to the **EZNCST_OPEN** structure which sets the parameters for the open. Refer to the following for members of the structure of **EZNCST_OPEN**.

(Note) The structure is created with the assumption of connection types other than Ethernet communication and serial communication. According to the following structure member descriptions, set 0 for unneeded parameters.

INetworkNumber: Sets the network number with MELSECNET/10(H). Sets "0x00" when a host station is set. When a Qn multi-drop connection (serial communication, via CC-Link module) is set, the following applies.

Value	Meaning
0x00	Sets a host network
0x01	Sets another network for multi-drop destination

IStationNumber: Sets the station number with MELSECNET and CC-Link. "0xFF" is set when a host station is set. If accessing the CPU of the CPU board and the AF board, sets a host station. When a Qn multi-drop connection (serial communication, via CC-Link module) is set, the following applies.

Value	Meaning
0x00	Set a host network
0x01	Set another network for multi-drop destination

IUnitNumber: Sets the module number of the computer link (serial communication) module or the station number for a Qn communication system intelligent special module. However, sets "0x00" with the setting of a QnA series host station (module mounted to the host station CPU). This is disabled with computer link (serial communication) communication and a Qn intelligent special target. With a multi-drop link, the module number of the target destination computer link (serial communication) module station is set.

IConnectUnitNumber: Sets the module number of the computer link (serial communication) module or the Ethernet module for QnA/Qn. With a multi-drop link, the module number of the request source computer link (serial communication) module station is set. However, with a multi-drop via a CPU direct connection, the module number of the request source station is not required. ("0x00".) Sets "0x00" when not a multi-drop link. Sets a relay destination station number when using a QnA or Qn Ethernet module. ("0x00" is fixed when accessing within a host network.) If accessing other networks via MNET/10, sets the station number set in the parameter of the connected Ethernet module.

IIONumber: Sets the module I/O number. This parameter sets the target actual input/output No. (start I/O number ÷ 16) of the serial communication module and intelligent special module with a multi-drop link or intelligent special module access. **(With a multi-drop link, the station to pass through: request source station I/O number is set.)** Sets 0x3E0 to 0x3FF if accessing other stations via the host station CPU or network.

Value	Target
0 to 1FFh number ÷ 16)	Communication system intelligent special module (start I/O
200 to 3CFh	Reserve
3D0h	Control system CPU module
3D1h	Standby system CPU module
3D2h	System A CPU module
3D3h	System B CPU module
3D4h	CPU module in other system
3D5h to 3DBh	Reserve
3DCh	System A communication peripheral equipment 1
3DDh	System B communication peripheral equipment 1
3DEh	System A communication peripheral equipment 2
3DFh	System B communication peripheral equipment 2
3E0 to 3E3h	Individual CPU module with multiple CPUs (Module 1 to 4)
3F0h	Global request with multiple CPUs
3FCh	Card next to CPU
3FDh	Peripheral equipment 2
3FEh	Peripheral equipment 1
3FFh	CPU module (including LM)

ICpuType: Sets the target CPU (NC module) that performs communication.

Value	Target
CPU_Q17NNCCPU	Q173NCCPU (C70)

IUnitType: Sets the module connected to a physical port on the computer.

Value	Meaning
UNIT_ACPU	Direct to ACPUs-RS422 port
UNIT_QCPU	Direct to QnACPU-RS422 port
UNIT_QNCPU	Direct to QnCPU (Q mode) RS232C port
UNIT_QNCPU_A	Direct to QnCPU (A mode) RS232C
UNIT_QNUSB	Direct to QnCPU (Q mode) USB port
UNIT_QNUSB_A	Direct to QnCPU (A mode) USB port
UNIT_QNMOTION	Direct to Q motion -RS232C port
UNIT_QNMOTIONUSB	Direct to Q motion USB port
UNIT_FXCPU	Direct to FXCPU-RS422 port
UNIT_C24	Direct to C24 module for A
UNIT_UC24	Direct to UC24 module for A
UNIT_QC24	Direct to QC24 module for QnA
UNIT_QJ71C24	Direct to C24 module for Q
UNIT_FXENET_ADP	Connection to Ethernet adapter for FX
UNIT_FX232BD	Connection to FXCPU computer link (RS232C)
UNIT_FX485BD	Connection to FXCPU computer link (RS485)
UNIT_E71	Connection to Ethernet LAN for A
UNIT_QE71	Connection to Ethernet LAN for QnA
UNIT_QJ71E71	Connection to Ethernet LAN for Q
UNIT_G4ACPU	Direct to AJ65BT-G4 (-S3) module (ACPU access)
UNIT_G4QCPU	Direct to AJ65BT-G4 (-S3) module (QnA access)
UNIT_G4QNCPU	Direct to AJ65BT-G4-S3 module (Qn access)
UNIT_MNET2BOARD	Connection to MNET2 board
UNIT_MNET10BOARD	Connection to MNET/10 board
UNIT_MNETHBOARD	Connection to MNET/H board
UNIT_MNETGBOARD	Connection to CC-Link IE controller network board
UNIT_CCLINKBOARD	Connection to CC-Link board
UNIT_MSPANUBOARD	Connection to CPU board
UNIT_AFBOARD	Connection to AF board
UNIT_EMEDBOARD	Connection to EmEd board
UNIT_SIMULATOR	Connection to simulator (LLT)
UNIT_QBF	Connection to personal computer CPU for Q
UNIT_SSCBOARD	Connection to SSC net board
UNIT_A900GOT	Connection to GOT900 series / 1000 series
UNIT_OTHER	Generic connection
UNIT_MNETGBOARD	Connection to CC-Link IE controller network board
UNIT_QNETHER	Connection to QnCPU (Q mode) Ethernet port
UNIT_QNETHER_DIRECT	Direct connection to QnCPU (Q mode) Ethernet port
UNIT_GOT_QJ71E71	Connection to QJ71E71 module through GOT1000 series
UNIT_GOT_QNETHER	Connection to QnCPU Ethernet port through GOT1000 series

IPacketType: Sets the computer link or Ethernet packet transmission format. The following format is set for this parameter.

Value	Meaning
PACKET_BINARY1	Dedicated protocol format (when AJ71E71/AJ71QE71 is set)
PACKET_ASCII1	Dedicated protocol format (when AJ71(U)C24, AJ71E71/AJ71QE71 is set)
PACKET_PL1	CPU protocol format (when AJ71E71/AJ71QE71 or other than the above is set)

IProtocolType: Sets the communication protocol type of the module (board) to connect. Select connection through a serial port + modem with communication via AJAJ71QC24N/QJ71C24/LJ71C24 + modem. (If directly connecting to AJ71QC24N/QJ71C24/LJ71C24, select connection through a serial port.) Select connection through a shared memory server only with a simulator connection, and select connection through a Q bus only with a personal computer CPU connection.

Value	Meaning
PROTOCOL_MNET2	Through MNET II board
PROTOCOL_MNET10	Through MNET/10 board
PROTOCOL_MNETH	Through MNET/10H and MNET/25H board
PROTOCOL_MNETG	Through CC-Link IE controller network board
PROTOCOL_CCIEF	Through CC-Link IE field network board
PROTOCOL_EMED	Through EmEd board
PROTOCOL_SERIAL	Through serial port
PROTOCOL_USB	Through USB port
PROTOCOL_TCPIP	Through TCP/IP
PROTOCOL_UDPIP	Through UDP/IP
PROTOCOL_SHAREDMEMORY	Through shared memory server
PROTOCOL_CCLINK	Through CC-Link board
PROTOCOL_MSPANU	Through CPU board
PROTOCOL_AF	Through AF board
PROTOCOL_SSC	Through SSC board
PROTOCOL_TEL	Through Q6TEL, A6TEL
PROTOCOL_SERIALMODEM	Through serial port + modem
PROTOCOL_QBF	Through Q bus
PROTOCOL_USBGOT	Through GOT1000 USB port

IPortNumber: Sets the port number for connection between the physical port on the computer and the module set by *IUnitType*. For the connectable ports for the connection module, refer to the connectable ports remarks. However, an arbitrary value is set as the request source (personal computer) port number with an Ethernet connection. If "=0" is set as the port number, the MNET/10 routing method will be an automatic response method. In addition, set a fixed value of "5001" when not selecting an automatic response method via QE71 or when not setting TCP/IP for E71/QE71.

Value	Meaning
PORT_1	Communication port 1
PORT_2	Communication port 2
PORT_3	Communication port 3
PORT_4	Communication port 4
PORT_5	Communication port 5
PORT_6	Communication port 6
PORT_7	Communication port 7
PORT_8	Communication port 8
PORT_9	Communication port 9
PORT_10	Communication port 10

However, when an Ethernet connection is made, the following is applicable.

Model	Protocol	Port number	
QJ71E71 AJ71QE71 (UDP)	UDP	Method other than automatic response	5001 is fixed
		Automatic response method	0: Automatically assigns open ports in the personal computer Other than 0: Create sockets using specified port
	TCP	-	Fixed to 0: Automatically assigns open ports in the personal computer
AJ71QE71 (TCP) AJ71E71	UDP	Sets by matching the port number set in the sequence	
	TCP	If sets by the sequence: Set by matching the set port number If not set by the sequence: Arbitrarily set an open port in the personal computer	

IBaudRate: Sets the baud rate with serial communication. This parameter can be one of the following values.

Value	Meaning
CBR_2400	2400 bps
CBR_4800	4800 bps
CBR_9600	9600 bps
CBR_14400	14400 bps
CBR_19200	19200 bps
CBR_38400	38400 bps
CBR_56000	56000 bps
CBR_57600	57600 bps
CBR_115200	115200 bps
CBR_128000	128000 bps
CBR_256000	256000 bps

IDataBits: Sets the number of sent and received byte data bits (6 to 8).

IParity: Sets the parity bit. This parameter can be one of the following values. It becomes effective only during serial communication.

Value	Meaning
EVENPARITY	Even number
ODDPARITY	Odd number
MARKPARITY	Mark
NOPARITY	No parity

IStopBits: Sets the number of stop bits used. This parameter can be one of the following values. It becomes effective only during serial communication.

Value	Meaning
ONESTOPBIT	1 stop bit
ONE5STOPBITS	1.5 stop bits
TWOSTOPBITS	2 stop bits

IControl: Sets the control signal. This parameter can be one of the following values. It becomes effective only during serial communication.

Value	Meaning
TRC_NONE	No flow control
TRC_DTR	DTR control
TRC_RTS	RTS control
TRC_DTR_OR_RTS	DTR or RTS control
TRC_DTR_CD	DTR control (with CD control)
TRC_RTS_CD	RTS control (with CD control)
TRC_DTR_OR_RTS_CD	DTR or RTS control (with CD control)

IpcwszHostAddress: Sets the connected host name (IP address) as a UNICODE character string with Ethernet communication. Set NULL when Ethernet is not set.

ICpuTimeOut: Sets the CPU monitoring timer with Ethernet communication. The unit is *250 ms. (The default is 4.)

ITimeOut: Sets the communication time-out value. The unit is ms. (The default is 1000 ms.)

* The time-out starts counting from when data communication ends.

ISumCheck: Sets whether a sum check is enabled or disabled. One of the following values is set for this parameter. It is enabled only when connecting through a computer link module or an A-series Ethernet module (TCP/IP).

Value	Meaning
TRUE	There is a sum check
FALSE	There is no sum check

ISourceNetworkNumber: Sets the request source network number when Ethernet for QnA and Qn (via AJ71QE71 and QJ71E71) is set

Set the same network No. (network No. specified by the network parameter) as the Ethernet for a QnA or Qn connection.

ISourceStationNumber: Sets the request source station number (station number on the personal computer side) when an Ethernet for QnA and Qn (via AJ71QE71 and QJ71E71) is set

Set the station number so as not to overlap with the QE71 station numbers set in the same Ethernet loop.

IDestinationPortNumber: Sets the port number of the target destination module when Ethernet is set. Sets the relay destination port number when accessing other networks. The following applies when other than an automatic response method, E71, or QE71 (TCP/IP).

- QnA (AJ71QE71) (UDP/IP) : "5001" is fixed
- Qn (QJ71E71) (TCP/IP) : "5002" is fixed
If the target is a Q redundant CPU, any port number can also be set.
- Qn (QJ71E71) (UDP/IP) : "5001" is fixed
- Qn (Ethernet port) (UDP/IP) : "5006" is fixed
- Qn (Ethernet port) (TCP/IP) : "5007" is fixed
- Qn (Ethernet port direct communication) : "5008" is fixed

IDestinationIONumber: Sets the actual input/output No. (start I/O number ÷ 16) of the last access target station with a Qn multi-drop connection (via CC-Link, serial communication). (When the target is an intelligent special module.) If the target is a CPU module, set between 0x3F0 and 0x3FF. (Refer to "IIONumber".)

IConnectChannelNumber: Sets the connected channel No. (Ch1/Ch2) when connection of the serial communication module for Qn is set. Because this is used for system reservation, do not set anything. (Specify 0x00.)

IMultiDropChannelNumber: Sets the multi-drop connection channel No. (Ch1/Ch2) with a Qn multidrop connection. This will be invalid if any other connection is set.

Value	Meaning
0x01	Connection to channel 1
0x02	Connection to channel 2

IThroughNetworkType: Sets whether to include MNET/10 mode in the networks to pass through when accessing other stations via MELSECNET/10H.

Value	Meaning
0x00	Does not include MNET/10 mode
0x01	Includes MNET/10 mode

IIntelligentPreferenceBit: Sets whether to connect through the multi-drop link destination network with a Qn multi-drop connection (via CC-Link, serial communication). (This is to distinguish the host network module.)

Value	Meaning
0x00	Multi-drop does not access other destination networks
0x01	Multi-drop accesses other destination networks

IDidPropertyBit: With Q series host station intelligent special access (intelligent special module mounted to the CPU of the host station), by disabling the following settings, it is not necessary to set "*IUnitNumber*". (Set only by the module I/O number of "*IIONumber*".)

Value	Meaning
0x00	Enables module number
0x01	Disables module number

IDsidPropertyBit: With a Qn multi-drop connection, as the following are disabled, there is no need to set "*IDestinationIONumber*". However, if the following settings are disabled, make sure to enable "*IDidPropertyBit*". (Set by "*IUnitNumber*".)

Value	Meaning
0x00	Enables the I/O number of the last access target station
0x01	Disables the I/O number of the last access target station

plRet: Returns an error code.

S_OK: Normal termination

EZNC_COMM_ALREADYOPENED: Cannot be set because communication is already in progress

EZ_ERR_DATA_TYPE: Invalid argument data type

EZ_ERR_DATA_RANGE: Invalid argument data range

EZ_ERR_NOT_SUPPORT: Not supported

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

- **Function** Configures MELSEC communication settings. This is valid only for the C70. This function is not supported with the M700/M800 Series. (EZ_ERR_NOT_SUPPORT is returned to *plRet*.)

Call before executing **Open2()**. If it is not called, an error will occur when **Open2()** is executed. The setting details are retained until the object is released by **Release()**. Temporarily, until **Close()** is performed if **Open2()** is performed, re-setting with **SetMelsecProcotol()** cannot be done. An error will occur. If an error occurs in **SetMelsecProcotol()**, the setting before the error occurred is maintained. The setting contents that resulted in the error are disabled. Sets NULL to the pointer setting argument such as "*lpcwszHostAddress*" when not used.

(Note) This method does not support automation interfaces. Use is limited to a custom interface.

```

□ typedef struct EZNcStOpen{
Structure   LONG      INetworkNumber;           // Network number
              LONG      IStationNumber;       // Station number
              LONG      IUnitNumber;           // Module number
              LONG      IConnectUnitNumber;    // Module number
              LONG      IIONumber;            // Module I/O number
              LONG      ICpuType;             // Target CPU
              LONG      IUnitType;           // Connected module
              LONG      IPacketType;         // Packet transmission type
              LONG      IProtocolType;        // Communication protocol type
              LONG      IPortNumber;         // Connection port number
              LONG      IBaudRate;           // Baud rate
              LONG      IDataBits;           // Number of byte data bits
              LONG      IParity;            // Parity bit
              LONG      IStopBits;          // Stop bit
              LONG      IControl;           // Control signal
              WCHAR *   IpcwszHostAddress;    // Connection host name (IP address)
              LONG      ICpuTimeOut;        // CPU monitoring timer
              LONG      ITimeOut;           // Time-out value
              LONG      ISumCheck;          // Sum check
              LONG      ISourceNetworkNumber; // Request source network number
              LONG      ISourceStationNumber; // Request source station number
                                     (personal computer side station number)
              LONG      IDestinationPortNumber; // Port number
              LONG      IDestinationIONumber; // Actual input/output No.
              LONG      IConnectChannelNumber; // Channel No.
              LONG      IMultiDropChannelNumber; // Multi-drop connection channel No.
              LONG      IThroughNetworkType; // MNET/10 mode
              LONG      IIntelligentPreferenceBit; // Via multi-drop link destination
              LONG      IDidPropertyBit;    // Intelligent special module setting
              LONG      ISidPropertyBit;    // Multi-drop connection setting
} EZNCST_OPEN;

```

□ **Open2(), Close()**
Reference

□ **Specifica-
tion**

2.4.1 IEZNCSystem::GetVersion **Get NC system S/W number, name**

```

□ Custom call procedure
HRESULT      GetVersion(
                LONG IAxisNo,           // (I) Axis number
                LONG IIndex,           // (I) Parameter number
                LPOLESTR* lppwszBuffer, // (O) NC system S/W number, name
                LONG* plRet             // (O) Error code
            )

□ Automation call procedure
System_GetVersion(
    IAxisNo As LONG           // (I) Axis number
    IIndex As LONG           // (I) Parameter number
    lppwszBuffer As STRING*  // (O) NC system S/W number, name
) As LONG                   // (O) Error code
    
```

□ **Argument**

IAxisNo: Sets the axis number (From Axis 1 = from **1**)

IIndex: Sets the parameter number. Refer to the table below.

lppwszBuffer: Returns the system S/W number, name, and control S/W version as a **UNICODE** character string.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_DATASIZE: Application does not fit into prepared buffer

EZNC_DATA_READ_READ: Data is not readable

<i>IIndex</i>	Description	Data range
0	NC system S/W number, name, and PLC version	Depends on the system specifications.
1	Control unit, extension unit	Depends on the system specifications.
2	RIO unit, terminal RIO unit Axis setting is necessary only for C70.	Depends on the system specifications.

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Failure

-
- **Function** Gets the various NC system S/W version information as a **UNICODE** character string.
- 0: Gets the system S/W number, name, and PLC version of the NC system.
The format of the character string data becomes as follows.
NC system S/W number\tNC system name\tprogrammable controller system number\0
A **TAB** code is inserted between the NC system number and the NC system S/W name.
The end of the data becomes a **NULL** code.
Output example: "BND-2005W000-A0 MITSUBISHI CNC 830WM"
If there is no item, a **TAB** code will follow. If a termination item does not exist, a **NULL** code will follow the **TAB** code.
- 1: Gets the control unit and extension unit versions.
The format of the character string data becomes as follows.
Control unit number\tExtension unit number\0
A **TAB** code is inserted between the control unit number and the extension unit number.
The end of the data becomes a **NULL** code.
- 2: Gets the RIO unit and terminal RIO unit versions.
The format of the character string data becomes as follows.
RIO unit number\tTerminal RIO unit number\0
M700 has 24 items with RIO unit 1\t RIO unit 2\t...\0.
M700/M800 series have up to 32 items (*) with RIO unit 1¥\t RIO unit 2¥\t5 ¥¥¥0.
* Confirm the number of RIO unit with MTB.
A **TAB** code is inserted between the RIO unit number and the terminal RIO unit number.
The end of the data becomes a **NULL** code.
As the character string area memory is allocated in this product, clients using VC++ need to release the character string area memory explicitly with **CoTaskMemFree()**.
-

□ **Reference**

□ **Specifica-
tion**

2.4.2 IEZNCSystem::GetSystemInformation

Get NC system information

□ Custom call procedure

```
HRESULT      GetSystemInformation(
                LONG IType,                // (I) Information type
                LONG* pISystem,           // (O) System information
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
System_GetSystemInformation(
    IType As LONG                // (I) Information type
    pISystem As LONG*           // (O) System information
    ) As LONG                    // (O) Error code
```

□ **Argument** *IType*: Sets the NC system information type. Refer to the table below.

pISystem: Returns the NC system information.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_READ: Data is not readable

<i>IType</i>	Description	Data range
0	Part system enabled/disabled	0: Part system disabled 1: Part system enabled
1	Number of axes each part system	This will be different for NC systems with 1 [Axis] or more.

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets information regarding the NC system.

□ **Reference**

□ **Specifica-
tion**

System

2.4.3 IEZNCSystem::GetAlarm

Get alarm information

□ Custom call procedure

```

HRESULT      GetAlarm(
                LONG IMessageNumber,           // (I) Number of messages to get
                LONG IAlarmType,               // (I) Alarm type to get
                LPOLESTR* IppwszBuffer,       // (O) Message character string
                LONG* pIRet                     // (O) Error code
            )

```

□ Automation call procedure

```

System_GetAlarm(
    IMessageNumber As LONG           // (I) Number of messages to get
    IAlarmType As LONG               // (I) Alarm type to get
    IppwszBuffer As STRING*         // (O) Message character string
) As LONG                           // (O) Error code

```

□ **Argument** *IMessageNumber*: Sets the number of messages to get. Value: **1 to 10 (maximum)**

IAlarmType: Sets the alarm type to get.

Value	Meaning
M_ALM_NC_ALARM	NC alarm
M_ALM_STOP_CODE	Stop code
M_ALM_PLC_ALARM	PLC alarm message
M_ALM_OPE_MSG	Operator message
M_ALM_ALL_ALARM	No alarm type distinction

IppwszBuffer: Gets the alarm message as a **UNICODE** character string.

The message format includes **CR**, **LF** codes to distinguish between messages. In addition, **NULL** is inserted at the end of the message.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_OPE_CURRALM_ADDR: Invalid part systems, axes settings

EZNC_OPE_CURRALM_ALMTYPE: Invalid alarm type

EZNC_OPE_CURRALM_DATAERR: Error in communication data between NC and personal computer

EZNC_OPE_CURRALM_DATASIZE: Application does not fit into prepared buffer

EZNC_OPE_CURRALM_NOS: Invalid number of got messages

EZ_ERR_NOT_SUPPORT : Not supported

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets the alarm message of the alarm currently generated in the setting NC control unit. The language of the alarm message adheres to an NC parameter (#1043 lang). Messages are retrieved in descending order of importance. As the character string area memory is allocated in this product, clients using VC++ need to release the character string area memory explicitly with **CoTaskMemFree()**. This function is not supported with the M800 Series. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)

□ **Reference**

□ **Specification**

System	(All systems when 0)
--------	----------------------

2.4.4 IEZNCSystem2::GetAlarm2

Get alarm information

□ Custom call procedure

```

HRESULT      GetAlarm2(
                LONG lMessageNumber,           // (I) Number of messages to get
                LONG lAlarmType,             // (I) Alarm type to get
                LPOLESTR* lppwszBuffer,       // (O) Message character string
                LONG* plRet                  // (O) Error code
                )

```

□ Automation call procedure

```

System_GetAlarm2(
    lMessageNumber As LONG           // (I) Number of messages to get
    lAlarmType As LONG              // (I) Alarm type to get
    lppwszBuffer As STRING*        // (O) Message character string
    ) As LONG                        // (O) Error code

```

□ **Argument** *lMessageNumber*: Sets the number of messages to get. Value: **1 to 10 (maximum)**

lAlarmType: Sets the alarm type to get.

Value	Meaning
M_ALM_NC_ALARM	NC alarm
M_ALM_STOP_CODE	Stop code
M_ALM_PLC_ALARM	PLC alarm message
M_ALM_OPE_MSG	Operator message
M_ALM_ALL_ALARM	No alarm type distinction

lppwszBuffer: Gets the alarm message as a **UNICODE** character string.

The message format includes **CR**, **LF** codes to distinguish between messages. In addition, **NULL** is inserted at the end of the message.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_OPE_CURRALM_ADDR: Invalid system, spindle specification

EZNC_OPE_CURRALM_ALMTYPE: Invalid alarm type

EZNC_OPE_CURRALM_DATAERR: Error in communication data between NC and personal computer

EZNC_OPE_CURRALM_DATASIZE: Application does not fit into prepared buffer

EZNC_OPE_CURRALM_NOS: Invalid number of got messages

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets the alarm message of the alarm currently generated in the setting NC control unit. The language of the alarm message adheres to an NC parameter (#1043 lang). Messages are retrieved in descending order of importance. As the character string area memory is allocated in this product, clients using VC++ need to release the character string area memory explicitly with **CoTaskMemFree()**.

□ **Reference**

□ **Specification** System (All systems when 0)

2.5.1 IEZNCPosition::GetWorkPosition **Get workpiece coordinate position**

```

□ Custom call procedure
HRESULT      GetWorkPosition(
                LONG IAxisNo,                // (I) Axis number setting
                DOUBLE* pdPosition,          // (O) Workpiece coordinate position
                LONG ISkipOn,                // (I) Skip on flag
                LONG* pIRet                  // (O) Error code
            )

□ Automation call procedure
Position_GetWorkPosition(
    IAxisNo As LONG                // (I) Axis number setting
    pdPosition As DOUBLE*          // (O) Workpiece coordinate position
    ISkipOn As LONG                // (I) Skip on flag
    ) As LONG                       // (O) Error code
    
```

□ **Argument** *IAxisNo*: Sets the axis number (From Axis 1 = from 1)

pdPosition: Returns the workpiece coordinate position of the set axis number of the set part system.
Data range: -99,999.999 to 99,999.999 [mm]

ISkipOn : Sets the skip on flag.

Value	Meaning
1	Skip is on
0	Normal

pIRet: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZ_ERR_DATA_TYPE: Invalid argument data type
EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting
EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the workpiece coordinate position of the set system/axis number
If 1 is set for the skip on flag, the workpiece coordinate position at the time the skip on signal is input will be got.

□ **Reference**

□ **Specification** System Axis number

2.5.2 IEZNCPosition::GetWorkPosition2 **Get workpiece coordinate position**

□ Custom call procedure

```
HRESULT      GetWorkPosition2(
                LONG IAxisNo,           // (I) Axis number
                DOUBLE* pdPosition,    // (O) Workpiece coordinate position
                LONG ISkipOn,          // (I) Skip on flag
                LONG* plRet             // (O) Error code
            )
```

□ Automation call procedure

```
Position_GetWorkPosition2(
    IAxisNo As LONG           // (I) Axis number
    pdPosition As DOUBLE*    // (O) Workpiece coordinate position
    ISkipOn As LONG          // (I) Skip on flag
) As LONG                    // (O) Error code
```

□ *IAxisNo*: Sets the axis number (From Axis 1 = from 1)

Argument

pdPosition: Returns the workpiece coordinate position of the set axis number of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

ISkipOn : Sets the skip on flag.

Value	Meaning
1	Skip is on
0	Normal

plRet: Returns an error code. (Upon automation, the return value is used.)

- S_OK**: Normal termination
- EZ_ERR_DATA_TYPE**: Invalid argument data type
- EZNC_DATA_READ_ADDR**: Invalid part system, axis No. setting
- EZNC_DATA_READ_READ**: Data is not readable
- EZ_ERR_NOT_SUPPORT**: Not supported

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the workpiece coordinate position of the set system/axis number. If 1 is set for the skip on flag, the workpiece coordinate position at the time the skip on signal is input will be got.

□ Reference

□ **Specifica-
tion** System Axis number

2.5.3 IEZNCPosition::GetMachinePosition

Get machine position

□ Custom call procedure

```

HRESULT      GetMachinePosition(
                LONG IAxisNo,                // (I) Axis number
                DOUBLE* pdPosition,          // (O) Machine position
                LONG ISkipOn,                // (I) Skip on flag
                LONG* pIRet                    // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetMachinePosition(
    IAxisNo As LONG                // (I) Axis number
    pdPosition As DOUBLE*          // (O) Machine position
    ISkipOn As LONG                // (I) Skip on flag
) As LONG                          // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis. (From Axis 1 = from 1)

pdPosition: Returns the machine position of the set axis number of the set part system.
Data range: -99,999.999 to 99,999.999 [mm]
This will vary according to the NC system specifications and parameters.

ISkipOn : Sets the skip on flag.

Value	Meaning
1	Skip is on
0	Normal

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis number setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the machine coordinate position for the set system/axis number (coordinate position in a basic machine coordinate system).
If 1 is set for the skip on flag, the machine coordinate position at the time the skip on signal is input will be got.

□ **Reference**

□ **Specification** System Axis number

2.5.4 IEZNCPosition::GetMachinePosition2

Get machine position

□ Custom call procedure

```

HRESULT      GetMachinePosition2(
                LONG IAxisNo,                // (I) Axis number
                DOUBLE* pdPosition,          // (O) Machine position
                LONG ISkipOn,                // (I) Skip on flag
                LONG* pIRet                   // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetMachinePosition2(
    IAxisNo As LONG                // (I) Axis number
    pdPosition As DOUBLE*          // (O) Machine position
    ISkipOn As LONG                // (I) Skip on flag
) As LONG                          // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis. (From Axis 1 = from 1)

pdPosition: Returns the machine position of the set axis number of the set part system.
Data range: -99,999.999 to 99,999.999 [mm]
This will vary according to the NC system specifications and parameters.

ISkipOn : Sets the skip on flag.

Value	Meaning
1	Skip is on
0	Normal

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis number setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the machine coordinate position for the set system/axis number (coordinate position in a basic machine coordinate system).

If 1 is set for the skip on flag, the machine coordinate position at the time the skip on signal is input will be got.

□ **Reference**

□ **Specification**

System

Axis number

2.5.5 IEZNCPosition::GetCurrentPosition

Get relative position

□ Custom call procedure

```
HRESULT      GetCurrentPosition(
                LONG IAxisNo,                // (I) Axis number
                DOUBLE* pdPosition,         // (O) Relative position
                LONG* pIRet                  // (O) Error code
            )
```

□ Automation call procedure

```
Position_GetCurrentPosition(
    IAxisNo As LONG                // (I) Axis number
    pdPosition As DOUBLE*         // (O) Relative position
    ) As LONG                       // (O) Error code
```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

pdPosition: Returns the relative position from the position at a completion of the dog type zero point return or from the preset position configured by G92/origin set/counter set.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis number setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the relative position to the position at a completion of the dog type zero point return or to the preset position configured by G92/origin set/counter set of the set system/axis number.

□ Reference

□ **Specifica-
tion** System Axis number

2.5.6 IEZNCPosition::GetDistance

Get remaining command

□ Custom call procedure

```

HRESULT      GetDistance(
                LONG IAxisNo,                // (I) Axis number
                DOUBLE* pdDistance,         // (O) Remaining command
                LONG ISkipOn,               // (I) Skip on flag
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetDistance(
    IAxisNo As LONG                // (I) Axis number
    pdDistance As DOUBLE*          // (O) Remaining command
    ISkipOn As LONG                // (I) Skip on flag
) As LONG                          // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis number (From Axis 1 = from 1)

pdDistance: Returns the remaining command of the travel command being executed in the set axis No. of the set system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

ISkipOn : Sets the skip on flag.

Value	Meaning
1	Skip is on
0	Normal

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system, axis number setting

EZNC_DATA_READ_READ: Data is not readable

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets the remaining command of the travel command being executed for the set part system/axis number.

If 1 is set for the skip on flag, the remaining command of the travel command at the time the skip on signal is input will be got.

□ **Reference**

□ **Specification**

System

Axis number

2.5.7 IEZNCPosition::GetDistance

Get remaining command

□ Custom call procedure

```

HRESULT      GetDistance2(
                LONG IAxisNo,                // (I) Axis number
                DOUBLE* pdDistance,         // (O) Remaining command
                LONG ISkipOn,               // (I) Skip on flag
                LONG* pIRet                 // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetDistance2(
    IAxisNo As LONG                // (I) Axis number
    pdDistance As DOUBLE*         // (O) Remaining Command r
    ISkipOn As LONG               // (I) Skip on flag
) As LONG                         // (O) Error code

```

□ *IAxisNo*: Sets the axis number. (From Axis 1 = from 1)

Argument

pdDistance: Returns the remaining command of the travel command being executed in the set axis number. of the set system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

ISkipOn : Sets the skip on flag.

Value	Meaning
1	Skip is on
0	Normal

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system, axis number setting

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the remaining command of the travel command being executed for the set system/axis number.
If 1 is set for the skip on flag, the remaining command of the travel command at the time the skip on signal is input will be got.

□ Reference

□ **Specification**

System

Axis number

2.5.8 IEZNCPosition::GetNextDistance

Get next command

□ Custom call procedure

```

HRESULT      GetNextDistance(
                LONG IAxisNo,                // (I) Axis No. setting
                DOUBLE* pdDistance,         // (O) Next command
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetNextDistance(
    IAxisNo As LONG                // (I) Axis No. setting
    pdDistance As DOUBLE*         // (O) Next command
    ) As LONG                       // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

pdDistance: Returns the travel command of the next block for the set axis No. of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ Gets the travel command of the next block for the set system/axis No.

Function

□ Reference

□ Specification

System	Axis number
--------	-------------

2.5.9 IEZNCPosition::GetFeedSpeed

Get feed speed

□ Custom call procedure

```

HRESULT GetFeedSpeed(
    LONG IFeedType,           // (I) Feed speed type
    DOUBLE* pdSpeed,         // (O) Feed speed
    LONG* pIRet               // (O) Error code
)

```

□ Automation call procedure

```

Position_GetFeedSpeed(
    IFeedType As LONG         // (I) Feed speed type
    pdSpeed As DOUBLE*       // (O) Feed speed
) As LONG                    // (O) Error code

```

□ *IFeedType*: Sets the type of feed speed to get.

Argument	Value	Meaning
	0	F command feed speed (FA)
	1	Manual effective feed speed (FM)
	2	Synchronization feed speed (FS)
	3	Automatic effective feed speed (Fc)
	4	Screw lead (FE)

pdSpeed: Returns the feed speed of the specified system.

Data range:

FA	: 0.000 to 1000000.000 [mm/min]
FM	: 0.000 to 1000000.000 [mm/min]
FS	: 0.000 to 1000.0000000 [mm/rev]
FC	: 0.000 to 1000000.000 [mm/min]
FE	: 0.000 to 1000.0000000 [mm]

Feed speed type	Data range	
	M700/M800 series	C70
FA	0.000 to 1,000,000.000 [mm/min]	0.000 to 1,000,000.000 [mm/min]
FM	0.000 to 1,000,000.000 [mm/min]	0.000 to 1,000,000.000 [mm/min]
FS	0.000 to 1,000.0000000 [mm/rev]	0.000 to 1,000.0000000 [mm/rev]
Fc	0.000 to 1,000,000.000 [mm/min]	0.000 to 1,000,000.000 [mm/min]
FE	0.000 to 1,000.0000000 [mm] (Unit will vary)	0.000 to 1,000.0000000 [mm]

The number of digits is determined by the NC type, options, and MTB setting values (parameters).

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the feed speed of the set system.

□ **Reference**

□ **Specification** System

2.5.10 IEZNCPosition::GetTCPSpeed

Get tip speed

□ Custom call procedure

```

HRESULT      GetTCPSpeed (
                DOUBLE* pdPosition,           // (O) Tip speed
                LONG* plRet                    // (O) Error code
            )

```

□ Automation call procedure

```

Position_ GetTCPSpeed (
    pdPosition As DOUBLE*           // (O) Tip speed
) As LONG                          // (O) Error code

```

□ *pdPosition*: Returns the tip speed of the set system.

Argument

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid system specification

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

Return value	Value	Meaning
--------------	-------	---------

	S_OK	Normal termination
--	-------------	--------------------

	S_FALSE	Communication failure
--	----------------	-----------------------

□ **Function** Gets the tip speed of the set part system.

If **1** is set for the skip on flag, the workpiece coordinate position at the time the skip on signal is input will be got.

This is valid only for the M700/M800 series.

This function is not supported with C70.

□ **Reference**

□ **Specifica-
tion** System

2.5.11 IEZNCPosition::GetManualOverlap

Get manual interrupt amount

□ Custom call procedure

```

HRESULT      GetManualOverlap(
                LONG IAxisNo,           // (I) Axis No. setting
                LONG IType,           // (I) Type
                DOUBLE* pdLength,     // (O) Manual interrupt amount
                LONG* pIRet           // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetManualOverlap(
    IAxisNo As LONG           // (I) Axis No. setting
    IType As LONG            // (I) Type
    pdLength As DOUBLE*     // (O) Manual interrupt amount
) As LONG                   // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IType: Sets the manual interrupt amount type to get.

Value	Meaning
0	If getting the manual interrupt amount while the manual ABS switch is off
1	If getting the manual interrupt amount while the manual ABS switch is on

pdLength: Returns the manual interrupt amount for the set axis No. of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the manual interrupt amount of the set part system/axis.

□ **Reference**

□ **Specifica-
tion** System Axis number

2.5.12 IEZNCPosition::GetManualOverlap2

Get manual interrupt amount

□ Custom call procedure

```

HRESULT      GetManualOverlap2(
                LONG IAxisNo,           // (I) Axis No.
                LONG IType,             // (I) Type
                DOUBLE* pdLength,       // (O) Manual interrupt amount
                LONG* pIRet              // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetManualOverlap2(
    IAxisNo As LONG           // (I) Axis No.
    IType As LONG             // (I) Type
    pdLength As DOUBLE*      // (O) Manual interrupt amount
) As LONG                    // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

IType: Sets the manual interrupt amount type to get.

Value	Meaning
0	If getting the manual interrupt amount while the manual ABS switch is off
1	If getting the manual interrupt amount while the manual ABS switch is on

pdLength: Returns the manual interrupt amount for the set axis No. of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system, axis specification

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the manual interrupt amount of the set part axis of the set part system.

□ **Reference**

□ **Specifica-
tion** System Axis number

2.5.13 IEZNCPosition::GetProgramPosition

Get program position

□ Custom call procedure

```

HRESULT      GetProgramPosition(
                LONG IAxisNo,                // (I) Axis No.
                DOUBLE* pdPosition,         // (O) Program position
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Position_GetProgramPosition(
    IAxisNo As LONG                // (I) Axis No.
    pdPosition As DOUBLE*         // (O) Program position
    ) As LONG                       // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

pdPosition: Returns the program position.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ Gets program position.

Function

□ Reference

□ Specification System Axis number

2.5.14 IEZNCPosition::GetProgramPosition3

Get program position

□ Custom call procedure

```

HRESULT      GetProgramPosition3(
              LONG IAxisNo,           // (I) Axis No.
              DOUBLE* pdPosition,    // (O) Program position
              LONG* pIRet             // (O) Error code
              )

```

□ Automation call procedure

```

Position_GetProgramPosition3(
  IAxisNo As LONG           // (I) Axis No.
  pdPosition As DOUBLE*    // (O) Program position
  ) As LONG                 // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

pdPosition: Returns the program position.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No.setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ Gets program position.

Function

□ Reference

□ Specification System Axis number

2.5.15 IEZNCPosition::GetTCPMachinePosition**Get tip machine position**□ **Custom call procedure**

```

HRESULT      GetTCPMachinePosition (
                LONG IAxisNo,                // (I) Axis No.
                DOUBLE* pdPosition,         // (O) Tip machine position
                LONG* pIRet                  // (O) Error code
            )

```

□ **Automation call procedure**

```

Position_ GetTCPMachinePosition (
    IAxisNo As LONG                // (I) Axis No.
    pdPosition As DOUBLE*         // (O) Tip machine position
    ) As LONG                      // (O) Error code

```

□ *IAxisNo*: Set the axis No. (From Axis 1 = from 1)

Argument

pdPosition: Returns the tip machine position of the set axis No. of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the tip machine position.
This is valid only for the M700/M800 series.
This function is not supported with C70.

□ **Reference**

□ **Specifica-
tion** System Axis number

2.5.16 IEZNCPosition::GetTCPWorkPosition

Get tip workpiece position

□ Custom call procedure

```

HRESULT      GetTCPWorkPosition (
                LONG IAxisNo,                // (I) Axis No.
                DOUBLE* pdPosition,         // (O) Tip workpiece position
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Position_ GetTCPWorkPosition (
    IAxisNo As LONG                // (I) Axis No.
    pdPosition As DOUBLE*          // (O) Tip workpiece position
    ) As LONG                       // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ Argument

pdPosition: Returns the tip workpiece position of the set axis No. of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets the tip workpiece position. This is valid only for the M700/M800 series. This function is not supported with C70.	

□ Reference

□ Specification

System	Axis number
--------	-------------

2.5.17 IEZNCPosition::GetFeedbackPosition

Get feedback position

□ Custom call procedure

```

HRESULT      GetFeedbackPosition (
                LONG IAxisNo,                // (I) Axis No.
                DOUBLE* pdPosition,         // (O) Feedback position
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Position_ GetFeedbackPosition (
    IAxisNo As LONG                // (I) Axis No.
    pdPosition As DOUBLE*         // (O) Feedback position
    ) As LONG                       // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

pdPosition: Returns the feedback position of the set axis of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
Function	Gets the feedback position. This is valid only for the M700/M800 series. This function is not supported with C70.	

□ Reference

□ Specification

System

Axis number

2.5.18 IEZNCPosition::GetTableCoordinationPosition

Get table coordinate system counter

□ Custom call procedure

```

HRESULT      GetTableCoordinationPosition (
                LONG IAxisNo,           // (I) Axis No.
                DOUBLE* pdPosition,    // (O) Table coordinate system counter
                LONG* pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

Position_ GetTableCoordinationPosition (
            IAxisNo As LONG           // (I) Axis No.
            pdPosition As DOUBLE*    // (O) Table coordinate system counter
            ) As LONG                // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ Argument

pdPosition: Returns the table coordinate system counter of the set axis of the set part system.
Data range: -99,999.999 to 99,999.999 [mm]
This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
----------------	-------	---------

	S_OK	Normal termination
--	-------------	--------------------

	S_FALSE	Communication failure
--	----------------	-----------------------

□ **Function** Gets the table coordinate system counter.
This is valid only for the M700/M800 series.
This function is not supported with C70.

□ **Reference**

□ **Specification** System Axis number

2.5.19 IEZNCPosition::GetWorkInstallationPosition

Get workpiece installation
coordinate system counter

□ Custom call procedure

```

HRESULT      GetWorkInstallationPosition (
                LONG IAxisNo,           // (I) Axis No.
                DOUBLE* pdPosition,    // (O) Workpiece installation coordinate system counter
                LONG* pIRet             // (O) Error code
            )
    
```

□ Automation call procedure

```

Position_ GetWorkInstallationPosition (
    IAxisNo As LONG           // (I) Axis No.
    pdPosition As DOUBLE*    // (O) Workpiece installation coordinate system counter
    ) As LONG                 // (O) Error code
    
```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ Argument

pdPosition: Returns the workpiece installation coordinate system counter of the set axis of the set system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the workpiece installation coordinate system counter.
This is valid only for the M700/M800 series.
This function is not supported with C70.

□ Reference

□ **Specification** System Axis number

2.5.20 IEZNCPosition::GetInclinedSurfacePosition

Get inclined surface
coordinate system counter

□ Custom call procedure

```

HRESULT      GetInclinedSurfacePosition (
                LONG IAxisNo,           // (I) Axis No.
                DOUBLE* pdPosition,    // (O) Inclined surface coordinate system counter
                LONG* pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

Position_ GetInclinedSurfacePosition (
    IAxisNo As LONG           // (I) Axis No.
    pdPosition As DOUBLE*    // (O) Inclined surface coordinate system counter
) As LONG                   // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ Argument

pdPosition: Returns the inclined surface coordinate system counter of the set axis No. of the set part system.

Data range: -99,999.999 to 99,999.999 [mm]

This will vary according to the NC system specifications and parameters.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the inclined surface coordinate system counter.
This is valid only for the M700/M800 series.
This function is not supported with C70.

□ Reference

□ **Specification** System Axis number

2.6.1 IEZNCCommand2::GetGCodeCommand **Get G code modal command value**

□ Custom call procedure

```
HRESULT GetGCodeCommand(
    LONG IType, // (I) Type
    DOUBLE* pdValue, // (O) Command value
    LONG* plRet // (O) Error code
)
```

□ Automation call procedure

```
Command_GetGCodeCommand(
    IType As LONG // (I) Type
    pdValue As DOUBLE* // (O) Command value
) As LONG // (O) Error code
```

□ *IType*: Sets the G code modal command value type to get.

Argument The following describes examples for the M700/M800 series M system. The content will differ depending on the type and the settings.

Value	Meaning
1	Group 1 (Interpolation mode) G00, G01, G02, G03, G33, G02.1, G03.1, G02.3, G03.3, G02.4, G03.4, G062 command modal
2	Group 2 (Plane selection) G17, G18, G19 command modal
3	Group 3 (Absolute) G90, (incremental) G91 command modal
4	Group 4 (Chuck barrier) G22, G23 command modal
5	Group 5 (Feed mode) G93, G94, G95 command modal
6	Group 6 (Inch) G20, (millimeter) G21 command modal
7	Group 7 (Radial compensation mode) G40, G41, G42, G41.2, G42.2 command modal
8	Group 8 (Length compensation mode) G43, G44, G43.1, G43.4, G43.5, G49 command modal
9	Group 9 (Fixed cycle mode) G70, G71, G72, G73, G74, G75, G76, G77, G78, G79, G80, G81, G82, G83, G84, G85, G86, G87, G88, G89 command modal
10	Group 10 (Initial point return) G98, (R point return) G99 command modal
11	Group 11 G50, G51 command modal
12	Group 12 (Workpiece coordinate system modal) G54, G54.1, G55, G56, G57, G58, G59 command modal
13	Group 13 (Cutting mode) G61, G61.1, G61.2, G62, G63, G63.1, G63.2, G64 command modal
14	Group 14 (Modal call) G66, G66.1, G67 command modal
15	Group 15 (Normal control) G40.1, G41.1, G42.1 command modal (only for M700/M800 series M system)
16	Group 16 (Coordinate rotation) G68, G68.2, G68.3, G69 (only for M700/M800 series M system)
17	Group 17 (Constant surface speed control) G96, G97 command modal
18	Group 18 (Polar coordinate command) G15, G16 command modal
19	Group 19 (G command mirror image) G50.1, G51.1 command modal
20	Group 20 (Spindle selection) G43.1, G44.1, G47.1 command modal
21	Group 21 (Cylindrical interpolation / polar coordinate interpolation) G07.1, G107, G12.1, G112, G13.1, G113 (only for M700/M800 series M system)

pdValue : Returns the current G code modal command value of the set part system.
 Value (Example) Meaning

2	G02
17	G17
50.2	G50.2

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination
EZ_ERR_DATA_TYPE: Invalid argument data type
EZNC_DATA_READ_ADDR: Invalid system
EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets the G code command modal value of the set part system. Refer to the "Programming Manual" of each model for the individual model's G command and group list. Also, depending on the model, different operation than with the original G code command may be incorporated by using the G code macro call. Check after referring to the instructions issued by MTB	
□ Reference		
□ Specification	System	

2.6.2 IEZNCCommand2::GetToolCommand

Get tool compensation
number

□ Custom call procedure

```

HRESULT      GetToolCommand(
                LONG IAxisNo,           // (I) Axis No.
                LONG IType,           // (I) Type
                LONG* pIValue,       // (O) Tool compensation number
                LONG* pIRet         // (O) Error code
                )

```

□ Automation call procedure

```

Command_GetToolCommand(
    IAxisNo As LONG           // (I) Axis No.
    IType As LONG           // (I) Type
    pIValue As LONG*       // (O) Tool compensation number
    ) As LONG               // (O) Error code

```

- **Argument** *IAxisNo*: Sets the axis when getting the length compensation number.
(From Axis 1 = from 1)

IType: Sets the tool compensation type to get.

Value	Meaning
0	D command value of the shape compensation number
1	D command value of the wear compensation number
2	H command value of the length compensation number (axis specification necessary)

pIValue : Returns the shape/wear compensation number of the tool for the set part system and the tool length compensation number of the set axis No. in the set part system.

Data range: 1 to 200 (range depends on the number of tool offset sets)

Value meaning: 1 = D1, 1 = H1

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

- **Function** Gets the shape/wear compensation number of the tool for the set part system and the tool length compensation number of the set axis No. in the set part system.

□ **Reference**

- **Specifica-
tion** System Axis number

2.6.3 IEZNCCommand2::GetFeedCommand

Get feed speed command value

□ Custom call procedure

```

HRESULT      GetFeedCommand(
                LONG IType,                // (I) Type
                DOUBLE* pdValue,          // (O) Command value
                LONG* pIRet                // (O) Error code
            )

```

□ Automation call procedure

```

Command_GetFeedCommand(
    IType As LONG                // (I) Type
    pdValue As DOUBLE*          // (O) Command value
) As LONG                        // (O) Error code

```

□ *IType*: Sets the command value type to get.

Argument	Value	Meaning
	0	F command feed speed (FA)
	1	Manual effective feed speed (FM)
	2	Synchronization feed speed (FS)
	3	Automatic effective feed speed (FC)
	4	Screw lead (FE)
	5	Tip speed (TCP) (M700/M800 series only)

pdValue: Returns the current feed speed command value of the set part system.

Feed speed type	Data range	
	M700/M800 series	C70
FA	0.000 to 10,000,000.000 [mm/min]	0.000 to 1,000,000.000 [mm/min]
FM	0.000 to 1,000,000.000 [mm/min]	0.000 to 1,000,000.000 [mm/min]
FS	0.000 to 1,000,000.000000 [mm/rev]	0.000 to 1,000,000.000 [mm/rev]
FC	0.000 to 100,000.000 [mm/min]	0.000 to 1,000,000.000 [mm/min]
FE	0.000 to 100,000.000 [mm/rev] (Unit will vary)	0.000 to 999.9999 [mm/rev]

The total number of digits is determined by the NC model, options, and MTB setting values (parameters).

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid system

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ Gets the current feed speed command value of the set part system.

□ Function

□ Reference

□ Specification

System

2.6.4 IEZNCCommand2::GetCommand2

Get M/S/T/B function command modal value

□ Custom call procedure

```

HRESULT      GetCommand2(
                LONG IType,                // (I) Command type
                LONG IIndex                // (I) Command number
                LONG* pIValue,            // (O) Command value
                LONG* pIRet                // (O) Error code
            )

```

□ Automation call procedure

```

Command_GetCommand2(
    IType As LONG                // (I) Command type
    IIndex As LONG                // (I) Command number
    pIValue As LONG*            // (O) Command value
) As LONG                        // (O) Error code

```

□ *IType*: Sets the command value type to get.

Argument	Value	Meaning
EZNC_M		M command (sub function M command value)
EZNC_S		S command (spindle rotation speed S command value)
EZNC_T		T command (tool change T command value)
EZNC_B		B command (second sub function command value (specification of index table position, etc.))

IIndex: Set the command number.

Example) When *IType* = EZNC_M and *IIndex*= 1, the M command will be 1.

Model \ Command	C70	M700 series	M800 series
M	1 to 4	1 to 4	1 to 4
S	1 to 7	1 to maximum number of spindles*	1 to maximum number of spindles*
T	1 to 4	1	1
B	1 to 4	1 to 4	1 to 4

*For the maximum number of spindles, refer to the product catalog for each Mitsubishi CNC.

pIValue : Returns the current command value of the set part system.

Data range: 0 to 99,999,999 (maximum)

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_SUBSECT: Invalid subsection number

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ Gets the current command modal value for the M/S/T/B function of the set part system.

Function

□ **SetCommad2()**

Reference

□ Specification

System	(PLC axis system cannot set)
--------	------------------------------

2.6.5 IEZNCCommand2::SetCommand2

Set manual numerical value command value settings for M/S/T/B functions

□ Custom call procedure

```

HRESULT      SetCommand2(
                LONG IType,                // (I) Type
                LONG IIndex                // (I) Command number
                LONG IValue,              // (I) Command value
                LONG* pIRet                // (O) Error code
            )

```

□ Automation call procedure

```

Command_SetCommand2(
    IType As LONG                // (I) Type
    IIndex As LONG              // (I) Command number
    IValue As LONG              // (I) Command value
) As LONG                       // (O) Error code

```

□ *IType*: Sets the command value type to get.

Argument	Value	Meaning
EZNC_M		M command (sub function M command value)
EZNC_S		S command (spindle rotation speed S command value)
EZNC_T		T command (tool change T command value)
EZNC_B		B command (second sub function command value (specification of index table position, etc.))

IIndex: Sets the set number.

Example) When *IType* = EZNC_M and *IIndex*= 1, the M command will be 1.

Model Command	C70	M700 series	M800 series
M	1 to 4	1 to 4	1 to 4
S	1 to 7	1 to maximum number of spindles*	1 to maximum number of spindles*
T	1 to 4	1	1
B	1 to 4	1 to 4	1 to 4

*For the maximum number of spindles, refer to the product catalog for each Mitsubishi CNC.

IValue: Sets the command value of the set part system or the axis No.

Data range: 0 to 99999999 (maximum)

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_WRITE_ADDR: Invalid part system setting

EZNC_DATA_WRITE_SUBSECT: Invalid subsection number

EZ_ERR_NOT_SUPPORT: Not supported

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets the manual numerical value command value of the M/S/T/B function of the axis No. or the set part system.

□ **Reference** **GetCommand2()**

2.7.1 IEZNCProgram2::CurrentBlockRead **Read current program block**

□ Custom call procedure

```
HRESULT CurrentBlockRead(
    LONG IBlockNumber,           // (I) Number of blocks
    LPOLESTR* lppwszProgramData, // (O) Program storage
    LONG* pICurrentBlockNo,     // (O) Block number being executed
    LONG* pIRet                 // (O) Error code
)
```

□ Automation call procedure

```
Program_CurrentBlockRead(
    IBlockNumber As LONG           // (I) Number of blocks
    lppwszProgramData As STRING*  // (O) Program storage
    pICurrentBlockNo As LONG*     // (O) Block number being executed
) As LONG                        // (O) Error code
```

□ **Argument** *IBlockNumber*: Sets the number of blocks to get. Value: 1 to 10

lppwszProgramData: Gets the program blocks as a **UNICODE** character string. To separate program blocks, **CR**, **LF** codes are inserted between them. In addition, **NULL** is inserted at the end.

pICurrentBlockNo: Returns the block number being executed in the got blocks.

Value	Meaning
0	Not in operation
1	1st block
2	2nd block

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK : Normal termination

EZNC_OPE_GETPRGBLK_ADDR: Invalid part system setting

EZNC_OPE_GETPRGBLK_DATAERR: Error in communication data between NC and personal computer

EZNC_OPE_GETPRGBLK_DATASIZE: Application does not fit into prepared buffer

EZNC_OPE_GETPRGBLK_NOS: The number of blocks setting is invalid

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the program for which the operation search has been completed or the program currently being executed. Reads the program for which the operation search has been completed for the set part system or the program block in operation.

If no operation search has been completed, the following applies.

```
lppwszProgramData = ""
pICurrentBlockNo = 0
```

As the character string area memory is allocated in this product, clients using VC++ need to release the character string area memory explicitly with **CoTaskMemFree()**.

Even if no operation search has been completed, the character string area memory must be released.

□ Reference **IEZNCOperation::Search()**

□ Specification	System
-----------------	--------

2.7.2 IEZNCProgram2::GetProgramNumber2

Get program number

□ Custom call procedure

```

HRESULT      GetProgramNumber2(
                LONG IProgramType,           // (I) Program type
                LPOLESTR* IppwszProgramNo,  // (O) Program No.
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Program_GetProgramNumber2(
    IProgramType As LONG           // (I) Program type
    IppwszProgramNo As STRING*    // (O) Program No.
) As LONG                         // (O) Error code

```

□ *IProgramType*: Sets the program type.

Argument	Value	Meaning
	EZNC_MAINPRG	Main program
	EZNC_SUBPRG	Subprogram

IppwszProgramNo: Returns the number of the program for which search has been completed or currently in automatic operation as a **UNICODE** character string. The program number is got as the program file name with the M700/M800 series.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ Function

Returns the number of the program for which search has been completed or currently in automatic operation. As the character string area memory is allocated in this product, clients using VC++ need to release the character string area memory explicitly with **CoTaskMemFree()**.

□ Reference

GetSequenceNumber(), **GetBlockNumber()**, **GetSubProLevel()**

□ Specification

System

2.7.3 IEZNCProgram2::GetSequenceNumber**Read sequence number**

□ Custom call procedure

```

HRESULT      GetSequenceNumber(
                LONG IProgramType,           // (I) Program type
                LONG* pISequenceNo,        // (O) Sequence number
                LONG* pIRet                 // (O) Error code
            )

```

□ Automation call procedure

```

Program_GetSequenceNumber(
    IProgramType As LONG           // (I) Program type
    pISequenceNo As LONG*         // (O) Sequence number
) As LONG                         // (O) Error code

```

□ **Argument** *IProgramType*: Sets the program type.

Value	Meaning
EZNC_MAINPRG	Main program
EZNC_SUBPRG	Subprogram

pISequenceNo: Returns the sequence number of the program for which search has been completed or currently in automatic operation.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK	: Normal termination
EZ_ERR_DATA_TYPE	: Invalid argument data type
EZNC_DATA_READ_ADDR	: Invalid system specification
EZNC_DATA_READ_READ	: Data is not readable

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Returns the sequence number of the program for which search has been completed or currently in automatic operation.

□ **Reference** **GetProgramNumber2(), GetBlockNumber(), GetSubProLevel()**

□ **Specification** System

2.7.4 IEZNCProgram2::GetBlockNumber

Read block number

□ Custom call procedure

```

HRESULT      GetBlockNumber(
                LONG IProgramType,           // (I) Program type
                LONG* pIBlockNo,           // (O) Block number
                LONG* pIRet                // (O) Error code
            )

```

□ Automation call procedure

```

Program_GetBlockNumber(
    IProgramType As LONG           // (I) Program type
    pIBlockNo As LONG*           // (O) Block number
) As LONG                         // (O) Error code

```

□ *IProgramType*: Sets the program type.

Argument	Value	Meaning
	EZNC_MAINPRG	Main program
	EZNC_SUBPRG	Subprogram

pIBlockNo: Returns the block number of the program for which search has been completed or currently in automatic operation.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Returns the block number of the program for which search has been completed or currently in automatic operation.

□ **Reference** **GetProgramNumber2(), GetSequenceNumber(), GetSubProLevel()**

□ **Specification** System

2.7.5 IEZNCProgram2::GetSubProLevel

Get subprogram call level

□ Custom call procedure

```

HRESULT      GetSubProLevel(
                LONG* pLevel,           // (O) Level
                LONG* pRet              // (O) Error code
            )

```

□ Automation call procedure

```

Program_GetSubProLevel(
    pLevel As LONG*           // (O) Level
) As LONG                    // (O) Error code

```

□ **Argument** *pLevel* : Returns the subprogram call level.
Value: 0 to 8

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the sub-program call level of the set system.

□ **Reference** **GetProgramNumber2(), GetSequenceNumber()**

□ **Specification** System

2.7.6 IEZNCProgram2::GetInformation

Get program information

□ Custom call procedure

```

HRESULT      GetInformation(
                LONG InfoType,           // (I) Information type
                LONG* pInfoData,        // (O) User machining program information
                LONG* pRet              // (O) Error code
            )

```

□ Automation call procedure

```

Program_GetInformation(
    InfoType As LONG           // (I) Information type
    pInfoData As LONG*        // (O) User machining program information
) As LONG                     // (O) Error code

```

□ *InfoType*: Sets the type of information to get.

Argument	Value	Meaning
	EZNC_PRG_MAXNUM	Maximum number of registrable programs
	EZNC_PRG_CURNUM	Number of programs currently registered
	EZNC_PRG_RESTNUM	Remaining number of registrable programs
	EZNC_PRG_CHARNUM	Number of registered characters
	EZNC_PRG_RESTCHARNUM	Remaining number of registrable characters (250 character units)

pInfoData: Returns the program information specified by *InfoType*.

If **EZNC_PRG_MAXNUM** set, *pInfoData*

means 1: 200 [programs]. The data range depends on the specifications of the NC control unit.

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ Gets program information.

□ Function

□ Reference

□ Specification

2.7.7 IEZNCProgram2:: GetCurrentBlockByByte

Get program information

□ Custom call procedure

```
HRESULT    GetCurrentBlockByByte(
            LONG* pSize,                // (O) Number of bytes
            LONG* pRet                  // (O) Error code
            )
```

□ Automation call procedure

```
Program_ GetCurrentBlockByByte(
    pSize As LONG*                // (O) Number of bytes
) As LONG                        // (O) Error code
```

□ **Argument** *pSize* : Returns the number of bytes from start of program of the set part system.
Value: From 0

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the number of bytes from the start of the program in the searched block or the block currently stopped with single block stop.
This is valid only for the M700/M800 series.
This function is not supported with C70.

□ **Reference**

□ **Specifica-
tion**

2.8.1 IEZNCtime::GetClockData **Get date and time**

□ Custom call procedure

```
HRESULT      GetClockData(
                LONG* pDate,           // (O) Year, month, day
                LONG* pTime,          // (O) Hour, minute, second
                LONG* pRet            // (O) Error code
            )
```

□ Automation call procedure

```
Time_GetClockData(
    pDate As LONG*           // (O) Year, month, day
    pTime As LONG*          // (O) Hour, minute, second
) As LONG                   // (O) Error code
```

□ **Argument** *pDate*: Returns the date (year, month, day).
Output example: 1998/12/05 = 19981205

pTime: Returns the time (hour, minute, second) of the clock in the NC.
Value: 0 to 235959
Output example: 23:59:59 = 235959

pRet: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the date and time from the clock in the NC.

□ **Reference** **SetClockData()**

□ **Specification**

2.8.2 IEZNCtime::SetClockData

Set date and time

□ Custom call procedure

```

HRESULT      SetClockData(
                LONG IDate,           // (I) Year, month, day
                LONG ITime,          // (I) Hour, minute, second
                LONG* pIRet           // (O) Error code
            )

```

□ Automation call procedure

```

Time_SetClockData(
    IDate As LONG           // (I) Year, month, day
    ITime As LONG          // (I) Hour, minute, second
) As LONG                  // (O) Error code

```

□ **Argument** *IDate*: Sets the date (year, month, day).
Setting example: 1998/12/05 = 19981205

ITime: Sets the time (hour, minute, second) for the clock in the NC.
Value: 0 to 235959
Setting example: 23:59:59 = 235959

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets the date and time for the clock in the NC.

□ **Reference** **GetClockData()**

□ **Specifica-
tion**

2.8.3 IEZNCtime::GetAliveTime

Get power-on time

□ Custom call procedure

```

HRESULT      GetAliveTime(
                LONG* pTime,           // (O) Power-on time
                LONG* pRet            // (O) Error code
            )

```

□ Automation call procedure

```

Time_GetAliveTime(
    pTime As LONG*           // (O) Power-on time
) As LONG                  // (O) Error code

```

□ **Argument** *pTime*: Gets total power-on time (hour, minute, second) from the controller power ON to OFF.
 Value: 0 to 99995959
 Output example: 9999:59:59 = 99995959

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets total power-on time (hour, minute, second) from the controller power ON to OFF.
 Stops integration when the value reaches the maximum value, and retains the maximum value.

□ **Reference** **SetAliveTime()**

□ **Specifica-
tion**

2.8.4 IEZNCtime::SetAliveTime

Set power-on time

□ Custom call procedure

```

HRESULT SetAliveTime(
    LONG lTime,           // (I) Power-on time
    LONG* plRet           // (O) Error code
)

```

□ Automation call procedure

```

Time_SetAliveTime(
    lTime As LONG        // (I) Power-on time
) As LONG               // (O) Error code

```

□ **Argument** *lTime*: Sets total power-on time (hour, minute, second) from the controller power ON to OFF.
 Value: 0 to 99995959
 Setting example: 9999:59:59 = 99995959

plRet: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZNC_DATA_WRITE_WRITE: Data is not writable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Forcibly sets total power-on time (hour, minute, second) from the controller power ON to OFF.

□ **Reference** **GetAliveTime()**

□ **Specification**

2.8.5 IEZNCtime::GetRunTime

Get automatic operation time

□ Custom call procedure

```

HRESULT      GetRunTime(
                  LONG* plTime,           // (O) Automatic operation time
                  LONG* plRet           // (O) Error code
                )

```

□ Automation call procedure

```

Time_GetRunTime(
  plTime As LONG*           // (O) Automatic operation time
) As LONG                   // (O) Error code

```

□ **Argument** *plTime*: Returns total processing time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by M02/M30 or the reset operation.
 Value: 0 to 99995959
 Output example: 9999:59:59 = 99995959

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets total processing time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by M02/M30 or the reset operation.
 Stops integration when the value reaches the maximum value, and retains the maximum value.

□ **Reference** **SetRunTime()**

□ **Specifica-
tion**

2.8.6 IEZNCtime::SetRunTime

Set automatic operation time

□ Custom call procedure

```
HRESULT      SetRunTime(
                LONG ITime,                // (I) Automatic operation time
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
Time_SetRunTime(
    ITime As LONG                // (I) Automatic operation time
) As LONG                        // (O) Error code
```

□ **Argument** *ITime*: Sets total processing time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by M02/M30 or the reset operation.
Value: 0 to 99995959
Setting example: 9999:59:59 = 99995959

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Forcibly sets total processing time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by M02/M30 or the reset operation.

□ Reference **GetRunTime()**

Reference

□ Specification

2.8.7 IEZNCtime::GetStartTime

Get automatic start time

□ Custom call procedure

```

HRESULT      GetStartTime(
                LONG* pTime,           // (O) Automatic start time
                LONG* pRet            // (O) Error code
            )

```

□ Automation call procedure

```

Time_GetStartTime(
    pTime As LONG*           // (O) Automatic start time
) As LONG                   // (O) Error code

```

□ **Argument** *pTime*: Returns total automatic operation time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by feed hold, block stop, or reset.

Value: 0 to 99995959

Output example: 9999:59:59 = 99995959

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets total automatic operation time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by feed hold, block stop, or reset.

□ **Reference** **SetStartTime()**□ **Specifica-
tion**

2.8.8 IEZNCTime::SetStartTime

Set automatic start time

□ Custom call procedure

```

HRESULT      SetStartTime(
                LONG ITime,                // (I) Automatic start time
                LONG* pIRet                // (O) Error code
            )

```

□ Automation call procedure

```

Time_SetStartTime(
    ITime As LONG                // (I) Automatic start time
) As LONG                        // (O) Error code

```

□ **Argument** *ITime*: Sets total automatic operation time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by feed hold, block stop, or reset.
Value: 0 to 99995959
Setting example: 9999:59:59 = 99995959

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets total automatic operation time (hour, minute, second) from the automatic operation start using memory (tape) or in MDI mode to the termination by feed hold, block stop, or reset.

□ **Reference** **GetStartTime()**

□ **Specifica-
tion**

2.8.9 IEZNCtime::GetEstimateTime

Get external integration time

□ Custom call procedure

```

HRESULT      GetEstimateTime(
                LONG IKind,                // (I) External integration time type
                LONG* pITime,              // (O) External integration time
                LONG* pIRet                 // (O) Error code
            )

```

□ Automation call procedure

```

Time_GetEstimateTime(
    IKind As LONG                // (I) External integration time type
    pITime As LONG*              // (O) External integration time
) As LONG                        // (O) Error code

```

□ *IKind*: Sets the external integration time type.

Argument	Value	Meaning
	0	External integration time 1 (programmable controller device C70: Y314 M700/M800 series: Y704): When counting with the device turned ON
	1	External integration time 2 (programmable controller device C70: Y315 M700/M800 series: Y705): When counting with the device turned ON

pITime: Returns the time (hour, minute, second) controlled by the programmable controller. Stops integration when the integration time display reaches the maximum value, and retains the display with the maximum value.

Value: 0 to 99995959

Output example: 9999:59:59 = 99995959

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Returns the time (hour, minute, second) controlled by the programmable controller. Starts counting when the user programmable controller device is turned ON. Refer to the programmable controller interface manual for each model because the device number differs depending on models.

□ **SetEstimateTime()**

Reference

□ Specification

2.8.10 IEZNCTime::SetEstimateTime

Set external integration time

□ Custom call procedure

```

HRESULT SetEstimateTime(
    LONG IKind,           // (I) External integration time type
    LONG ITime,          // (I) External integration time
    LONG* pIRet           // (O) Error code
)

```

□ Automation call procedure

```

Time_SetEstimateTime(
    IKind As LONG         // (I) External integration time type
    ITime As LONG         // (I) External integration time
) As LONG                // (O) Error code

```

□ *IKind*: Sets the external integration time type.

Argument	Value	Meaning
	0	External integration time 1 (programmable controller device C70: Y314 M700/M800 series: Y704): When counting with the device turned ON
	1	External integration time 2 (programmable controller device C70: Y315 M700/M800 series: Y705): When counting with the device turned ON

ITime: Sets the time (hour, minute, second) controlled by the PLC.

Stops integration when the integration time display reaches the maximum value, and retains the display with the maximum value.

Value: 0 to 99995959

Setting example: 9999:59:59 = 99995959

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets the time (hour, minute, second) controlled by the programmable controller. Starts counting when the user programmable controller device is turned ON. Refer to the programmable controller interface manual for each model because the device number differs depending on models.

□ **Reference** **GetEstimateTime()**

□ **Specification**

2.9.1 IEZNCAxisMonitor::GetServoMonitor **Get servo monitor**

□ Custom call procedure

```

HRESULT GetServoMonitor(
    LONG IAxisNo,           // (I) Axis No.
    LONG IIndex,           // (I) Monitor data
    LONG* pIData,         // (O) Monitor data
    LPOLESTR* IppwszBuffer, // (O) Monitor data character string
    LONG* pIRet           // (O) Error code
)
    
```

□ Automation call procedure

```

Monitor_GetServoMonitor(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Monitor data
    pIData As LONG*         // (O) Monitor data
    IppwszBuffer As STRING* // (O) Monitor data character string
) As LONG                   // (O) Error code
    
```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

IIndex: Sets the parameter number for the set axis No. in the set system.

pIData: Returns the axis status.

IppwszBuffer: Outputs data (return value) as a **UNICODE** character string when any of 100 to 104 is set for *IIndex*.

For the **M700/M800 series**, outputs data (return value) as a **UNICODE** character string when any of 11 to 15, 18 to 20, or 100 to 104 is set for *IIndex*.

pIRet: Returns an error code. (Upon automation, the return value is used.)

- S_OK**: Normal termination
- EZNC_DATA_READ_READ**: Data is not readable
- EZNC_DATA_READ_DATASIZE**: Application does not fit into prepared buffer
- EZNC_DATA_READ_DATATYPE**: Invalid data type (parameter number)
- EZNC_DATA_READ_ADDR**: Invalid part system, axis No. setting
- EZNC_DATA_READ_AXIS**: Invalid axis specification
- EZ_ERR_DATA_TYPE**: Invalid argument data type

<i>IIndex</i>	Description	Data range	Remarks
0	GAIN. Position loop gain status display.	Unit: 1/s	
1	DROOP. (tracking delay)	Unit: i	
2	SPEED. Actual motor speed.	From 0 [rpm]	
3	CURRENT. Load current. Motor current (displayed by converting to continuous current when stalled).	From 0 [%]	
4	MAXCUR1. Maximum current I.	Unit: %	
5	MAXCUR2. Maximum current II.	Unit: %	
6	OVER LOAD. Overload.	Unit: %	
7	REGEN LOAD. Regenerative load.	Unit: %	
10	CYC CNT. Cycle counter.	Unit: Pulse	

<input type="checkbox"/> Argument	<i>//index</i>	Description	Data range	Remarks
	11	GRIDSP. Grid interval.	Unit: Command unit*	
	12	GRID. Grid amount.	Unit: Command unit*	
	13	MACPOS. Machine position.	Unit: Command unit*	
	14	MOT POS. Motor end FB.	Unit: Command unit*	
	15	SCA POS. Machine end FB.	Unit: Command unit*	
	16	FB ERROR. FB error.	Unit: i	
	17	DFB COMP. DFB compensation amount.		
	18	Remain command	Unit: Command unit*	
	19	Currrnt posn.	Unit: Command unit*	
	20	Manual interrupt amount.	Unit: Command unit*	
	100	AMP DISP. Amplifier display. 7-segment LED display on a drive unite.	Outputs a 3-digit character string from "00\0" to "FF\0".	
	101	Alarm 1.	Outputs a 3-digit character string.	
	102	Alarm 2.	Same as above	
	103	Alarm 3.	Same as above	
	104	Alarm 4.	Same as above	

* The M700/M800 series allows acquisition of value (actual value) converted according to the command unit as a character string.

<input type="checkbox"/> Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

- **Function** Gets servo monitor information of the set axis No. in the set part system.
When the data range in the *Index* table is [Unit: Command unit], the value got needs to be converted according to the command unit sets for the Mitsubishi CNC. For the setting unit, refer to the Mitsubishi CNC specifications.

< For Linear axis >

	Metric system	Conversion for 1 of LONG type
For 10- μ m specifications	-999,999.99 to 999,999.99	1 = 1/200 (mm)
For 1- μ m specifications	-99,999.999 to 99,999.999	1 = 1/2000 (mm)
For 0.1- μ m specifications	-9,999.9999 to 9,999.9999	1 = 1/20000 (mm)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (mm)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (mm)

	Inch system	Conversion for 1 of LONG type
For 10- μ m specifications	-99,999.999 to 99,999.999	1 = 1/200 (inch)
For 1- μ m specifications	-9,999.9999 to 9,999.9999	1 = 1/2000 (inch)
For 0.1- μ m specifications	-999.99999 to 999.99999	1 = 1/20000 (inch)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (inch)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (inch)

< For Rotary axis >

	Metric system	Conversion for 1 of LONG type
For 10- μ m specifications	-999999.99 to 999999.99	1 = 1/200 (mm)
For 1- μ m specifications	-99,999.999 to 99,999.999	1 = 1/2000 (mm)
For 0.1- μ m specifications	-9999.9999 to 9999.9999	1 = 1/20000 (mm)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (mm)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (mm)

	Inch system	Conversion for 1 of LONG type
For 10- μ m specifications	-999,999.99 to 999,999.99	1 = 1/200 (inch)
For 1- μ m specifications	-99,999.999 to 99,999.999	1 = 1/2000 (inch)
For 0.1- μ m specifications	-9999.9999 to 9999.9999	1 = 1/20000 (inch)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (inch)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (inch)

Conversion example) For the linear axis with the 1- μ m specifications in the Metric system, when the LONG value got is 710001,

$$710001 \div 2000 = 355.0005. \text{ However, } 355.0005 \text{ is rounded to minus infinity.}$$

Therefore the result is 355.000.

Data in units of 0.5 μ m (1/2000 mm) is rounded to minus infinity when displayed.

This means that +0.5 μ m is displayed as 0 and -0.5 μ m is displayed as -1 μ m.

As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.

- **Reference** **GetServoVersion(), GetServoDiagnosis()**

- **Specification** System, PLC axis, Axis number

2.9.2 IEZNCAxisMonitor::GetServoVersion

Get servo axis unit information

□ Custom call procedure

```

HRESULT      GetServoVersion(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,         // (I) Servo information
                LPOLESTR* IppwszBuffer, // (O) Servo information
                LONG* pIRet          // (O) Error code
                )

```

□ Automation call procedure

```

Monitor_GetServoVersion(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Servo information
    IppwszBuffer As STRING* // (O) Servo information
    ) As LONG                 // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IIndex: Set the servo information. Refer to the table below.

IppwszBuffer: Sets servo information as a **UNICODE** character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_AXIS: Invalid axis No. setting

<i>IIndex</i>	Description	Data range
0	Unit type	Up to 17 alphanumeric characters.
1	Unit serial No.	Up to 9 alphanumeric characters.
2	Software version	Up to 17 alphanumeric characters.
3	Control method.	Up to 7 alphanumeric characters.
4	Motor end detector	Up to 9 alphanumeric characters.
5	Machine end detector	Up to 9 alphanumeric characters.
6	Motor	Up to 9 alphanumeric characters.

□ **Return value** Value Meaning

S_OK Normal termination

S_FALSE Communication failure

□ **Function** Gets servo version information.
As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.

□ **Reference** **GetServoMonitor()**, **GetServoDiagnosis()**

□ **Specification** [System], [PLC axis], [Axis number]

2.9.3 IEZNCAxisMonitor::GetServoDiagnosis

Get servo diagnostics information

□ Custom call procedure

```

HRESULT      GetServoDiagnosis(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,         // (I) Diagnostics information
                LONG* pIData,        // (O) Diagnostics information value
                LPOLESTR* IppwszBuffer, // (O) Diagnostics information character string
                LONG* pIRet         // (O) Error code
                )

```

□ Automation call procedure

```

Monitor_GetServoDiagnosis(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Diagnostics information
    pIData As LONG*         // (O) Diagnostics information value
    IppwszBuffer As STRING* // (O) Diagnostics information character string
    ) As LONG                 // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ Argument

IIndex: Sets servo diagnostics information. Refer to the table below.

pIData: Returns the servo diagnostics information value.

IppwszBuffer: Gets diagnostics information as a **UNICODE** character string. Outputs a character string when *IIndex* is 21 to 30.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid system, spindle specification

EZNC_DATA_READ_AXIS: Invalid axis specification

<i>IIndex</i>	Description	Data range
0	Work time	
1	Alarm history 1 (Alarm No).	Previous servo alarm number
2	" 2 (Alarm No).	Same as above
3	" 3 (Alarm No).	Same as above
4	" 4 (Alarm No).	Same as above
5	" 5 (Alarm No).	Same as above
6	" 6 (Alarm No).	Same as above
7	" 7 (Alarm No).	Same as above
8	" 8 (Alarm No).	Same as above
11	Alarm history 1 (time).	Previous servo alarm occurrence time
12	" 2 (time).	Same as above
13	" 3 (time).	Same as above
14	" 4 (time).	Same as above
15	" 5 (time).	Same as above
16	" 6 (time).	Same as above
17	" 7 (time).	Same as above
18	" 8 (time).	Same as above

□ Argument	<i>IIndex</i>	Description	Data range
	21	MNT (1).	Up to 3 alphanumeric characters
	22	MNT (2).	Same as above
	23	MNT (3).	Same as above
	24	MNT (4).	Same as above
	30	SYS.	Up to 2 alphanumeric characters

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets servo diagnostics information. As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with CoTaskMemFree() .	
□ Reference	GetServoMonitor(), GetServoVersion()	
□ Specification	[System], [PLC axis], [Axis number]	

2.9.4 IEZNCAxisMonitor::GetPowerVersion

Get power supply version information

□ Custom call procedure

```

HRESULT      GetPowerVersion(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,         // (I) Version information
                LPOLESTR* IppwszBuffer, // (O)Version information character string
                LONG* pIRet         // (O) Error code
                )

```

□ Automation call procedure

```

Monitor_GetPowerVersion(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Version information
    IppwszBuffer As STRING* // (O) Version information
    ) As LONG                 // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IIndex: Sets version information. Refer to the table below.

IppwszBuffer: Gets version information as a **UNICODE** character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid system, spindle specification

<i>IIndex</i>	Description	Data range
0	Unit type	Up to 17 alphanumeric characters.
1	Unit serial No.	Up to 9 alphanumeric characters.
2	Software version	Up to 17 alphanumeric characters.
3	Connected drive.	1 alphanumeric character.

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets power supply version information.
As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.

□ **Reference** **GetPowerDiagnosis()**

□ **Specification** Axis number

2.9.5 IEZNCAxisMonitor::GetPowerDiagnosis

Get power supply diagnostics information

□ Custom call procedure

```

HRESULT      GetPowerDiagnosis(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Diagnostics information
                LONG* pIData,          // (O) Diagnostics information value
                LPOLESTR* lppwszBuffer, // (O) Diagnostics information character string
                LONG* pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

Monitor_GetPowerDiagnosis(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Diagnostics information
    pIData As LONG*          // (O) Diagnostics information value
    lppwszBuffer As STRING*  // (O) Diagnostics information character string
) As LONG                   // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

IIndex: Sets diagnostics information. Refer to the table below.

pIData: Returns the diagnostics information value.

lppwszBuffer: Gets diagnostics information as a **UNICODE** character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

<i>IIndex</i>	Description	Data range
0	Work time	
1	Alarm history 1 (Alarm No).	Previous servo alarm number
2	" 2 (Alarm No).	Same as above
3	" 3 (Alarm No).	Same as above
4	" 4 (Alarm No).	Same as above
5	" 5 (Alarm No).	Same as above
6	" 6 (Alarm No).	Same as above
7	" 7 (Alarm No).	Same as above
8	" 8 (Alarm No).	Same as above
11	Alarm history 1 (time).	Previous servo alarm occurrence time
12	" 2 (time).	Same as above
13	" 3 (time).	Same as above
14	" 4 (time).	Same as above
15	" 5 (time).	Same as above
16	" 6 (time).	Same as above
17	" 7 (time).	Same as above
18	" 8 (time).	Same as above
21	MNT (1).	Up to 3 alphanumeric characters
22	MNT (2).	Same as above
23	MNT (3).	Same as above
24	MNT (4).	Same as above
30	SYS	Up to 2 alphanumeric characters

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets power supply diagnostics information. As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with CoTaskMemFree() .	
□ Reference	GetPowerVersion()	
□ Specification	<input type="text" value="Axis number"/>	

2.9.6 IEZNCAxisMonitor::GetSpindleMonitor

Monitor spindle

□ Custom call procedure

```

HRESULT      GetSpindleMonitor(
                LONG lIndex,                // (I) Monitor data
                LONG lSpindle,              // (I) Spindle number
                LONG* plData,               // (O) Monitor data value
                LPOLESTR* lppwszBuffer,    // (O) Monitor data character string
                LONG* plRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Monitor_GetSpindleMonitor(
    lIndex As LONG                // (I) Monitor data
    lSpindle As LONG              // (I) Spindle number
    plData As LONG*              // (O) Monitor data value
    lppwszBuffer As STRING*      // (O) Monitor data character string
) As LONG                        // (O) Error code

```

□ *lIndex*: Sets the parameter number for the set spindle.

□ Argument

lSpindle: Set the spindle number.

plData: Returns the spindle status.

lppwszBuffer: Gets spindle information as a **UNICODE** character string.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid system, spindle specification

EZ_ERR_DATA_TYPE: Invalid argument data type

<i>lIndex</i>	Description	Data range	Remarks
0	Gain. Spindle position loop gain.	Unit: 1/s	
1	Droop. Position deviation amount.	Unit: l	
2	Spindle (SR, SF) rotation speed. Actual spindle motor speed. Including override.	From 0 [rpm]	
3	Load. Spindle motor load.	From 0 [%]	
4	LED display. 7-segment LED display on a driver.	Outputs a 3-digit character string from "00\0" to "FF\0".	
5	Alarm 1.	Up to 3 alphanumeric characters.	
6	Alarm 2.	Same as above	
7	Alarm 3.	Same as above	
8	Alarm 4.	Same as above	M700/M800 series only
10	Cycle counter.		
11	Control input 1.		
12	" 2.		
13	" 3.		
14	" 4.		
15	Control output 1.		
16	" 2.		
17	" 3.		
18	" 4.		

□ **Return value** Value Meaning

S_OK Normal termination

S_FALSE Communication failure

□ Gets the set spindle status.

Function

□ **GetSpindleVersion(), GetSpindleDiagnosis()**

Reference

□
**Specifica-
tion**

2.9.7 IEZNCAxisMonitor::GetSpindleVersion

Get spindle unit version information

□ Custom call procedure

```

HRESULT      GetSpindleVersion(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,         // (I) Version information
                LPOLESTR* IppwszBuffer, // (O) Version information character string
                LONG* pIRet           // (O) Error code
                )

```

□ Automation call procedure

```

Monitor_GetSpindleVersion(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Version information
    IppwszBuffer As STRING* // (O) Version information
    ) As LONG                 // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IIndex: Sets version information. Refer to the table below.

IppwszBuffer: Gets version information as a **UNICODE** character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, spindle setting

EZNC_DATA_READ_AXIS: Invalid axis No. setting

<i>IIndex</i>	Description	Data range
0	Unit type	Up to 17 alphanumeric characters.
1	Unit serial No.	Up to 9 alphanumeric characters.
2	Software version	Up to 17 alphanumeric characters.

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets spindle version information.

As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.

□ **Reference** **GetSpindleMonitor(), GetSpindleDiagnosis()**

□ **Specification** Axis number

2.9.8 IEZNCAxisMonitor::GetSpindleDiagnosis

Get spindle diagnostics information

□ Custom call procedure

```

HRESULT      GetSpindleDiagnosis(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Diagnostics information
                LONG* pIData,          // (O) Diagnostics information value
                LPOLESTR* lppwszBuffer, // (O) Diagnostics information character string
                LONG* pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

Monitor_GetSpindleDiagnosis(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Diagnostics information
    pIData As LONG*          // (O) Diagnostics information value
    lppwszBuffer As STRING*  // (O) Diagnostics information character string
) As LONG                   // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

IIndex: Sets diagnostics information.

pIData: Returns the diagnostics information value.

lppwszBuffer: Gets diagnostics information as a **UNICODE** character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axins No. setting

EZNC_DATA_READ_AXIS: Invalid axis No. setting

EZ_ERR_DATA_TYPE: Invalid argument data type

<i>IIndex</i>	Description	Data range
0	Work time	
1	Alarm history 1 (Alarm No).	Previous spindle alarm number
2	" 2 (Alarm No).	Same as above
3	" 3 (Alarm No).	Same as above
4	" 4 (Alarm No).	Same as above
5	" 5 (Alarm No).	Same as above
6	" 6 (Alarm No).	Same as above
7	" 7 (Alarm No).	Same as above
8	" 8 (Alarm No).	Same as above
11	Alarm history 1 (time).	Previous spindle alarm time
12	" 2 (time).	Same as above
13	" 3 (time).	Same as above
14	" 4 (time).	Same as above
15	" 5 (time).	Same as above
16	" 6 (time).	Same as above
17	" 7 (time).	Same as above
18	" 8 (time).	Same as above
21	MNT (1).	Up to 3 alphanumeric characters.
22	MNT (2).	Same as above
23	MNT (3).	Same as above
24	MNT (4).	Same as above
30	SYS.	Up to 2 alphanumeric characters.

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets power supply diagnostics information. As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with CoTaskMemFree() .	
□ Reference	GetSpindleMonitor(), GetSpindleVersion()	
□ Specification	Axis number	

2.9.9 IEZNCAxisMonitor::GetAbsPositionMonitor

Get absolute position
monitor information

□ Custom call procedure

```

HRESULT      GetAbsPositionMonitor(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Axis monitor information
                LONG* pIData,          // (O) Monitor information value
                LPOLESTR* lppwszBuffer, // (O) Absolute position monitor information
                                                character string
                LONG* pIRet            // (O) Error code
            )

```

□ Automation call procedure

```

Monitor_GetAbsPositionMonitor(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Monitor information
    pIData As LONG*         // (O) Monitor information value
    lppwszBuffer As STRING*  // (O) Absolute position monitor information
                                                character string
) As LONG                   // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IIndex: Sets monitor information.

pIData: Returns monitor information value.

lppwszBuffer: Gets information about the absolute position monitor as a **UNICODE** character string. Outputs a character string when *IIndex* is 0.
For the M700/M800 series, outputs the result as a **UNICODE** character string when *IIndex* is 0 to 3.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_AXIS: Invalid axis No. setting

EZ_ERR_DATA_TYPE: Invalid argument data type

<i>IIndex</i>	Description	Data range	Syst em	Axis	PLC axis
0	ABS SYS. Detection system.	0: Semi closed encoder (ES) 1: Semi closed high-speed serial encoder (ESS) 2: Incremental (INC)	○	○	○
1	POF POS. Power off position.	Unit: Command unit*	○	○	○
2	PON POS. Power on position.	Unit: Command unit*	○	○	○
3	MAC POS. Current position.	Unit: Command unit*	○	○	○
4	R0.		○	○	○
5	P0.		○	○	○
6	E0.		○	○	○
7	Rn.		○	○	○
8	Pn.		○	○	○
9	En.		○	○	○
10	ABSn.		○	○	○
11	ABS0.		○	○	○

* The M700/M800 series allows acquisition of value (actual value) converted according to the command unit as a character string. For conversion according to the command unit, refer to □ Function in IEZNCAxisMonitor::GetServoMonitor().

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets information about the absolute position monitor.
ABS0 is valid only for the M700/M800 series.
As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.

□ **Reference**

□ **Specification** [System], [PLC axis], [Axis number]

2.9.10 IEZNCAxisMonitor::GetAuxAxisMonitor

Get auxiliary axis monitor information

□ Custom call procedure

```

HRESULT      GetAuxAxisMonitor (
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,         // (I) Auxiliary axis information type
                LONG* pIData,        // (O) Auxiliary axis information value
                LPOLESTR* IppwszBuffer, // (O) Auxiliary axis monitor information
                                                character string
                LONG* pIRet         // (O) Error code
                )

```

□ Automation call procedure

```

Monitor_GetAuxAxisMonitor (
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Auxiliary axis information type
    pIData As LONG*         // (O) Auxiliary axis information value
    IppwszBuffer As STRING* // (O) Auxiliary axis monitor information string
    ) As LONG                 // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IIndex: Sets the auxiliary axis information type. Refer to the table below.

pIData: Returns the auxiliary axis information.

IppwszBuffer: Gets monitor information as a **UNICODE** string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZ_ERR_NOT_SUPPORT: Not supported

<i>IIndex</i>	Description	Data range
0	Droop.	-999 to 999
1	Rotation speed.	0 to 9999 [rpm]
2	Load current.	-999 to 999 [%]
3	Maximum current 1.	-999 to 999 [%]
4	Maximum current 2.	-999 to 999 [%]
5	Motor load	-999 to 999 [%]
6	Regen load.	-999 to 999 [%]
7	Current station No.	1 to 360
8	Current position.	Auxiliary axis information: Parameter value: Unit: Command unit Auxiliary axis monitor information character string: -99,999.999 to 99,999.999
9	Inst station No.	1 to 360

Argument	Index	Description	Data range
	10	Inst posn:	Auxiliary axis information: Parameter value: Unit: Command unit Auxiliary axis monitor information character string: -99,999.999 to 99,999.999
	11	Position loop gain 1.	0 to 999
	12	Speed loop gain 1.	0 to 999
	13	Position loop gain 2.	0 to 999
	14	Speed loop gain 2.	0 to 999
	15	Speed integral compensation.	0 to 999
	16	Load inertia.	0 to 999.9

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets information about the auxiliary axis monitor.
When the data range in the *Index* table is [Unit: Command unit], the value got needs to be converted according to the command unit set for the Mitsubishi CNC. For the set unit, refer to the Mitsubishi CNC specifications.
<For Linear axis>

	Metric system	Conversion for 1 of LONG type
For 10-μm specifications	-999,999.99 to 999,999.99	1 = 1/200 (mm)
For 1-μm specifications	-99,999.999 to 99,999.999	1 = 1/2000 (mm)
For 0.1-μm specifications	-9,999.9999 to 9,999.9999	1 = 1/20000 (mm)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (mm)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (mm)

	Inch system	Conversion for 1 of LONG type
For 10-μm specifications	-99,999.999 to 99,999.999	1 = 1/200 (inch)
For 1-μm specifications	-9,999.9999 to 9,999.9999	1 = 1/2000 (inch)
For 0.1-μm specifications	-999.99999 to 999.99999	1 = 1/20000 (inch)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (inch)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (inch)

<For Rotary axis>

	Metric system	Conversion for 1 of LONG type
For 10-μm specifications	-999999.99 to 999999.99	1 = 1/200 (mm)
For 1-μm specifications	-99,999.999 to 99,999.999	1 = 1/2000 (mm)
For 0.1-μm specifications	-9999.9999 to 9999.9999	1 = 1/20000 (mm)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (mm)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (mm)

	Inch system	Conversion for 1 of LONG type
For 10-μm specifications	-999,999.99 to 999,999.99	1 = 1/200 (inch)
For 1-μm specifications	-99,999.999 to 99,999.999	1 = 1/2000 (inch)
For 0.1-μm specifications	-9999.9999 to 9999.9999	1 = 1/20000 (inch)
For 10-nm specifications	-999.99999 to 999.99999	1 = 1/200000 (inch)
For 1-nm specifications	-99.999999 to 99.999999	1 = 1/2000000 (inch)

Conversion example) For the linear axis with the 1-μm specifications in the Metric system, when the LONG value got is 710001,
 $710001 \div 2000 = 355.0005$.
However, 355.0005 is rounded to minus infinity. Therefore the result is 355.000.
Data in units of 0.5 μm (1/2000 mm) is rounded to minus infinity when displayed.
This means that +0.5 μm is displayed as 0 and -0.5 μm is displayed as -1 μm.

As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.

This function is not supported with C70.

Reference
□ Specification Axis number

2.9.11 IEZNCAxisMonitor::GetAuxAxisDiagnosis

Get auxiliary axis
diagnostics information

□ Custom call procedure

```

HRESULT GetAuxAxisDiagnosis (
    LONG IAxisNo,           // (I) Axis No.
    LONG IIndex,         // (I) Auxiliary axis diagnostics information type
    LPOLESTR* IppwszBuffer, // (O) Auxiliary axis diagnostics information
                                character string
    LONG* pIRet         // (O) Error code
)

```

□ Automation call procedure

```

Monitor_GetAuxAxisDiagnosis (
    IAxisNo As LONG       // (I) Axis No.
    IIndex As LONG       // (I) Auxiliary axis diagnostics information type
    IppwszBuffer As STRING* // (O) Auxiliary axis diagnostics information
                                character string
) As LONG                // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IIndex: Sets the auxiliary axis diagnostics information type. Refer to the table below.

IppwszBuffer: Gets the auxiliary axis diagnostics information as a **UNICODE** character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZ_ERR_NOT_SUPPORT: Not supported

<i>IIndex</i>	Description	Data range
0	Alarm history (1).	"Alarm information by type" with 9 alphanumeric characters
1	Alarm history (2).	"Alarm information by type" with 9 alphanumeric characters
2	Alarm history (3).	"Alarm information by type" with 9 alphanumeric characters
3	Alarm history (4).	"Alarm information by type" with 9 alphanumeric characters
4	Alarm history (5).	"Alarm information by type" with 9 alphanumeric characters
5	Alarm history (6).	"Alarm information by type" with 9 alphanumeric characters

□ **Return value** Value Meaning

S_OK Normal termination

S_FALSE Communication failure

□ **Function** Gets the auxiliary axis diagnostics information.
As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.
This function is not supported with C70.

□ **Reference**

□ **Specification** Axis number

2.9.12 IEZNCAxisMonitor::GetAuxAxisVersion

Get auxiliary axis version information

□ Custom call procedure

```

HRESULT GetAuxAxisVersion (
    LONG IAxisNo,           // (I) Axis No.
    LONG IIndex,           // (I) Auxiliary axis version information type
    LPOLESTR* IppwszBuffer, // (O) Auxiliary axis version information
                                character string
    LONG* pIRet           // (O) Error code
)

```

□ Automation call procedure

```

Monitor_GetAuxAxisVersion (
    IAxisNo As LONG         // (I) Axis No.
    IIndex As LONG         // (I) Auxiliary axis version information type
    IppwszBuffer As STRING* // (O) Auxiliary axis version information
                                character string
) As LONG                 // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

IIndex: Sets the auxiliary axis version information type.

IppwszBuffer: Sets the auxiliary axis version information as a **UNICODE** character string.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid system, spindle specification

EZ_ERR_NOT_SUPPORT: Not supported

<i>IIndex</i>	Description	Data range
0	Unit type	9 alphanumeric characters
1	Unit serial No.	16 alphanumeric characters
2	Motor	9 alphanumeric characters

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

S_OK Normal termination

S_FALSE Communication failure

□ **Function** Gets auxiliary axis version information.
 As the string area memory is allocated in this product, the client using VC++ needs to release the string area memory explicitly with **CoTaskMemFree()**.
 This function is not supported with C70.

□ **Reference**

□ **Specification** Axis number

2.9.13 IEZNCAxisMonitor::GetDwellTime

Get remaining dwell time

□ Custom call procedure

```

HRESULT      GetDwellTime(
                DOUBLE* pdTime,           // (O) Remaining dwell time
                LONG* plRet              // (O) Error code
            )

```

□ Automation call procedure

```

Monitor_GetDwellTime(
    pdTime As DOUBLE*           // (O) Remaining dwell time
) As LONG                      // (O) Error code

```

□ **Argument** *pdTime*: Returns the remaining dwell (G04) time.
 Unit: Second
 Value: 0.000 to 99,999.999 (s)

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Returns the remaining dwell (G04) time. Unit: Second, output up to second, 1/1000 (second).

□ **Reference**

□ **Specifica-
tion** System

2.9.14 IEZNCAxisMonitor:: GetPowerConsumption

Get current power
consumption

□ Custom call procedure

```

HRESULT      GetPowerConsumption (
                LONG   IAxisNo,           // (I) Axis No.
                DOUBLE** ppdPower,       // (O) Power consumption
                LONG*   pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

GetPowerConsumption (
    IAxisNo As LONG           // (I) Axis No.
    pvPower As VARIANT*      // (I) Power consumption
) As LONG                   // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

ppdPower : Returns the current total power consumption as an array. The data array is secured on the EZSocket side, so explicitly release it on the client side using CoTaskMemFree(). Refer to the index table for the got power consumption.

Index table

Array Index	Type of power consumption
0	Present consumption of entire drive system
1	Present power consumption of servo axis in drive system (fluctuating part)
2	Present power consumption of spindle in drive system (fluctuating part)

Automation argument:

IAxisNo: See the explanation of *IAxisNo*.

pvPower : Returns the power consumption array as a VARIANT.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets the present consumption of entire drive system as an array.
This function is not supported with the C70 or M700 series.

□ **Reference**

□ **Specifica-
tion**

2.9.15 IEZNCAxisMonitor:: GetIntegralPower

Get integral power

□ Custom call procedure

```

HRESULT      GetPowerConsumption (
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Parameter number
                DOUBLE** ppdPower,     // (O) Power consumption
                LONG* plRet            // (O) Error code
                )

```

□ Automation call procedure

```

GetPowerConsumption (
  IAxisNo As LONG           // (I) Axis NO.
  IIndex As LONG,          // (I) Parameter number
  pvPower As VARIANT*     // (I) Power consumption
  ) As LONG                 // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ **Argument**

IIndex : Sets the number of the integral power to be got.

ppdPower : Returns the total power consumption as an array. The data array is secured on the EZSocket side, so explicitly release it on the client side using CoTaskMemFree(). Refer to the index table for the got power consumption.

Index table

Array Index	Type of power consumption
0	Accumulated consumption of entire drive system
1	Drive system's fixed consumption correction
2	Accumulated consumption of servo axis in drive system (fluctuating part)
3	Accumulated regeneration of servo axis in drive system (fluctuating part)
4	Accumulated consumption of spindle in drive system (fluctuating part)
5	Accumulated regeneration of spindle in drive system (fluctuating part)

Automation argument:

IAxisNo: See the explanation of *IAxisNo*.

IIndex : See the explanation of *IIndex*.

pvPower : Returns the power consumption array as a VARIANT.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_NOT_SUPPORT: Not supported

□ **Return value** Value Meaning

S_OK Normal termination

S_FALSE Communication failure

□ Gets the current total power consumption as an array.

Function This function is not supported with the C70 or M700 series.

□ **Reference**

□ **Specification**


2.10.1 IEZNCRunStatus::GetInvalidStatus **Get disabled status**

```

□ Custom call procedure
HRESULT      GetInvalidStatus(
                LONG* pIStatus,           // (O) Disabled status flag
                LONG* pIRet              // (O) Error code
            )

□ Automation call procedure
Status_GetInvalidStatus(
    pIStatus As LONG*                   // (O) Disabled status flag
) As LONG                               // (O) Error code
    
```

□ *pIStatus* : Returns the disabled bit flag.



pIRet: Returns an error code. (Upon automation, the return value is used.)

- S_OK**: Normal termination
- EZNC_DATA_READ_ADDR**: Invalid system specification
- EZNC_DATA_READ_READ**: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Returns the disabled flag.
 Disabled status: Disables single block stop
 Waits for the MST command completion signal
 Disables feed hold
 Disables cutting override
 Disables G09 block deceleration check

□ **Reference**

□ **Specifica-
tion** System

2.10.2 IEZNCRunStatus::GetCommandStatus

Get operation command status

□ Custom call procedure

```

HRESULT      GetCommandStatus(
                LONG* pIStatus,           // (O) Operation command status
                LONG* pIRet              // (O) Error code
            )

```

□ Automation call procedure

```

Status_GetCommandStatus(
    pIStatus As LONG           // (O) Operation command status
) As LONG                    // (O) Error code

```

□ *pIStatus* : Returns the operation command status with any of the following numbers.

Argument	Value	Meaning	Value	Meaning
	0	Positioning (independent axis)	15	3rd reference position verification
	1	Positioning (linear)	16	4th reference position verification
	2	Linear interpolation	17	Automatic reference position return
	3	Circular interpolation (CW)	18	Return from the automatic reference position
	4	Circular interpolation (CCW)	19	2nd reference position return
	5	Helical interpolation (CW)	20	3rd reference position return
	6	Helical interpolation (CCW)	21	4th reference position return
	7	Reserved	22	Skip function
	8	Reserved	23	Multi-skip function 1
	9	Reserved	24	Multi-skip function 2
	10	Reserved	25	Multi-skip function 3
	11	Time command dwell	26	Threading
	12	Reserved	27	Reserved
	13	1st reference position verification	28	Reserved
	14	2nd reference position verification	29	Coordinate system setting

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets the operation command status.

□ Reference

□ Specification

System

2.10.3 IEZNCRunStatus::GetCuttingMode

Get cutting mode status

□ Custom call procedure

```
HRESULT      GetCuttingMode(
                LONG* pIMode,           // (O) Cutting mode
                LONG* pIRet            // (O) Error code
            )
```

□ Automation call procedure

```
Status_GetCuttingMode(
    pIMode As LONG           // (O) Cutting mode
) As LONG                   // (O) Error code
```

□ *pIMode*: Returns the cutting mode.

Argument	Value	Meaning
	1	In G01, G02, G03, G31, G33, G34, or G35 mode
	0	In any of other modes

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the cutting mode.

□ **Reference**

□ **Specifica-
tion** System

2.10.4 IEZNCRunStatus::GetAxisStatus

Get servo axis status

□ Custom call procedure

```

HRESULT      GetAxisStatus(
                LONG IAxisNo,                // (I) Axis No.
                LONG IType,                  // (I) Status type
                LONG* pIStatus,              // (O) Servo axis status
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Status_GetAxisStatus(
    IAxisNo As LONG                // (I) Axis No.
    IType As LONG                  // (I) Status type
    pIStatus As LONG*              // (O) Servo axis status
) As LONG                          // (O) Error code

```

□ **Argument** *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)
Valid when *IType* = 4. All axes information in the set part system can get when *Type* = number other than 4.

IType: Sets the status type.

pIStatus : Returns the servo axis status.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid system, spindle specification

EZNC_DATA_READ_READ: Data is not readable

<i>IType</i>	Description	Data range
0	1st reference position return completion.	A bit corresponding to the returned axis becomes 1. Example) 00000101 = The 1st and 3rd axes returns have been completed.
1	2nd reference position return completion.	A bit corresponding to the returned axis becomes 1. Example) 00000010 = The 2nd axis return has been completed.
2	3rd reference position return completion.	A bit corresponding to the returned axis becomes 1. Example) 00001010 = The 2nd and 3th axes returns have been completed.
3	Fourth reference position return completion.	A bit corresponding to the returned axis becomes 1. Example) 00001000 = The 4th axis return has been completed.
4	Axis status (axis being removed). The axis specification is required.	0: Axis not being removed 1: Axis being removed
5	Axis status (servo off).	Axis with servo turned off A bit corresponding to the axis becomes 1.
6	Axis status (mirror image).	Mirror image axis. A bit corresponding to the axis set for mirror image becomes 1.

□ **Return value** Value Meaning

S_OK Normal termination

S_FALSE Communication failure

Gets the servo axis status.

Function

Reference

**Specifica-
tion**

(Part system setting is required when the M700/M800 series is used or IType is 4 or 6.),

2.10.5 IEZNCRunStatus::GetRunStatus

Get operation status

□ Custom call procedure

```

HRESULT      GetRunStatus(
                LONG lIndex,                // (I) Operation type
                LONG* pIStatus,             // (O) Operation status
                LONG* pIRet                  // (O) Error code
            )

```

□ Automation call procedure

```

Status_GetRunStatus(
    lIndex As LONG                // (I) Operation type
    pIStatus As LONG*             // (O) Operation status
) As LONG                          // (O) Error code

```

□ *lIndex*: Sets the status number.

Argument

pIStatus: Returns the set operation status.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

<i>lIndex</i>	Description	Data range
0	Tool length measurement.	0: Tool length not being measured 1: Tool length being measured
1	In automatic operation "run". Gets the status indicating that the system is operating automatically.	0: Not operating in automatically 1: Operating automatically
2	Automatic operation "start". Gets the status indicating that the system is operating automatically and that a movement command or M, S, T, B process is being executed.	0: Not starting automatic operation 1: Starting automatic operation
3	Automatic operation "pause". Gets the status indicating that automatic operation is paused while executing a movement command or miscellaneous command with automatic operation.	0: Automatic operation not paused 1: Automatic operation paused

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ Gets the operation status.

Function Automatic operation paused is enabled only for the M700/M800 series.

Signals that indicate the status of automatic operation with the PLC interface include 'in automatic operation', 'automatic operation start', and 'automatic operation pause'. The ON/OFF statuses of these three signals in each state are shown below.

	In automatic operation "RUN" (OP)	In automatic operation "START" (STL)	In automatic operation "PAUSE" (SPL)
In "reset"	0	0	0
Automatic operation stop condition	1	0	0
Automatic operation pause condition	1	0	1
Automatic operation start condition	1	1	0

Each status represents the following type of state.

* Reset state

Automatic operation is stopped because of the reset conditions.

(All states in which the system is not operating automatically correspond to this.)

* Automatic operation stopped state

Automatic operation is stopped after executing one block.

(Single block stop corresponds to this.)

* Automatic operation pause state

Automatic operation is stopped during the execution of one block.

(The automatic operation pause (*SP) signal OFF state corresponds to this.)

* Automatic operation started state

Automatic operation is actually being executed.

Refer to the PLC Interface Manual for details.

□

Reference

□

**Specifica-
tion**

System

2.11.1 IEZNCFile6::FindDir2

Search directory

□ Custom call procedure

```

HRESULT FindDir2(
    LPCOLESTR IpcwszDirectoryName, // (I) Directory name
    LONG IFileType, // (I) Read type and format
    LPOLESTR* IppwszFileInfo, // (O) File information character string
    LONG* pIRet // (O) Error code
)

```

□ Automation call procedure

```

File_FindDir2(
    IpcwszDirectoryName As STRING // (I) Directory name
    IFileType As LONG // (I) Read type and format
    IppwszFileInfo As STRING* // (O) File information character string
) As LONG // (O) Error code

```

- *IpcwszDirectoryName*: Sets the directory name as a **UNICODE** character string.
- Argument** Specify directory with an absolute path as follows:
- Drive name + ":" + \Directory name\File name ...Gets the set file name information. (Note 1)
 - Drive name + ":" + "\Directory name" ...Gets the set directory name information. (Note 1)
 - Drive name + ":" + \Directory name\ ...Gets the set directory information.

(Note 1) This setting is for the M700/M800 series.

IFileType: Sets the type and format of data to be read.

The following can also be set with pipe (|). When **NULL** is set, file information is read.

Value	Meaning
EZNC_DISK_DIRTYPE	Directory information read
EZNC_DISK_COMMENT	Comment information read (on the NC control unit side only)
EZNC_DISK_DATE	Date information read (on the personal computer side only)
EZNC_DISK_SIZE	Size information read

IppwszFileInfo: Gets file information as a **UNICODE** character string.

The format of file information becomes as follows:

File name\tSize\tDate\tComment\0

A **TAB** code is inserted between file name, size, date, and comments.

The end of the data becomes a **NULL** code.

pIRet: Returns whether or not there is file information read or returns an error code. (Upon automation, the return value is used.)

0: When there is no file information

1 or more: When there is file information

EZNC_FILE_DIR_DATASIZE: Exceeded maximum data size

EZNC_FILE_DIR_NOTOPEN: Not open

EZNC_FILE_DIR_READ: File information read error

EZNC_FILE_DIR_ALREADYOPENED: A different directory is already opened

EZNC_FILE_DIR_NODRIVE: Drive does not exist

EZNC_FILE_DIR_NODIR: Directory does not exist

(Note 2) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes

EZNC_PCFILE_...

□ Return value	<table border="1"> <thead> <tr> <th data-bbox="316 197 384 226">Value</th> <th data-bbox="783 197 887 226">Meaning</th> </tr> </thead> <tbody> <tr> <td data-bbox="316 259 384 288">S_OK</td> <td data-bbox="783 259 1007 288">Normal termination</td> </tr> <tr> <td data-bbox="316 293 432 322">S_FALSE</td> <td data-bbox="783 293 1046 322">Communication failure</td> </tr> </tbody> </table>	Value	Meaning	S_OK	Normal termination	S_FALSE	Communication failure
Value	Meaning						
S_OK	Normal termination						
S_FALSE	Communication failure						
□ Function	<p data-bbox="316 327 544 356">Searches directory.</p> <p data-bbox="316 356 1473 472">In FindDir2(), information of one file can be read by reading once. To continuously get directory information, a list of file names in the set directory can be got by calling FindNextDir2() repeatedly. The format of file information to be stored in the area indicated by <i>lpszFileInfo</i> is as follows:</p> <p data-bbox="416 517 823 546">File name\tSize\tDate\tComment\0</p> <p data-bbox="316 551 1473 640">A TAB code is inserted between file name, size, date, and comments. The end of the data becomes a NULL code. Only information that follows file name set in the read type is stored. For example, if "EZNC_DISK_COMMENT EZNC_DISK_DATE" is set, information is as follows:</p> <p data-bbox="416 645 751 674">File name\tDate\tComment\0</p> <p data-bbox="316 678 1473 734">If "EZNC_DISK_SIZE EZNC_DISK_COMMENT" is set for a file to which comments cannot be added, the comment information will not be output and the comment will be as follows:</p> <p data-bbox="416 739 647 768">File name\tSize\t\0</p> <p data-bbox="316 772 1473 828">For a file from which date cannot get, setting of "EZNC_DISK_SIZE EZNC_DISK_DATE EZNC_DISK_COMMENT" becomes as follows with no date information output.</p> <p data-bbox="416 833 767 862">File name\tSize\t\tComment\0</p> <p data-bbox="416 866 1473 916">* The file from which a date cannot get refers to the file on the NC control unit side.</p> <p data-bbox="316 920 1473 976">As the character string area memory is allocated in this product, the client using VC++ needs to release the character string area memory explicitly with CoTaskMemFree().</p> <p data-bbox="316 1010 1473 1066">(Note 1) Reading the directory size information on the NC-side compact flash (M700 series) or SD card (M800 series) is not supported. The directory size information read is invalid.</p> <p data-bbox="316 1070 1473 1126">(Note 2) For the C70, when the file on the personal computer is specified and 0 is specified for <i>FileType</i>,</p> <p data-bbox="416 1131 1070 1160">\t is added to the end of file information got (filename\t\0).</p> <p data-bbox="416 1164 991 1193">To use file information got, remove \t before using.</p>						
□ Restrictions	<p data-bbox="316 1200 1473 1256">When FindDir2() is used, FindDir2(), OpenFile3(), OpenNcFile2() cannot be executed until ResetDir() is executed.</p> <p data-bbox="316 1261 1473 1346">When executed, an error "EZNC_FILE_DIR_ALREADYOPENED (0x80030101) A different directory is already opened" occurs. When using it, immediately execute ResetDir() after executing FindDir2().</p>						
□ Reference	<p data-bbox="316 1424 639 1453">FindNextDir2(), ResetDir()</p>						
□ Specification							

2.11.2 IEZNCFile6::FindNextDir2

Search next directory

□ Custom call procedure

```

HRESULT      FindNextDir2(
                LPOLESTR* lppwszFileInfo,    // (O) File information character string
                LONG* plRet                    // (O) Error code
            )

```

□ Automation call procedure

```

File_FindNextDir2(
    lppwszFileInfo As STRING*    // (O) File information character string
) As LONG                       // (O) Error code

```

□ *lppwszFileInfo*: Gets file information as a **UNICODE** character string.

Argument The format of file information becomes as follows:

File name\tSize\tDate\tComment\0

A **TAB** code is inserted between file name, size, date, and comments.

The end of the data becomes a **NULL** code.

plRet: Returns whether or not there is file information read or returns an error code. (Upon automation, the return value is used.)

0: When there is no file information

1 or more: When there is file information

EZNC_FILE_DIR_DATASIZE: Exceeded maximum data size

EZNC_FILE_DIR_NOTOPEN: Not open

EZNC_FILE_DIR_READ: File information read error

EZNC_FILE_DIR_NODRIVE: Drive does not exist

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes **EZNC_PCFILE_...**

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ Continuously searches for a directory.

Function To continuously get directory information after executing **FindDir2()**, a list of file names in the set directory can get by calling **FindNextDir2()** repeatedly. The format of file information that is stored in the area indicated by *lpszFileInfo* is the same as that for **FindDir2()**. As the character string area memory is allocated in this product, the client using VC++ needs to release the character string area memory explicitly with **CoTaskMemFree()**.

□ **FindDir2(), ResetDir()**

Reference

□ **Specification**

2.11.3 IEZNCFile6::ResetDir

Terminate directory search

□ Custom call procedure

```
HRESULT      ResetDir(
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
File_ResetDir( ) As LONG                // (O) Error code
```

□ *pIRet*: Returns an error code. (Upon automation, the return value is used.)

□ Argument

EZNC_FILE_DIR_DATASIZE: Exceeded maximum data size

EZNC_FILE_DIR_NOTOPEN: Not open

EZNC_FILE_DIR_READ: File information read error

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes **EZNC_PCFILE_...**

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□

□ Function

Terminates directory search.

To search for a directory again, execute **FindDir2()**.

□

□ Reference

FindDir2()

□

□ Specification

2.11.4 IEZNCFile6::Copy2

Copy file

□ Custom call procedure

```

HRESULT      Copy2(
                LPCOLESTR lpcwszSrcFileName, // (I) Transfer source file name
                LPCOLESTR lpcwszDstFileName, // (I) Transfer destination file name
                LONG* plRet // (O) Error code
            )

```

□ Automation call procedure

```

File_Copy2(
    lpcwszSrcFileName As STRING // (I) Transfer source file name
    lpcwszDstFileName As STRING // (I) Transfer destination file name
) As LONG // (O) Error code

```

□ *lpcwszSrcFileName*: Sets transfer source file name using **UNICODE** character strings.

Argument

lpcwszDstFileName: Sets transfer destination file name as a **UNICODE** character strings.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_COPY_BUSY: Copy is disabled (during operation)

EZNC_FILE_COPY_ENTRYOVER: Registration limit exceeded

EZNC_FILE_COPY_FILEEXIST: Copy destination file already exists

EZNC_FILE_COPY_FILESYSTEM: File system error

EZNC_FILE_COPY_ILLEGALNAME: Invalid file name format

EZNC_FILE_COPY_MEMORYOVER: Memory capacity exceeded

EZNC_FILE_COPY_NODIR: Directory does not exist

EZNC_FILE_COPY_NODRIVE: Drive does not exist

EZNC_FILE_COPY_NOFILE: File does not exist

EZNC_FILE_COPY_PLCRUN: Copy is disabled (programmable controller in operation)

EZNC_FILE_COPY_READ: Transfer source file is not readable

EZNC_FILE_COPY_WRITE: Transfer destination file is not writable

EZNC_FILE_COPY_PROTECT: Copying is disabled (protected)

EZNC_PCFILE_COPY_CREATE: File cannot be created (PC only)

EZNC_PCFILE_COPY_OPEN: File cannot be opened (personal computer only)

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes

EZNC_PCFILE_....

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

-
- **Function** Copies the file set by *lpcwszSrcFileName* to *lpcwszDstFileName*.
Set a file name with an absolute path as follows:
Drive name + ":" + \Directory name\File name

lpcwszDstFileName must not be a file name that already exists. The transfer destination directory must already exist.

In the C70, multiple program files under \PRG\USER can be collectively copied to a file on a personal computer. In this case, specify "*" as a file name for *lpcwszSrcFileName* (example: M01:\PRG\USER*.*)). Set any file name on a personal computer for *lpcwszDstFileName* (example: C:\PLURAL.PRG). To expand files combined into one in the C70, set any file name on a personal computer for *lpcwszSrcFileName* (example: C:\PLURAL.PRG) and set "ALL.PRG" as a file name under \PRG\USER of *lpcwszDstFileName* (example: M01:\PRG\USER\ALL.PRG).

This method does not check whether the set directory and file name are appropriate or not. It is recommended to check the appropriateness of file name and directory for irregular operations such as transfer between files with different types and applications (example: overwriting the user program (\PRG\USER\ to.PRG) with parameter file (PARAMET.BIN)) or copying a file to a directory with different purposes.

(Note) Do not perform this operation during automatic operation of the NC control unit. (C70 only)

-
- **Reference** Delete2(), Rename2()

- **Specification**
-

2.11.5 IEZNCFile6::Delete2

Delete file

□ Custom call procedure

```

HRESULT Delete2(
    LPCOLESTR lpcwszFileName, // (I) File name
    LONG* pRet // (O) Error code
)

```

□ Automation call procedure

```

File_Delete2(
    lpcwszFileName As STRING // (I) File name
) As LONG // (O) Error code

```

□ *lpcwszFileName*: Sets the file name as a **UNICODE** character string.

Argument

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_DEL_BUSY: Deletion is disabled (during operation)

EZNC_FILE_DEL_FILESYSTEM: File system error

EZNC_FILE_DEL_ILLEGALNAME: Invalid file name format

EZNC_FILE_DEL_PROTECT: Deletion is disabled (protected)

EZNC_FILE_DEL_NODIR: Directory does not exist

EZNC_FILE_DEL_NODRIVE: Drive does not exist

EZNC_FILE_DEL_NOFILE: File does not exist

EZNC_PCFILE_DEL_NOTDELETE: File cannot be deleted

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes **EZNC_PCFILE_...**

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Deletes the file set in *lpcwszFileName*.
Set a file name with an absolute path as follows:
Drive name + ":" + \Directory name\File name

(Note) Do not perform this operation during automatic operation of the NC control unit. (C70 only)
For the M700/M800 series, the operation can be performed unless automatic operation of the file intended for operation is being carried out.

□ **Reference** **Copy2(), Rename2()**

□ **Specification**

2.11.6 IEZNCFile6::Rename2

Change file name

□ Custom call procedure

```

HRESULT      Rename2(
                LPCOLESTR lpcwszSrcFileName, // (I) Old file name
                LPCOLESTR lpcwszDstFileName, // (I) New file name
                LONG* plRet                 // (O)Error code
            )

```

□ Automation call procedure

```

File_Rename2(
    lpcwszSrcFileName As STRING // (I) Old file name
    lpcwszDstFileName As STRING // (I) New file name
) As LONG // (O)Error code

```

□ *lpcwszSrcFileName*: Sets an old file name.

Argument

lpcwszDstFileName: Sets a new file name.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_REN_BUSY: Rename is disabled (during operation)

EZNC_FILE_REN_FILEEXIST: New file name already exists

EZNC_FILE_REN_FILESYSTEM: File system error

EZNC_FILE_REN_ILLEGALNAME: Invalid file name format

EZNC_FILE_REN_PROTECT: Rename is disabled (protected)

EZNC_FILE_REN_NODIR: Directory does not exist

EZNC_FILE_REN_NODRIVE: Drive does not exist

EZNC_FILE_REN_NOFILE: File does not exist

EZNC_PCFIL_REN_NOTRENAME: Rename is disabled

EZNC_PCFIL_REN_SAMENAME: New and old file names are identical

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes

EZNC_PCFIL_...

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Changes the file name set for *lpcwszSrcFileName* to that set for *lpcwszDstFileName*.

For *lpszSrcFileName*, set with an absolute path.

Drive name + ":" + \Directory name\File name

For *lpcwszDstFileName*, set only file name without drive name and directory. For *lpcwszDstFileName*, a file name that already exists must not be set.

(Note) Do not perform this operation during automatic operation of the NC control unit. (C70 only)

For the M700/M800 series, the operation can be performed during automatic operation of the NC control unit, unless automatic operation of the file intended for operation is being carried out.

□ **Reference** **Copy2(), Delete2()**

□ **Specifica-
tion**

2.11.7 IEZNCFile6::GetDriveInformation

Get drive information

□ Custom call procedure

```

HRESULT      GetDriveInformation(
                LPOLESTR* lppwszDriveInfo, // (O) Drive information character string
                LONG* plRet                // (O) Error code
                )

```

□ Automation call procedure

```

File_GetDriveInformation(
    lppwszDriveInfo As STRING* // (O): Drive information character string
    ) As LONG // (O) Error code

```

□ *lppwszDriveInfo*: Gets drive information as a **UNICODE** character string.

Argument The format of drive information is as follows:

Drive name:**CRLF**Drive name:**CRLF**...Drive name:**CRLF**\0

To separate drive names, CR, LF codes are inserted between them. The end of the data becomes **CR**, **LF** codes and a **NULL** code. The end of the data becomes a **NULL** code.

plRet: Returns the size of drive information got or an error code. (Upon automation, the return value is used.)

0: When a drive does not exist

1 or more: Number of bytes

EZNC_FILE_DRVLIST_READ: Drive information read error

EZNC_FILE_DIR_NODRIVE: Drive does not exist

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes **EZNC_PCFILE_...**

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Reads drive information of the NC control unit that is currently connected.

The format of drive information is as follows:

Drive name:**CRLF**Drive name:**CRLF**...Drive name:**CRLF**\0

To separate drive names, CR, LF codes are inserted between them. The end of the data becomes **CR**, **LF** codes and a **NULL** code. The end of the data becomes a **NULL** code.

Drive information on a personal computer cannot be read.

As the character string area memory is allocated in this product, the client using VC++ needs to release the character string area memory explicitly with **CoTaskMemFree()**.

□ **Reference** **GetDriveSize()**

□ **Specification**

2.11.8 IEZNCFile6::GetDriveSize

Get free drive space

□ Custom call procedure

```

HRESULT      GetDriveSize(
                LPCOLESTR lpcwszDirectryName,      // (I) Directory name
                LONG* plDriveSize,                // (O) Free space
                LONG* plRet                        // (O) Error code
                )

```

□ Automation call procedure

```

File_GetDriveSize(
    lpcwszDirectryName As STRING                // (I) Directory name
    plDriveSize As LONG*                        // (O) Free space
    ) As LONG                                    // (O) Error code

```

- **Argument** *lpcwszDirectryName*: Sets the directory name as a **UNICODE** character string. Directory is set with an absolute path as follows:
Drive name + ":" + \Directory name\

plDriveSize: Gets free space of the set directory. (unit: byte)

plRet: Returns an error code. (Upon automation, the return value is used.)

EZNC_FILE_REN_FILESYSTEM: File system error

EZNC_FILE_DIR_NODRIVE: Drive does not exist

EZNC_FILE_DISKFREE_NODIR: Directory does not exist

EZNC_FILE_DISKFREE_NODRIVE: Drive does not exist

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes **EZNC_PCFILE_....**

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

- **Function** Returns free space of the directory specified for *lpcwszDirectryName*. The unit of free space is a byte. Directory is specified with an absolute path as follows:
Drive name + ":" + \Directory name\

When a drive on a personal computer is set for drive name, setting of directory is ignored, and free space of the drive is returned.

When the NC control unit is set for a drive name, free space of the set directory is returned. When a subdirectory exists in the set directory, usage in the subdirectory is excluded from calculation of free space.

(Note) When a directory name (M01:\IC1\) that corresponds to the compact flash (M700 series) or SD card (M800 series) on the NC side is set, up to 2GB can get.

- **Reference** **GetDriveInformation()**

- **Specifica-
tion**

2.11.9 IEZNCFile6::GetDriveSize2

Get free drive space

□ Custom call procedure

```

HRESULT      GetDriveSize2(
                LPCOLESTR lpcwszDirectryName, // (I) Directory name
                LONG* plDriveSize,           // (O) Free space
                LONG* plRet                   // (O) Error code
            )

```

□ Automation call procedure

```

File_GetDriveSize2(
    lpcwszDirectryName As STRING // (I) Directory name
    plDriveSize As LONG*         // (O) Free space
) As LONG                       // (O) Error code

```

□ **Argument** *lpcwszDirectryName*: Sets the directory name as a **UNICODE** character string. Directory is set with an absolute path as follows:
Drive name + ":" + \Directory name\

plDriveSize: Gets free space of the set directory. (unit: byte)

Automation argument:

lpcwszDirectryName: See the explanation of *lpcwszDirectryName*.

pvDriveSize: Gets the free space of the set directory as a character string.

plRet: Returns an error code. (Upon automation, the return value is used.)

EZNC_FILE_REN_FILESYSTEM: File system error

EZNC_FILE_DIR_NODRIVE: Drive does not exist

EZNC_FILE_DISKFREE_NODIR: Directory does not exist

EZNC_FILE_DISKFREE_NODRIVE: Drive does not exist

(Note) If an error occurs on the personal computer, the error code **EZNC_FILE_...** becomes **EZNC_PCFILE_....**

□ Return value	Value	Meaning
----------------	-------	---------

	S_OK	Normal termination
--	-------------	--------------------

	S_FALSE	Communication failure
--	----------------	-----------------------

□ **Function** Returns free space of the directory set for *lpcwszDirectryName*.
The unit of free space is a byte.
Directory is set with an absolute path as follows:
Drive name + ":" + \Directory name\

When a drive on a personal computer is set for drive name, setting of directory is ignored, and free space of the drive is returned.

When the NC control unit is set for a drive name, free space of the set directory is returned. When a subdirectory exists in the set directory, usage in the subdirectory is excluded from calculation of free space.

This is valid only for the M800 series.

This function is not supported with C70.

□ **Reference** **GetDriveInformation()**□ **Specifica-
tion**

2.11.10 IEZNCFile6::OpenFile3

Open file

□ Custom call procedure

```

HRESULT      OpenFile3(
                LPCOLESTR lpcwszFileName, // (I) File name containing a path
                LONG lMode, // (I) Open mode
                LONG* plRet // (O) Error code
            )

```

□ Automation call procedure

```

File_OpenFile3(
    bstrFileName As STRING // (I) File name containing a path
    lMode As LONG // (I) Open mode
) As LONG // (O) Error code

```

- **Argument** *lpcwszFileName*: Sets the file name containing a path as a **UNICODE** character string.
 A file is set with an absolute path as follows:
 Drive name + ":" + \Directory name\File name

For a list of files in the NC control unit that is accessible, refer to Table 2-1, Table 2-2 and Table 2-3. All files except for machining programs in the NC control unit can be backed up, but cannot be edited.

bstrFileName: Refer to the explanation of *lpcwszFileName*.

lMode: Sets open mode.

Value	Meaning
EZNC_FILE_READ	Read mode
EZNC_FILE_WRITE	Write mode
EZNC_FILE_OVERWRITE	Overwrite mode (writes even if the specified file exists.)

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_OPEN_OPEN: File cannot be opened

EZNC_FILE_OPEN_ALREADYOPENED: File is already open

EZNC_FILE_OPEN_FILEEXIST: File already exists (in write mode)

EZNC_FILE_OPEN_FILENOEXIST: File does not exist (in read mode)

EZNC_FILE_OPEN_MODE: Invalid open mode

EZNC_FILE_OPEN_NOTOPEN: File cannot be opened

EZNC_FILE_OPEN_CREATE: Temporary file cannot be created (in write mode)

EZNC_FILE_READFILE_CREATE: Temporary file cannot be created (in read mode)

EZNC_FILE_DIR_NODRIVE: Drive does not exist

EZNC_FILE_DIR_ALREADYOPENED: A different directory is already opened

EZNC_FILE_OPEN_ILLEGALPATH: Invalid file path

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

-
- **Function** Opens a file in the specified mode. The directory that creates a temporary file is created in the following order of priority:
- Directory set with environment variable TMP
 - Directory to which the product is installed

The temporary file name is MELDASn. A number is placed in n.

(Note 1) Make sure to close the open file with **CloseFile2()** (or **AbortFile2()**). The temporary file will remain if **CloseFile2()** is not used.

(Note 2) Do not perform write or overwrite operation during automatic operation of the NC control unit. (C70 only)

For the M700/M800 series, write or overwrite operation can be performed during automatic operation of the NC control unit, unless automatic operation of the file intended for operation is being carried out. Read operation can be performed during automatic operation of the NC control unit.

(Note 3) It takes **C70** approximately 20 s to read SRAM.BIN (SRAM data (binary format)). Other methods cannot be used during that time.

-
- **Reference** **CloseFile2(), AbortFile2(), ReadFile2(), WriteFile()**

-
- **Specifica-
tion**
-

Table 2-1 M700 series (version A0 or later) List of accessible files

File description	Directory	File name	Remarks
Machining program	M01:\PRG\USER\	Program No.	
MTB macro	M01:\PRG\MMACRO\	Program No.	Program No. is O100001000 to O199999999.
Fixed cycle program	M01:\PRG\FIX\	Program No.	Program No. is 0100000010 to 100009999.
MDI program	M01:\PRG\MDI\	MDI.PRG	
Parameters [User, machine]	M01:\PRM\	ALL.PRM	
Auxiliary axis parameter	M01:\PRM\	AUXAXIS.PRM	M700/M700VW only
DeviceNet parameter file	M01:\PRM\	DEVICENT.PRM	
Rotary axis geometric deviation parameter file	M01:\PRM\	GEOMETRY.PRM	
PLC program	M01:\LAD\	USERPLC.LAD	
Workpiece offset data	M01:\DAT\	WORK.OFS	
Tool compensation amount data	M01:\DAT\	TOOL.OFS	
Common variable data	M01:\DAT\	COMMON.VAR	
Custom variable data	M01:\DAT\	CUSTOM.VAR	
SRAM data (binary format)	M01:\DAT\	SRAM.BIN	
Sampling data file (binary format)	M01:\DAT\	SAMPLE.BIN	
Tool life management data file	M01:\DAT\	TLIFE.TLF	
Tool management data file	M01:\DAT\	TOOLMNG.DAT	
SRAM open data file	M01:\DAT\	SRAMOPEN.DAT	
Device open data file	M01:\DAT\	DEVOPEN.DAT	
Machining surface data	M01:\DAT\	RNAVI.DAT	
Extended SRAM data (binary format)	M01:\DAT\	EXTSRAM.BIN	
All history	M01:\LOG\	ALLLOGLOG	Key history, alarm history, programmable controller I/O signal history, AC input power supply faults history
Key history	M01:\LOG\	KEYLOGLOG	
Sampling data file	M01:\LOG\	NCSAMP.CSV	
NC-side compact flash	M01:\IC1\	Any	The NC-side compact flash (hereinafter referred to as the "NC-side CF card") is recognized as DS (data server) from the NC control unit. Used for data backup, storing large-capacity programs, etc.

Table 2-2 M800 series List of accessible files

File description	Directory	File name	Remarks
Machining program	M01:\PRG\USER\	Program No.	
MTB macro	M01:\PRG\MMACRO\	Program No.	Program No. is 100010000 to 199999999.
Fixed cycle program	M01:\PRG\FIX\	Program No.	Program No. is 100000010 to 100009999.
MDI program	M01:\PRG\MDI\	MDI.PRG	
Parameters [User, machine]	M01:\PRM\	ALL.PRM	The header (1st line) is different from the M700 series. An M700 file can be used with M800, but an M800 file cannot be used with the M800 series.
Auxiliary axis parameter	M01:\PRM\	AUXAXIS.PRM	
DeviceNet parameter file	M01:\PRM\	DEVICENT.PRM	
Rotary axis geometric deviation parameter file	M01:\PRM\	GEOMETRY.PRM	
Safety parameter file	M01:\PRM\	SAFEPARA.BIN	
System files for maintenance and service	M01:\PRM\	SYSTEM.PRM	This cannot be accessed by the user.
PLC program file	M01:\LAD\	USERPLC.LAD	Not compatible with M700 series.
PLC program file for each project	M01:\LAD\	PROJECTxx.LAD	xx01 to usable project numbers
Own station safety PLC program file	M01:\LAD\	SAFEPLC1.LAD	
Other station safety PLC program file	M01:\LAD\	SAFEPLC2.LAD	
Workpiece offset data file	M01:\DAT\	WORK.OFS	
Tool compensation amount data	M01:\DAT\	TOOL.OFS	
Tool life management data file	M01:\DAT\	TLIFE.TLF	
Common variable data file	M01:\DAT\	COMMON.VAR	The format is different from M700 series
SRAM data	M01:\DAT\	SRAM.BIN	Not compatible with M700 series.
Tool management data file	M01:\DAT\	TOOLMNG.DAT	
SRAM open data file	M01:\DAT\	SRAMOPEN.DAT	
Device open data file	M01:\DAT\	DEVOPEN.DAT	
Machining surface data	M01:\DAT\	RNAVI.DAT	
Tool safety data file	M01:\DAT\	TOOLALL.DAT	
Machine manufacturer macro variable data file	M01:\DAT\	MMACRO.VAR	
All history	M01:\LOG\	ALLLOGLOG	The format is different from M700 series.
Key history data file	M01:\LOG\	KEYLOGLOG	The format is different from M700 series.
Touchscreen history	M01:\LOG\	TOUCHLOG.LOG	
Sampling data file	M01:\LOG\	NCSAMP.CSV	
Sampling data file	M01:\LOG\	NCSAMP.BIN	
PLC message data file (English)	M01:\PLCMSG\	PLCMSG_ENG.TXT	
PLC message data file (Japanese)	M01:\PLCMSG\	PLCMSG_JPN.TXT, etc.	
NC-side SD card	M01:\IC1\	Any	The NC-side SD card is recognized as DS (data server) from the NC control unit. Used for data backup, storing large-capacity programs, etc.

Table 2-3 C70 List of accessible files

File description	Directory	File name	Remarks
Machining program	M01:\PRG\USER\	Program No. PRG	
Fixed cycle program	M01:\PRG\FIX\	Program No. PRG	
MDI program	M01:\PRG\MDI\	MDI.PRG	
Parameters [User, machine]	M01:\PRM\	ALL.PRM	
PLC program file	M01:\LAD\	USERPLC.LAD	
Workpiece offset	M01:\DAT\	WORK.OFS	
Tool offset data	M01:\DAT\	TOOL.OFS	
Common variable data	M01:\DAT\	COMMON.VAR	
SRAM data (binary format)	M01:\DAT\	SRAM.BIN	For maintenance
Sampling data	M01:\LOG\	NCSAMP.CSV	For maintenance
Operation history data	M01:\LOG\	TRACE.TRC	For maintenance



DANGER

Cautions for writing to a file

Carefully check a file before writing to the file for the NC control unit. Writing to an incorrect file may cause unexpected operation, resulting in a serious accident.

2.11.11 IEZNCFile6::CloseFile2

Close file

□ Custom call procedure

```

HRESULT      CloseFile2(
                LONG* pIRet                // (O) Error code
            )

```

□ Automation call procedure

```

File_CloseFile2(
    ) As LONG                // (O) Error code

```

□ **Argument** *pIRet*: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZNC_FILE_WRITEFILE_WRITE: File is not writable

□ Return value	Value	Meaning
-----------------------	-------	---------

	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Closes a file. When the file was opened with **OpenFile3()**, make sure to close it with **CloseFile2()** (or **AbortFile2()**).

(Note) Do not perform this operation during automatic operation of the NC control unit. (C70 only)
 For the M700/M800 series, the operation can be performed during automatic operation of the NC control unit, unless automatic operation of the file intended for operation is being carried out.

□ **Reference** **OpenFile3(), AbortFile2(), ReadFile2(), WriteFile()**

□ **Specifica-
tion**

2.11.12 IEZNCFile6::AbortFile2

Force close file

□ Custom call procedure

```
HRESULT      AbortFile2(
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
File_AbortFile2(
    ) As LONG                // (O) Error code
```

□ **Argument** *pIRet*: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination

Return value	Value	Meaning
--------------	-------	---------

	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Forcibly closes an open file. Use this to stop writing. After writing is stopped, the file which was being written to will be deleted.
 The difference from **CloseFile2()** is that an error is not output.

□ **Reference** **OpenFile3(), CloseFile2(), ReadFile2(), WriteFile()**

□ **Specifica-
tion**

2.11.13 IEZNCFile6::ReadFile2

Read file

□ Custom call procedure

```

HRESULT      ReadFile2(
                DWORD dwLength,           // (I) Size of data to be read
                BYTE** ppbData,          // (O) Read data
                DWORD* pdwNumRead,       // (O) Read data size
                LONG* plRet               // (O) Error code
            )

```

□ Automation call procedure

```

File_ReadFile2(
    ILength As LONG           // (I) Size of data to be read
    pvData As VARIANT*       // (O) Read data
) As LONG                    // (O) Error code

```

-
- **Argument** *dwLength*: Sets the size of data to be read at a time in the number of bytes.
- ppbData*: Returns the pointer for the read byte data array. As the read data area is allocated in this product, the client needs to release it explicitly with **CoTaskMemFree()**.
- pdwNumRead*: Returns the number of bytes that were actually read. In automation call, the **VARIANT** data includes the number of bytes.

Automation argument:

ILength: Refer to the explanation of *dwLength*.

pvData: Returns the read byte data array in VARIANT.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_READFILE_NOTOPEN: No file is open in the read mode

EZNC_FILE_READFILE_READ: File is not readable

EZNC_FILE_READFILE_CREATE: Temporary file cannot be created

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

-
- **Function** Reads data from the file opened with **OpenFile3()**. Data to be read returns a byte data array and its number of bytes. Determines as the end of file when *pdwNumRead* is smaller than *dwLength*. Setting the size of data to be read at a time. When reading a large file, it can be read in multiple parts. The file can be read in sequence until **CloseFile2()** is executed.

-
- **Reference** **OpenFile3(), CloseFile2(), AbortFile2(), WriteFile()**

-
- **Specifica-
tion**
-

2.11.14 IEZNCFile6::WriteFile

Write file

□ Custom call procedure

```

HRESULT      WriteFile(
                DWORD dwLength,           // (I) Size of data to be written
                BYTE* pbData,            // (I) Data to be written
                LONG* pRet                // (O) Error code
            )

```

□ Automation call procedure

```

File_WriteFile(
    vData As VARIANT           // (I) Data to be written
) As LONG                     // (O) Error code

```

□ **Argument** *dwLength*: Sets the size of data that is written at a time in the number of bytes.

pbData: Sets data to be written as byte array.

Automation argument:

vData: Creates data to be written as a byte array and sets it by substituting it in *vData* (VARIANT type) as shown in the example below.

```

Example) Dim vWriteFile As Variant
         Dim byteWrite() As Byte
         vWriteFile = byteWrite

```

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_WRITEFILE_NOTOPEN: No file is open in write mode

EZNC_FILE_WRITEFILE_WRITE: Cannot be written to a file

EZNC_FILE_LENGTH: Invalid write data size

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Writes data to a file opened with **OpenFile3()**. Data to be written is data in a byte array. Sets the size of data to be written at a time. When writing a large amount of data, it can be written in multiple parts. Data can be written in sequence until **CloseFile2()** is executed. (Note 1) When a file in the NC control unit except for a machining program is changed, extra care should be taken because it may cause the NC control unit malfunction. Make sure to back up in advance to restore to its original state.

□ **Reference** **OpenFile3(), CloseFile2(), AbortFile2(), ReadFile2()**

□ **Specifica-
tion**



Cautions for writing to a file

Carefully check a file before writing to the file for the NC control unit. Writing to an incorrect file may cause unexpected operation, resulting in a serious accident.

2.11.15 IEZNCFile6::OpenNCFile2

Open machining program dedicated
file

□ Custom call procedure

```

HRESULT      OpenNCFile2 (
                LPCOLESTR lpcwszFileName,           // (I) File name containing a path
                LONG lMode,                         // (I) Open mode
                LONG* plRet                          // (O) Error code
            )

```

□ Automation call procedure

```

File_OpenNCFile2 (
    bstrFileName As STRING           // (I) File name containing a path
    lMode As LONG                    // (I) Open mode
) As LONG                            // (O) Error code

```

- **Argument** *lpcwszFileName*: Sets the file name containing a path as a **UNICODE** character string.
 A file is set with an absolute path as follows:
 Drive name + ":" + \Directory name\File name

Paths other than those shown below cannot be used.

Model	Machining program
M700 series	M01:\PRG\USER\Machining Program No. M01:\PRG\UMACRO\Machining Program No. M01:\PRG\MMACRO\Machining Program No. M01:\PRG\FIX\Machining Program No. M01:\PRG\MDI\Machining Program No.
M800 series	M01:\PRG\USER\Machining Program Name (32 or less alphanumeric characters including extension) M01:\PRG\MMACRO\Machining Program No. (100010000 –199999999) M01:\PRG\FIX\Machining Program No. (100000010 –100009999) M01:\PRG\MDI\MDI.PRG

bstrFileName: Refer to the explanation of *lpcwszFileName*.

lMode: Sets open mode.

Value	Meaning
EZNC_FILE_READ	Read mode
EZNC_FILE_WRITE	Write mode
EZNC_FILE_OVERWRITE	Overwrite mode (writes even if the specified file exists.)

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_OPEN_ALREADYOPENED: File is already open

EZNC_FILE_OPEN_FILEEXIST: File already exists (in write mode)

EZNC_FILE_OPEN_MODE: Invalid open mode

EZNC_FILE_OPEN_NOTOPEN: File cannot be opened

EZNC_FILE_OPEN_CREATE: File cannot be created (in write mode)

EZNC_FILE_OPEN_ILLEGALPATH: Invalid path

EZNC_FILE_OPEN_FILENOTEXIST: File does not exist

EZNC_FILE_OPEN_OPEN: File cannot be opened

EZNC_FILE_DIR_ALREADYOPENED: A different directory is already opened

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Opens the machining program file in the set mode. The directory that creates a temporary file is created in the following order of priority:	
	<ul style="list-style-type: none"> • Directory specified with environment variable TMP • Directory to which the product is installed 	
	The temporary file name is "MELDASn". A number is placed in n.	
	OpenFile3() cannot be used concurrently.	
	This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to pRet.)	
	(Note 1) Make sure to close the open file with CloseNCFile2() (or AbortNCFile2()). If CloseNCFile2() is not used, a temporary file will remain.	
	(Note 2) For the M700/M800 series, write or overwrite operation can be performed during automatic operation of the NC control unit, unless automatic operation of the file intended for operation is being carried out. Read operation can be performed during automatic operation of the NC control unit.	
□ Reference	CloseNCFile2(), AbortNCFile2(), ReadNCFile2(), WriteNCFile()	
□ Specification		

2.11.16 IEZNCFile6::CloseNCFile2

Close machining program dedicated
file

□ Custom call procedure

```
HRESULT      CloseNCFile2(
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
File_CloseNCFile2(
    ) As LONG                // (O) Error code
```

□ **Argument** *pIRet*: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZNC_FILE_WRITEFILE_WRITE: File is not writable
EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Closes the machining program file.
 This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)

(Note 1) For the M700/M800 series, the operation can be performed during automatic operation of the NC control unit, unless automatic operation of the file intended for operation is being carried out.

(Note 2) When the file was opened with **OpenNCFile2()**, make sure to close it with **CloseNCFile2()** (or **AborNCtFile2()**).

□ **Reference** **OpenNCFile2()**, **AbortNCFile2()**, **ReadNCFile2()**, **WriteNCFile()**

□ **Specifica-
tion**

2.11.17 IEZNCFile6::AbortNCFile2

Force close machining program
dedicated file

□ Custom call procedure

```
HRESULT      AbortNCFile2(
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
File_AbortNCFile2(
    ) As LONG                // (O) Error code
```

□ **Argument** *pIRet*: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Force closes the open machining program file. Use this to stop writing. After writing is stopped, the file which was being written to will be deleted.
The difference from **CloseNCFile2()** is that an error is not output.
This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)

2.11.18 IEZNCFile6::ReadNCFile2

Read machining program dedicated
file

□ Custom call procedure

```

HRESULT      ReadNCFile2(
                DWORD dwLength,           // (I) Size of data to be read
                BYTE** ppbData,         // (O) Read data
                DWORD* pdwNumRead,      // (O) Read data size
                LONG* pIRet              // (O) Error code
            )

```

□ Automation call procedure

```

File_ReadNCFile2(
    ILength As LONG           // (I) Size of data to be read
    pvData As VARIANT*       // (O) Read data
) As LONG                    // (O) Error code

```

□ **Argument** *dwLength*: Sets the size of data to be read at a time in the number of bytes.

ppbData: Returns the pointer for the read byte data array. As the read data area is allocated in this product, the client needs to release it explicitly with **CoTaskMemFree()**.

pdwNumRead: Returns the number of bytes that were actually read. In automation call, the **VARIANT** data includes the number of bytes.

Automation argument:

ILength: Refer to the explanation of *dwLength*.

pvData: Returns the read byte data array in **VARIANT**.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_READFILE_NOTOPEN: No file is open in the read mode

EZNC_FILE_READFILE_READ: File is not readable

EZNC_FILE_READFILE_CREATE: Temporary file cannot be created

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Data is read from the machining program file opened with **OpenNCFile2()**. Data to be read returns a byte data array and its number of bytes. Determines as the end of file when *pdwNumRead* is smaller than *dwLength*. Sets the size of data to be read at a time. When reading a large file, it can be read in multiple parts. The file can be read in sequence until **CloseNCFile2()** is executed. This function is not supported with C70. (**EZ_ERR_NOT_SUPPORT** is returned to *pIRet*.)

□ **Reference** **OpenNCFile2(), CloseNCFile2(), AbortNCFile2(), WriteNCFile()**

□ **Specification**

2.11.19 IEZNCFile6::WriteNCFile

Write machining program dedicated
file

□ Custom call procedure

```

HRESULT      WriteNCFile(
                DWORD dwLength,           // (I) Size of data to be written
                BYTE* pbData,           // (I) Data to be written
                LONG* pIRet             // (O) Error code
                )

```

□ Automation call procedure

```

File_WriteNCFile(
  vData As VARIANT           // (I) Data to be written
) As LONG                   // (O) Error code

```

□ **Argument** *dwLength*: Sets the size of data that is written at a time in the number of bytes.

pbData: Sets data to be written as byte array. In automation call, *vData* includes the number of bytes.

Automation argument:

vData: Creates data to be written as a byte array and sets it by substituting it in *vData* (VARIANT type) as shown in the example below.

```

Example) Dim vWriteFile As Variant
         Dim byteWrite() As Byte
         vWriteFile = byteWrite

```

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_WRITEFILE_NOTOPEN: No file is open in write mode

EZNC_FILE_WRITEFILE_WRITE: Cannot be written to a file

EZNC_FILE_LENGTH: Invalid write data size

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Data is written to the machining program file opened with **OpenNCFile2()**. Data to be written is data in a byte array.
Sets the size of data to be written at a time. When writing a large amount of data, it can be written in multiple parts. Data can be written in sequence until **CloseNCFile2()** is executed. This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)
(Note) For the M700/M800 series, when edit lock B (#8105) parameter is 1, programs 8000 to 9999 cannot be written. When edit lock C (#1121) parameter is 1, programs 9000 to 9999 cannot be written.

□ **Reference** **OpenNCFile2(), CloseNCFile2(), AbortNCFile2(), ReadNCFile2()**

□ **Specification**



Cautions for writing to a file

Carefully check a file before writing to the file for the NC control unit. Writing to an incorrect file may cause unexpected operation, resulting in a serious accident.

2.12.1 IEZNCCommonVariable2::CommonVRead **Read common variables**

□ **Custom call procedure**

```
HRESULT CommonVRead(
    LONG lIndex,           // (I) Variable number
    DOUBLE* pdData,       // (O) Variable value
    LONG* plType           // (O) Type
    LONG* plRet           // (O) Error code
)
```

□ **Automation call procedure**

```
CommonVariable_Read2(
    lIndex As LONG           // (I) Variable number
    pdData As DOUBLE*       // (O) Variable value
    plType As LONG*         // (O) Type
) As LONG                  // (O) Error code
```

□ **Argument** *lIndex*: Sets the common variable number to be read.
 Value:
 (For C70)
 100 to 199, 500 to 999
 (For M700/M800 series)
 100 to 199, 400 to 999, 100100 to 100199, 200100 to 200199, 300100 to 300199
 400100 to 400199, 500100 to 500199, 600100 to 600199
 700100 to 700199, 800100 to 800199, 900000 to 907399

pdData: Returns the common variable value of the set common variable number.

plType: Returns the variable value type. (For the **M700/M800 series**, enabled.)

Value	Meaning
1	Numerical value
0	Not set

plRet: Returns an error code. (Upon automation, the return value is used.)

- S_OK**: Normal termination
- EZNC_DATA_READ_ADDR**: Invalid system specification
- EZNC_DATA_READ_READ**: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Reads common variables. There is limit to the common variable number that can be handled, depending on specifications for the number of sets for common variables. For common variables #100 to #199, system specification is necessary.

□ **Reference** **CommonVWrite(), GetSize()**

□ **Specification** ([System] common variables #100 to #199 only)

2.12.2 IEZNCCommonVariable2::CommonVWrite

Write common variables

□ Custom call procedure

```

HRESULT CommonVWrite(
    LONG lIndex,           // (I) Variable number
    DOUBLE dData,         // (I) Variable value
    LONG lType,           // (I) Type
    LONG* plRet            // (O) Error code
)

```

□ Automation call procedure

```

CommonVariable_Write2(
    lIndex As LONG         // (I) Variable number
    dData As DOUBLE       // (I) Variable value
    lType As LONG         // (I) Type
) As LONG                 // (O) Error code

```

□ *lIndex*: Set the common variable number to be written.

Argument

Value:

(For C70)

100 to 199, 500 to 999

(For M700/M800 series)

100 to 199, 400 to 999, 100100 to 100199, 200100 to 200199, 300100 to 300199

400100 to 400199, 500100 to 500199, 600100 to 600199

700100 to 700199, 800100 to 800199, 900000 to 907399

dData: Sets the common variable value to be written to the set common variable number.*lType*: Specifies the type. (For the **M700/M800**, enabled.)

Value	Meaning
1	Numerical value
0	Not set

plRet: Returns an error code. (Upon automation, the return value is used.)**S_OK**: Normal termination**EZNC_DATA_WRITE_ADDR**: Invalid part system setting**EZNC_DATA_WRITE_WRITE**: Data is not writable

□ Return value

Value

Meaning

S_OK

Normal termination

S_FALSE

Communication failure

□ Function

Writes common variables. There is limit to the common variable number that can be handled, depending on specifications for the number of sets for common variables. For common variables #100 to #199, part system setting is necessary.

□ Reference

CommonVRead(), **GetSize()**

□ Specification

([System] common variables #100 to #199 only)

2.12.3 IEZNCCommonVariable2::GetSize

Get number of sets for
common variables

□ Custom call procedure

```

HRESULT      GetSize(
                LONG IType,           // (I) Common variable type
                LONG* pIData,       // (O) Number of sets
                LONG* pIRet         // (O) Error code
                )

```

□ Automation call procedure

```

CommonVariable_GetSize(
    IType As LONG           // (I) Common variable type
    pIData As LONG*        // (O) Number of sets
    ) As LONG               // (O) Error code

```

□ *IType*: Specifies the common variable type to be read.

Argument	Value	Meaning
	0	When the number of sets of common variables #100 and greater is got.
	1	When the number of sets of common variables #500 and greater is got.

pIData: Returns the number of sets of common variable type.
Value meaning: 40 = 40 [sets]

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Reads the number of sets of common variables. For common variables #100 to #199, part system setting is necessary.

□ **Reference** **CommonVRead(), CommonVWrite()**

□ **Specification** ([System] common variables #100 to #199 only)

2.12.4 IEZNCCommonVariable2::GetName

Get names of common variables

□ Custom call procedure

```

HRESULT      GetName(
                LONG Index,                // (I) Common variable number
                LPOLESTR* lppwszName,     // (O) Common variable name character string
                LONG* pRet                 // (O) Error code
            )

```

□ Automation call procedure

```

CommonVariable_GetName(
    Index As LONG                // (I) Common variable number
    lppwszName As STRING*       // (O) Common variable name character string
) As LONG                       // (O) Error code

```

□ *Index*: Sets the common variable number to be read.

Argument Value:
 (For M700 series and C70)
 500 to 519
 (For M800 series)
 500 to 599

lppwszName: Returns the common variable name as a **UNICODE** character string. Names are seven alphanumeric characters starting with an alphabet letter. The character string ends with a **NULL** code.

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_DATASIZE: Exceeded maximum data size

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Reads common variable names. Names are seven alphanumeric characters starting with an alphabet letter. The character string ends with a **NULL** code. As the character string area memory is allocated in this product, the client using VC++ needs to release the character string area memory explicitly with **CoTaskMemFree()**.

□ **Reference** **CommonVRead(), CommonVWrite()**

□ **Specification**

2.12.5 IEZNCCommonVariable2::SetName

Set name settings for
common variables

□ Custom call procedure

```

HRESULT      SetName(
                LONG Index,                // (I) Common variable number
                LPCOLESTR lpcwszName,      // (I) Common variable name character string
                LONG* plRet                // (O) Error code
            )

```

□ Automation call procedure

```

CommonVariable_SetName(
    Index As LONG                // (I) Common variable number
    lpcwszName As STRING          // (I) Common variable name character string
) As LONG                        // (O) Error code

```

□ *Index*: Sets the common variable number to be written.

Argument Value:
 (For M700 series and C70)
 500 to 519
 (For M800 series)
 500 to 599

lpcwszName: Set the common variable name as a **UNICODE** character string.
 Names are seven alphanumeric characters starting with an alphabet letter. The
 character string ends with a **NULL** code.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Writes common variable names. Names are seven alphanumeric characters starting with an alphabet letter. The character string ends with a **NULL** code.

□ **Reference** **GetName()**

□ **Specifica-
tion**

2.12.6 IEZNCCommonVariable2::GetCVNullData

Get value when no numerical
value is set

□ Custom call procedure

```

HRESULT      GetCVNullData(
                DOUBLE* pdData,      // (O) Value when no numerical value is set
                LONG*  plRet         // (O) Error code
            )

```

□ Automation call procedure

```

CommonVariable_GetNullData(
    pdData As DOUBLE* // (O) Value when no numerical value is set
) As LONG             // (O) Error code

```

□ **Argument** *pdData*: Returns the value when no numerical value is set.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
-----------------------	-------	---------

	S_OK	Normal termination
--	-------------	--------------------

	S_FALSE	Communication failure
--	----------------	-----------------------

□ **Function** Gets the value when no numerical value of variable (#100 to 199, #500 to 519) is set.

□ **Reference**

□ **Specifica-
tion**

2.13.1 IEZNCLocalVariable2::LocalVRead **Read local variable**

□ Custom call procedure

```
HRESULT LocalVRead(
    LONG lIndex,           // (I) Variable number
    LONG lLevel,          // (I) Level
    DOUBLE* pdData,       // (O) Variable value
    LONG* plType           // (O) Type
    LONG* plRet            // (O) Error code
)
```

□ Automation call procedure

```
LocalVariable_Read2(
    lIndex As LONG         // (I) Variable number
    lLevel As LONG         // (I) Level
    pdData As DOUBLE*     // (O) Variable value
    plType As LONG*       // (O) Type
) As LONG                 // (O) Error code
```

□ **Argument** *lIndex*: Sets the common variable number to be read.
Value: 1 to 33

lLevel: Sets the macro subprogram execution level.
Value: 0 to 4

pdData: Returns the local variable value of the set local variable number of the set system.

plType: Returns the type. (Unused)

Value	Meaning
1	Numerical value
0	Not set

plRet: Returns an error code. (Upon automation, the return value is used.)

- S_OK**: Normal termination
- EZNC_DATA_READ_ADDR**: Invalid part system setting
- EZNC_DATA_READ_READ**: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Reads the local variable value of the specified system.

□ **Reference** **GetMacroLevel()**

□ **Specification** System

2.13.2 IEZNCLocalVariable2::GetMacroLevel

Get macro subprogram call level

□ Custom call procedure

```

HRESULT      GetMacroLevel(
                LONG* pData,           // (O) Level
                LONG* pRet            // (O) Error code
            )

```

□ Automation call procedure

```

LocalVariable_GetMacroLevel(
    pData As LONG           // (O) Level
) As LONG                 // (O) Error code

```

□ **Argument** *pData*: Returns the macro subprogram call level.
Value: 0 to 8

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the macro subprogram call level.

□ **Reference**

□ **Specifica-
tion** System

2.13.3 IEZNCLocalVariable2::GetLVNullData

Get value when no numerical
value is set

□ Custom call procedure

```

HRESULT      GetLVNullData(
                DOUBLE* pdData,      // (O) Value when no numerical value is set
                LONG* plRet           // (O) Error code
            )

```

□ Automation call procedure

```

LocalVariable_GetNullData(
    pdData As DOUBLE* // (O) Value when no numerical value is set
) As LONG             // (O) Error code

```

□ **Argument** *pdData*: Returns the value when no numerical value is set.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
-----------------------	-------	---------

	S_OK	Normal termination
--	-------------	--------------------

	S_FALSE	Communication failure
--	----------------	-----------------------

□ **Function** Gets the value when no numerical value of variable (#1 to 33) is set.

□ **Reference**

□ **Specifica-
tion**

2.14.1 IEZNCtool3::GetToolSetSize

Get number of sets for tool offset

```

□ Custom call procedure
HRESULT      GetToolSetSize(
                LONG* pSize,           // (O) Number of sets
                LONG* pRet            // (O) Error code
            )
□ Automation call procedure
Tool_GetToolSetSize(
    pSize As LONG*           // (O) Number of sets
) As LONG                   // (O) Error code
    
```

□ **Argument** *pSize*: Returns the number of sets for tool offset of the set part system. The number of sets is determined by NC specifications.
 Value meaning: 200 = 200 [sets]

pRet: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the number of sets for tool offset of the set part system. The number of sets is determined by NC specifications.

□ **Reference** **GetType()**

□ **Specification** System

2.14.2 IEZNCTool3::GetType

Get tool offset type

□ Custom call procedure

```

HRESULT      GetType(
                LONG* pType,           // (O) Type
                LONG* pRet            // (O) Error code
            )

```

□ Automation call procedure

```

Tool_GetType(
    pType As LONG*           // (O) Type
) As LONG                  // (O) Error code

```

□ *pType*: Returns the tool offset type of the set part system.

Argument	Value	Meaning
	1	M system type I: 1 axis compensation amount
	4	M system type II: 1 axis compensation amount with wear compensation amount
	6	L system type: 2 axes compensation amount

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the tool offset type of the set part system.

□ Reference **GetToolSetSize()**

□ **Specifica-
tion** System

2.14.3 IEZNCTool3::GetOffset

Get tool offset amount

□ Custom call procedure

```

HRESULT      GetOffset(
                LONG IType,           // (I) Tool offset type
                LONG IKind,           // (I) Offset amount type
                LONG IToolSetNo,      // (I) Tool set number
                DOUBLE* pdOffset,     // (O) Offset amount
                LONG* pINo,           // (O) Hypothetical tool nose pointnumber
                LONG* pIRet           // (O) Error code
            )

```

□ Automation call procedure

```

Tool_GetOffset(
    IType As LONG           // (I) Tool offset type
    IKind As LONG           // (I) Offset amount type
    IToolSetNo As LONG      // (I) Tool set number
    pdOffset As DOUBLE*     // (O) Offset amount
    pINo As LONG*           // (O) Hypothetical tool nose point number
) As LONG                  // (O) Error code

```

□ *IType*: Sets the tool offset type. Refer to the parameter table.

Argument

IKind: Sets the type of tool offset amount. Refer to the parameter table.

IToolSetNo: Set the tool offset set number.

The number of sets can be got with **GetToolSetSize()**.

pdOffset: Returns the tool offset amount. Refer to the parameter table.

pINo: Returns the hypothetical tool nose point number. Refer to the parameter table.
L system type only. Returns none except for the L system type.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_DATATYPE: Invalid data type

EZNC_DATA_READ_SUBSECT: Invalid subsection number

EZ_ERR_NOT_SUPPORT: Not supported

Parameter table

Value: Type	Value: Type of tool offset amount	Data range
1: M system type I	0: Tool offset amount	-99,999.999 to 99,999.999 [mm]
4: M system type II	0: Tool length compensation amount (dimensions) 1: (Wear) 2: Tool radius compensation amount (dimensions) 3: (Wear)	-99,999.999 to 99,999.999 [mm]
6: L system type	0: Tool length compensation amount X 1: Z 2: C (Y*)	C70 : -99.999 to 99.999 [mm] M700/M800 series : -99,999.999 to 99,999.999 [mm]
	3: Tool length offset amount X 4: Z 5: C (Y*)	C70 : -999.999 to 999.999 [mm] M700/M800 series : -99,999.999 to 99,999.999 [mm]
	6: Tool radius (nose R) R	C70 : 0 to 99.999 [mm] M700/M800 series : 0 to 99,999.999 [mm]
	7: Tool radius (nose R) wear amount r	C70 : 0 to 99.999 [mm] M700/M800 series : 0 to 99,999.999 [mm]
	8: Hypothetical tool nose point number P	0 to 8 (Refer to Figure 1)

* For the M700/M800 series




Figure 1 Hypothetical tool nose point number

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets the tool offset amount of the set part system/axis No. The range shown in the parameter table varies depending on the command unit such as inch system and metric system of the Mitsubishi CNC. For details, refer to the installation manual of each Mitsubishi CNC.	
□ Reference	GetType(), SetOffset(), GetToolSetSize()	
□ Specification	System	

2.14.4 IEZNCTool3::GetOffset2

Get tool offset amount

□ Custom call procedure

```

HRESULT      GetOffset2(
                LONG IType,           // (I) Tool offset type
                LONG IKind,           // (I) Offset amount type
                LONG IToolSetNo,      // (I) Tool set number
                DOUBLE* pdOffset,     // (O) Offset amount
                LONG* pINo,           // (O) Hypothetical tool nose point number
                LONG* pIRet           // (O) Error code
            )

```

□ Automation call procedure

```

Tool_GetOffset2(
    IType As LONG           // (I) Tool offset type
    IKind As LONG           // (I) Offset amount type
    IToolSetNo As LONG      // (I) Tool set number
    pdOffset As DOUBLE*    // (O) Offset amount
    pINo As LONG*          // (O) Hypothetical tool nose point number
) As LONG                  // (O) Error code

```

□ *IType*: Sets the tool offset type. Refer to the parameter table.

Argument

IKind: Sets the type of tool offset amount. Refer to the parameter table.

IToolSetNo: Sets the tool offset set number.

The number of sets can get with **GetToolSetSize()**.

pdOffset: Returns the tool offset amount. Refer to the parameter table.

pINo: Returns the Hypothetical tool nose point number. Refer to the parameter table.
L system type only. Returns none except for the L system type.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_DATATYPE: Invalid data type

EZNC_DATA_READ_SUBSECT: Invalid subsection number

Parameter table

Value: Type	Value: Type of tool offset amount	Data range
1: M system type I	0: Tool offset amount	-99,999.999 to 99,999.999 [mm]
4: M system type II	0: Tool length compensation amount (dimensions) 1: (Wear) 2: Tool radius compensation amount (dimensions) 3: (Wear)	-99,999.999 to 99,999.999 [mm]
6: L system type	0: Tool length compensation amount 1: Z 2: C (Y*)	C70 : -99.999 to 99.999 [mm] M700/M800 series : -99,999.999 to 99,999.999 [mm]
	3: Tool length offset amount X 4: Z 5: C (Y*)	C70 : -999.999 to 999.999 [mm] M700/M800 series : -99,999.999 to 99,999.999 [mm]
	6: Tool radius (nose R) R	C70 : 0 to 99.999 [mm] M700/M800 series : 0 to 99,999.999 [mm]
	7: Tool radius (nose R) wear amount r	C70 : 0 to 99.999 [mm] M700/M800 series : 0 to 99,999.999 [mm]
	8: Hypothetical tool nose point number P	0 to 8 (Refer to Figure 1)

* For the M700/M800 series




Figure 1 Hypothetical tool nose point

<input type="checkbox"/> Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
<input type="checkbox"/> Function	Gets the tool offset amount of the set part system/axis No. The range shown in the parameter table varies depending on the command unit such as inch system and metrik system of the Mitsubishi CNC. For details, refer to the installation manual of each Mitsubishi CNC.	
<input type="checkbox"/> Reference	GetType(), SetOffset(), GetToolSetSize()	
<input type="checkbox"/> Specification	System	

2.14.5 IEZNCTool3::SetOffset

Set tool offset amount
settings

□ Custom call procedure

```

HRESULT      SetOffset(
                LONG IType,           // (I) Tool offset type
                LONG IKind,           // (I) Offset amount type
                LONG IToolSetNo,      // (I) Tool set number
                DOUBLE dOffset,       // (I) Offset amount
                LONG INo,              // (I) Hypothetical tool nose point number
                LONG* pIRet            // (O) Error code
            )

```

□ Automation call procedure

```

Tool_SetOffset(
    IType As LONG           // (I) Tool offset type
    IKind As LONG           // (I) Offset amount type
    IToolSetNo As LONG      // (I) Tool set number
    dOffset As DOUBLE       // (I) Offset amount
    INo As LONG             // (I) Hypothetical tool nose point point number
) As LONG                  // (O) Error code

```

□ *IType*: Sets the tool offset type. Refer to the parameter table.

Argument

IKind: Sets the type of tool offset amount. Refer to the parameter table.

IToolSetNo: Sets the tool offset set number.

The number of sets can get with **GetToolSetSize()**.

dOffset: Sets the tool offset amount. Refer to the parameter table.

INo: Sets the hypothetical tool nose point number. Refer to the parameter table.

L system type only. Disabled for the M system type.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_WRITE_DATATYPE: Invalid data type

EZNC_DATA_WRITE_SUBSECT: Invalid subsection number

Parameter table

Value: Type	Value: Type of tool offset amount	Data range
1: M system type I	0: Tool offset amount	-99,999.999 to 99,999.999 [mm]
4: M system type II	0: Tool length compensation amount (dimensions) 1: (Wear) 2: Tool radius compensation amount (dimensions) 3: (Wear)	-99,999.999 to 99,999.999 [mm]
6: L system type	0: Tool length compensation amount X	C70 : -99.999 to 99.999 [mm] M700/M800 series : -99,999.999 to 99,999.999 [mm]
	1: Z	
	2: C (Y*)	
	3: Tool length offset amount X	C70 : -999.999 to 999.999 [mm] M700/M800 series : -99,999.999 to 99,999.999 [mm]
	4: Z	
	5: C (Y*)	
	6: Tool radius (nose R) R	C70 : 0 to 99.999 [mm] M700/M800 series : 0 to 99,999.999 [mm]
	7: Tool radius (nose R) wear amount r	C70 : 0 to 99.999 [mm] M700/M800 series : 0 to 99,999.999 [mm]
	8: Hypothetical tool nose point number P	0 to 8 (Refer to Figure 1)

* For the M700/M800 series




Figure 1 Hypothetical tool nose point number

□ Return value	Value	Meaning
	S_OK S_FALSE	Normal termination Communication failure
□ Function	Configures the tool offset amount of the set part system/axis No. The range shown in the parameter table varies depending on the command unit such as inch system and metrik system of the Mitsubishi CNC. For details, refer to the installation manual of each Mitsubishi CNC.	
□ Reference	GetType(), GetOffset(), GetToolSetSize()	
□ Specification	System	

2.14.6 IEZNCTool3::GetToolWorkOffset

Get workpiece coordinate
offset

□ Custom call procedure

```

HRESULT      GetToolWorkOffset(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Workpiece coordinate system number
                DOUBLE* pdOffset,      // (O) Offset value
                LONG* pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

Tool_GetToolWorkOffset(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Workpiece coordinate system number
    pdOffset As DOUBLE*      // (O) Offset value
) As LONG                   // (O) Error code

```

□ *IAxisNo*: Sets the axis. (From Axis 1 = from 1)

□ Argument

IIndex: Sets the workpiece coordinate system number to be read.

Value	Meaning
54	G54 offset
55	G55 offset
56	G56 offset
57	G57 offset
58	G58 offset
59	G59 offset
60	EXT offset

pdOffset: Returns the offset value of the workpiece coordinate of the set part system/axis No.
Value: -99,999.999~99,999.999 [mm]

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination
EZNC_DATA_READ_ADDR: Invalid part system setting
EZNC_DATA_READ_READ: Data is not readable
EZNC_DATA_READ_AXIS: Invalid axis No. setting
EZ_ERR_NOT_SUPPORT: Not supported

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Gets the offset value of the workpiece coordinate of the set part system/axis No. For details, refer to the installation guide.
Refer to the instruction manual for each numerical controller for details.

□ Reference

□ **Specifica-
tion** [System], [Axis number]

2.14.7 IEZNCTool3::GetToolWorkOffset2

Get workpiece coordinate
offset

□ Custom call procedure

```

HRESULT      GetToolWorkOffset2(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Workpiece coordinate system number
                DOUBLE* pdOffset,      // (O) Offset value
                LONG* pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

Tool_GetToolWorkOffset2(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Workpiece coordinate system number
    pdOffset As DOUBLE*      // (O) Offset value
) As LONG                   // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ Argument

IIndex: Sets the workpiece coordinate system number to be read.

Value	Meaning
54	G54 offset
55	G55 offset
56	G56 offset
57	G57 offset
58	G58 offset
59	G59 offset
60	EXT offset

pdOffset: Returns the offset value of the workpiece coordinate of the set part system/axis No.
Value: -99,999.999~99,999.999 [mm]

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_AXIS: Invalid axis No. setting

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the offset value of the workpiece coordinate of the set part system/axis No. For details, refer to the installation guide.

Refer to the instruction manual for each numerical controller for details.

Setting mode

(1) For setting absolute value,

Sets the set offset value as the current offset value.

(2) For setting additional value,

Sets the offset value got by adding the set offset value to the current offset value.

□ **Reference**

□ **Specifica-
tion** [System], [Axis number]

2.14.8 IEZNCtool3:: SetToolWorkOffset

Set workpiece coordinate
offset settings

□ Custom call procedure

```

HRESULT      SetToolWorkOffset(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Workpiece coordinate system number
                DOUBLE dOffset,        // (I) Offset value
                LONG IMode,            // (I) Mode
                LONG* pIRet            // (O) Error code
            )

```

□ Automation call procedure

```

Tool_SetToolWorkOffset(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Workpiece coordinate system number
    dOffset As DOUBLE        // (I) Offset value
    IMode As LONG           // (I) Mode
) As LONG                   // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

IIndex: Sets the workpiece coordinate system number to be read.

Value	Meaning
54	G54 offset
55	G55 offset
56	G56 offset
57	G57 offset
58	G58 offset
59	G59 offset
60	EXT offset

dOffset: Sets the offset value of the workpiece coordinate of the set part system/axis No.
Value: -99,999.999~99,999.999 [mm]

IMode: Sets the setting mode (absolute value setting/additional value setting).

Value	Meaning
0	Sets absolute value
1	Sets additional value

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_ADDR: Invalid part system setting

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_WRITE_AXIS: Invalid axis No. setting

□ Return
value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Sets the offset value of the workpiece coordinate of the set part system/axis No.
For details, refer to the instruction manual for each Mitsubishi CNC.

Setting mode

(1) For setting absolute value,

Sets the set offset value as the current offset value.

(2) For setting additional value,

Sets the offset value got by adding the set offset value to the current offset value.

□ **Reference**

□ **Specifica-
tion** [System], [Axis number]

2.14.9 IEZNCtool3:: SetToolWorkOffset9

Set workpiece coordinate
offset settings

□ Custom call procedure

```

HRESULT      SetToolWorkOffset2(
                LONG IAxisNo,           // (I) Axis No.
                LONG IIndex,           // (I) Workpiece coordinate system number
                DOUBLE dOffset,        // (I) Offset value
                LONG IMode,            // (I) Mode
                LONG* pIRet            // (O) Error code
            )

```

□ Automation call procedure

```

Tool_SetToolWorkOffset2(
    IAxisNo As LONG           // (I) Axis No.
    IIndex As LONG           // (I) Workpiece coordinate system number
    dOffset As DOUBLE        // (I) Offset value
    IMode As LONG           // (I) Mode
) As LONG                   // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

IIndex: Sets the workpiece coordinate system number to be read.

Value	Meaning
54	G54 offset
55	G55 offset
56	G56 offset
57	G57 offset
58	G58 offset
59	G59 offset
60	EXT offset

dOffset: Sets the offset value of the workpiece coordinate of the set part system/axis No.
Value: -99,999.999~99,999.999 [mm]

IMode: Sets the setting mode (absolute value setting/additional value setting).

Value	Meaning
0	Sets absolute value
1	Sets additional value

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_ADDR: Invalid part system setting

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_WRITE_AXIS: Invalid axisNo. setting

□ Return
value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Configures the offset value of the workpiece coordinate of the set part system/axis No.
Refer to the instruction manual for each Mitsubishi CNC for details.

Setting mode

(1) For setting absolute value,

Sets the set offset value as the current offset value.

(2) For setting additional value,

Sets the offset value got by adding the set offset value to the current offset value.

□ **Reference**

□ **Specifica-
tion** [System], [Axis number]

2.14.10 IEZNCTool3::GetSurface**Get reference surface height**□ **Custom call procedure**

```

HRESULT GetSurface(
    LONG IAxisNo,           // (I) Axis No.
    DOUBLE* pdHight,      // (O) Reference surface height
    LONG* pIRet            // (O) Error code
)

```

□ **Automation call procedure**

```

Tool_GetSurface(
    IAxisNo As LONG        // (I) Axis No.
    pdHight As DOUBLE*    // (O) Reference surface height
) As LONG                // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

pdHight: Returns the reference surface coordinate position of the tool length measurement II of the set part system/axis No.

Value: -99999.999 to 99999.999 [mm]

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_AXIS: Invalid axis No. setting

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the reference surface coordinate position of the tool length measurement II of the set part system/axis No.

□ **Reference**

□ **Specification** System, Axis number

2.14.11 IEZNCTool3::GetSurface2

Get reference surface height

□ Custom call procedure

```

HRESULT GetSurface2(
    LONG IAxisNo,           // (I) Axis No.
    DOUBLE* pdHight,       // (O) Reference surface height
    LONG* pIRet            // (O) Error code
)

```

□ Automation call procedure

```

Tool_GetSurface2(
    IAxisNo As LONG        // (I) Axis No.
    pdHight As DOUBLE*    // (O) Reference surface height
) As LONG                 // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

Argument

pdHight: Returns the reference surface coordinate position of the tool length measurement II of the set part system/axis No.

Value: -99,999.999 to 99,999.999 [mm]

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting

EZNC_DATA_READ_AXIS: Invalid axis No. setting

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
Function	Gets the reference surface coordinate position of the tool length measurement II of the set axis No. of the set part system.	

□ Reference

□ Specification ,

2.14.12 IEZNCtool3::SetSurface

Set reference surface height settings

□ Custom call procedure

```

HRESULT      SetSurface(
                LONG IAxisNo,           // (I) Axis No.
                DOUBLE dHight,         // (I) Reference surface height
                LONG* pIRet             // (O) Error code
            )

```

□ Automation call procedure

```

Tool_SetSurface(
    IAxisNo As LONG           // (I) Axis No.
    dHight As DOUBLE*        // (O) Reference surface height
) As LONG                    // (O) Error code

```

□ *IAxisNo*: Sets the axis No. (From Axis 1 = from 1)

□ Argument

dHight: Sets the reference surface coordinate position of the tool length measurement II of the set part system/axis No.

Value: -99999.999 to 99999.999 [mm]

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_WRITE_ADDR: Invalid part system, axis No. setting

EZNC_DATA_WRITE_AXIS: Invalid axis No. setting

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets the reference surface coordinate position of the tool length measurement II of the set part system/axis No.

□ Reference

□ **Specification** System, Axis number

2.14.13 IEZNCTool3::GetToolLifeType2

Get tool life management
method

□ Custom call procedure

```

HRESULT      GetToolLifeType2(
                LONG* pType,           // (O) Tool life management method
                LONG* pRet             // (O) Error code
            )

```

□ Automation call procedure

```

Tool_GetToolLifeType2(
    pType As LONG*           // (O) Tool life management method
) As LONG                  // (O) Error code

```

□ *pType*: Returns the tool life control type.

Argument	Value	Meaning
	0	Disabled
	1	Type I
	2	Type II

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_DATA_RANGE: Invalid argument data range

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ Gets tool life management method.

□ Function

□ **SetToolLifeType2()**

□ Reference

□ Specifica-
tion

2.14.14 IEZNCtool3::SetToolLifeType2

Select Tool life management
method

□ Custom call procedure

```

HRESULT      SetToolLifeType2(
                LONG IType,           // (I) Tool life management method
                LONG* pIRet          // (O) Error code
            )

```

□ Automation call procedure

```

Tool_SetToolLifeType2(
    IType As LONG           // (O) Tool life management method
) As LONG                  // (O) Error code

```

□ *IType*: Sets the tool life management method.

Argument	Value	Meaning
	0	Disabled (For the C70, cannot be specified.)
	1	Tool life management I
	2	Tool life management II

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZ_ERR_DATA_RANGE: Invalid argument data range

EZ_ERR_DATA_TYPE: Invalid argument data type

EZ_ERR_NOT_SUPPORT: Not supported

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Selects tool life management I or II. Write is inhibited by password mode. (**EZNC_DATA_WRITE_WRITE** is returned.)

□ **Reference** **GetToolLifeType2()**

□ **Specifica-
tion**

2.14.15 IEZNCtool3::GetToolLifeGroupList

Get Tool Life management group No
list

□ Custom call procedure

```

HRESULT      GetToolLifeGroupList (
                LPDWORD lpdwLength,           // (O) Number of groups
                LPDWORD* lppdwGroup,         // (O) Array of group numbers
                LONG* plRet                   // (O) Error code
                )

```

□ Automation call procedure

```

Tool_GetToolLifeGroupList(
    pvGroup As VARIANT*           // (O) Group number
) As LONG                          // (O) Error code

```

□ **Argument** *lpdwLength*: Returns the number of sets of groups.

lppdwGroup: Returns the list of group numbers as an array. As the group number array is allocated in this product, the client needs to release it explicitly with **CoTaskMemFree()**.

Automation argument:

pvGroup: Returns the group number array as **VARIANT**.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_MEMORY_ALLOC: Memory cannot be allocated.

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
-----------------------	-------	---------

	S_OK	Normal termination
--	-------------	--------------------

	S_FALSE	Communication failure
--	----------------	-----------------------

□ **Function** Gets tool life management group No.

□ **Reference** **AddToolLifeGroup(), ChangeToolLifeGroup(), DeleteToolLifeGroup()**

□ **Specifica-
tion** System (M700/M800 series only)

2.14.16 IEZNCtool3::ChangeToolLifeGroup

Change tool life management
group No

□ Custom call procedure

```

HRESULT      ChangeToolLifeGroup (
                DWORD dwSrcGroup,    // (I) Old group number
                DWORD dwDstGroup,    // (I) New group number
                LONG* plRet          // (O) Error code
                )

```

□ Automation call procedure

```

Tool_ChangeToolLifeGroup(
    ISrcGroup As LONG      // (I) Old group number
    IDstGroup As LONG      // (I) New group number
    ) As LONG                // (O) Error code

```

□ **Argument** *dwSrcGroup*: Sets the old group number.

dwDstGroup: Sets the new group number.

Automation argument:

ISrcGroup: Refer to the explanation of *dwSrcGroup*.

IDstGroup: Refer to the explanation of *dwDstGroup*.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable.

EZNC_DATA_NOT_EXIST: Data does not exist

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_EXIST: Group number already exists

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Changes the set group number to the new group number.
The set old group tool is changed to the new group.

□ **Reference** **GetToolLifeGroupList(), AddToolLifeGroup(), DeleteToolLifeGroup()**

□ **Specifica-
tion** System (M700/M800 series only)

2.14.17 IEZNCtool3::DeleteToolLifeGroup

Delete tool life management
group No

□ Custom call procedure

```

HRESULT DeleteToolLifeGroup (
    DWORD dwGroup, // (I) Group number
    LONG* pIRet    // (O) Error code
)

```

□ Automation call procedure

```

Tool_DeleteToolLifeGroup(
    IGroup As LONG // (I) Group number
) As LONG          // (O) Error code

```

□ **Argument** *dwGroup*: Sets the group number to be deleted.

Automation argument:

IGroup: Refer to the explanation of *dwGroup*.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable.

EZNC_DATA_NOT_EXIST: Data does not exist

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_READ_ADDR: Invalid part system setting

EZNC_DATA_TLFGROUP_ADDR: Invalid address (part system setting)

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Deletes the group number.

□ **Reference** **GetToolLifeGroupList(), AddToolLifeGroup(), ChangeToolLifeGroup()**

□ **Specification** System

2.14.18 IEZNCtool3::GetToolLifeToolNoList

Get list of tool numbers within Life management group

□ Custom call procedure

```

HRESULT      GetToolLifeToolNoList (
                DWORD dwGroup,           // (I) Group number
                LPDWORD lpdwLength,     // (O) Number of registered tools
                LPDWORD *lppdwToolNo,   // (O) Array of tool numbers
                LONG* pRet              // (O) Error code
                )

```

□ Automation call procedure

```

Tool_ GetToolLifeToolNoList (
        IGroup As LONG                // (I) Group number
        pvToolNo As VARIANT         // (O) Array of tool numbers
        ) As LONG                     // (O) Error code

```

□ **Argument** *dwGroup*: Sets the group number for which the list of tool numbers is got.

lpdwLength: Returns the number of registered tools included in the group (array length of the list of tool numbers).

lppdwToolNo: Returns the list of tool numbers included in the group as an array. As the tool number list array is allocated in this product, the client needs to release it explicitly with **CoTaskMemFree()**.

Automation argument:

IGroup: Refer to the explanation of *dwGroup*.

pvToolNo: Returns the list of tool numbers included in the group as VARIANT.

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_MEMORY_ALLOC: Memory cannot be allocated

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the list of tool numbers of the set group.

□ **Reference** **AddToolLifeToolNo(), ChangeToolLifeToolNo(), DeleteToolLifeToolNo()**

□ **Specification** System

2.14.19 IEZNCtool3::AddToolLifeToolNo

Add tool number to tool life management group No

□ Custom call procedure

```

HRESULT      AddToolLifeToolNo (
                    DWORD dwGroup,           // (I) Group number
                    DWORD dwToolNo,        // (I) Tool number
                    LONG* plRet           // (O) Error code
                )

```

□ Automation call procedure

```

Tool_AddToolLifeToolNo (
    IGroup As LONG           // (I) Group number
    IToolNo As LONG        // (I) Tool number
    ) As LONG                // (O) Error code

```

□ **Argument** *dwGroup*: Sets the group numbers to which tool numbers are added.

dwToolNo: Sets the tool numbers to be added.

Automation argument:

IGroup: Refer to the explanation of *dwGroup*.

IToolNo: Refer to the explanation of *dwToolNo*.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_DUPLICATE: Duplicated numbers

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZNC_DATA_TLFTOOL_EXIST: Tool number already exists

EZNC_DATA_TLFTOOL_OUTOFSPEC: Set tool number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Adds the tool numbers to the specified group.

□ **Reference** **GetToolLifeToolNoList(), ChangeToolLifeToolNo(), DeleteToolLifeToolNo()**

□ **Specifica-
tion** System

2.14.20 IEZNCtool3::ChangeToolLifeToolNo

Change tool life management
group No

□ Custom call procedure

```

HRESULT      ChangeToolLifeToolNo(
                DWORD dwGroup,           // (I) Group number
                DWORD dwSrcToolNo,      // (I) Old tool number
                DWORD dwDstToolNo,      // (I) New tool number
                LONG* plRet             // (O) Error code
                )

```

□ Automation call procedure

```

Tool_ChangeToolLifeToolNo (
    IGroup As LONG           // (I) Group number
    ISrcToolNo As LONG       // (I) Old tool number
    IDstToolNo As LONG       // (I) New tool number
    ) As LONG                 // (O) Error code

```

□ **Argument** *dwGroup*: Sets the group number in which the tool number is changed.

dwSrcToolNo: Sets the old tool number.

dwDstToolNo: Sets the new tool number.

Automation argument:

IGroup: Refer to the explanation of *dwGroup*.

ISrcToolNo: Refer to the explanation of *dwSrcToolNo*.

IDstToolNo: Refer to the explanation of *dwDstToolNo*.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_NOT_EXIST: Data does not exist

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZNC_DATA_TLFTOOL_EXIST: Tool number already exists

EZNC_DATA_TLFTOOL_NONEXIST: Tool number does not exist

EZNC_DATA_TLFTOOL_OUTOFSPEC: Set tool number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Changes the set tool number to the new tool number.

□ **Reference** **GetToolLifeToolNoList(), AddToolLifeToolNo(), DeleteToolLifeToolNo()**

□ **Specifica-
tion** System

2.14.21 IEZNCtool3::DeleteToolLifeToolNo

Delete tool life management
tool number

□ Custom call procedure

```

HRESULT DeleteToolLifeToolNo (
    DWORD dwGroup,           // (I) Group number
    DWORD dwToolNo,         // (I) Tool number
    LONG* plRet              // (O) Error code
)

```

□ Automation call procedure

```

Tool_ DeleteToolLifeToolNo (
    IGroup As LONG           // (I) Group number
    IToolNo As LONG         // (I) Tool number
) As LONG                  // (O) Error code

```

□ **Argument** *dwGroup*: Sets the group number from which tool numbers are deleted.

dwToolNo: Sets the tool numbers to be deleted.

Automation argument:

*I*Group: Refer to the explanation of *dwGroup*.

*I*ToolNo: Refer to the explanation of *dwToolNo*.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_NOT_EXIST: Data does not exist

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZNC_DATA_TLFTOOL_NONEXIST: Tool number does not exist

EZNC_DATA_TLFTOOL_OUTOFSPEC: Set tool number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Deletes the set tool numbers.

□ **Reference** **GetToolLifeToolNoList(), AddToolLifeToolNo(), ChangeToolLifeToolNo()**

□ **Specifica-
tion** System

2.14.22 IEZNCTool3::GetToolLifeValue

Get tool life management data

□ Custom call procedure

```

HRESULT GetToolLifeValue (
    DWORD dwGroup,           // (I) Group number
    DWORD dwToolNo,         // (I) Tool number
    LPOLESTR** lpppszData,  // (O) Tool life management data value
                             // character string array
    LONG* plRet              // (O) Error code
)

```

□ Automation call procedure

```

Tool_GetToolLifeValue (
    IGroup As LONG           // (I) Group number
    IToolNo As LONG         // (I) Tool number
    pvData As VARIANT*      // (O) Tool life management data value
                             // character string
) As LONG                   // (O) Error code

```

□ *dwGroup*: Sets the group number for which tool life is got.

Argument

dwToolNo: Sets the tool number for which tool life is got.

lpppszData: Returns the life management data value as a **UNICODE** character string array. As the data value array is allocated in this product, the client needs to release it explicitly with **CoTaskMemFree ()**. Refer to the index table.

Automation argument:

IGroup: Refer to the explanation of *dwGroup*.

IToolNo: Refer to the explanation of *dwToolNo*.

pvData: Returns the life control data value (UNICODE character string) array as VARIANT. For life control data values, refer to the index.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZNC_DATA_NOT_EXIST: Data does not exist

EZ_ERR_MEMORY_ALLOC: Memory cannot be allocated

EZ_ERR_DATA_RANGE: Invalid argument data range

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZNC_DATA_TLFTOOL_NONEXIST: Tool number does not exist

EZNC_DATA_TLFTOOL_OUTOFSPEC: Set tool number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

Index table

Array Index	Tool life type (data range)	
	C70 M system	M700/M800 series M system
0	Tool number (1 to 99999999)	Tool number (1 to 99999999)
1	Status (depends on MTB specifications)	Status (0x00 to 0xFF)
2	Method (000 to 222)*	Method (000 to 222)*
3	Length dimension (± 1 to 99999.999)	Length dimension (± 9999.999)
4	Radius dimension (± 1 to 99999.999)	Radius dimension (± 9999.999)
5	Life (Time: 0 to 4000, Count: 0 to 65000)	Life (Time: 0 to 4000, Count: 0 to 65000)
6	Used (Time: 0 to 4000, Count: 0 to 65000)	Used (Time: 0 to 4000, Count: 0 to 65000)
7	Auxiliary (0 to 65535, depends on MTB specifications)	Auxiliary (0 to 65535, depends on MTB specifications)
8	Length wear (Reserved: 0)	Length wear (Reserved: 0)
9	Radius wear (Reserved: 0)	Radius wear (Reserved: 0)
10	Group (1 to 99999999)	Group (1 to 99999999)
Array Index	Tool life type (data range)	
	M700/M800 series L system (TYPE I), C70 L system (TYPE I)	M700/M800 series L system (TYPE II)
0	Application of time management (0 to 995959)	Tool number (1 to 999999)
1	Application of number of times management (0 to 9999)	Compensation number (0 to 80)
2	Status A (0 to 2)	Usage (Time: 0 to 99999999, Count: 0 to 999999)
3	Life of time management (0 to 995959)	ST (0 to 3)
4	Life of count management (0 to 9999)	Method (Time: 0, Count: 1)
5	Status B (depends on MTB specifications)	Life (0 to 999999)
6 to 10	-	-
Array Index	Tool life type (data range)	
	C70 L system (TYPE II)	
0	Tool number (1 to 999999)	
1	Group (1 to 9999)	
2	Method (0: Time, 1: Count)	
3	Compensation number (1 to 80)	
4	Status (0 to 3)	
5	Life (Time: 0 to 999999, Count: 0 to 999999)	
6	Used (Time: 0 to 999999, Count: 0 to 999999)	
7 to 10	-	

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets life control data for the set tool number. Note that the number of elements of the character string array that returns life control data varies depending on models. * For the "method" for tool life management data, refer to the installation manual of each Mitsubishi CNC.	
□ Reference	SetToolLifeValue()	
□ Specification	System	

2.14.23 IEZNCtool3::SetToolLifeValue

Set individual tool life management data

□ Custom call procedure

```

HRESULT      SetToolLifeValue (
                DWORD dwGroup,           // (I) Group number
                DWORD dwToolNo,        // (I) Tool number
                DWORD dwKind,          // (I) Type of tool life management data
                LPCOLESTR lpcwszData, // (I) Tool life management
                LONG* plRet           // (O) Error code
                )

```

□ Automation call procedure

```

Tool_ SetToolLifeValue (
        IGroup As LONG           // (I) Group number
        IToolNo As LONG         // (I) Tool number
        IKind As LONG          // (I) Type of tool life management I data
        lpcwszData As STRING // (I) Tool life management data
        ) As LONG               // (O) Error code

```

□ *dwGroup*: Sets the group number for which tool life is set.

Argument

dwToolNo: Sets the tool number for which tool life is set.

dwKind: Sets the type of tool life. Refer to the parameter table.

lpcwszData: Sets the specified type of life data.

Automation argument:

IGroup: Refer to the explanation of *dwGroup*.

IToolNo: Refer to the explanation of *dwToolNo*.

IKind: Refer to the explanation of *dwKind*.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_NOT_EXIST: Data does not exist

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_DATA_RANGE: Invalid argument data range (*dwKind*)

EZ_ERR_DATA_TYPE: Invalid argument data type

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZNC_DATA_TLFTOOL_NONEXIST: Tool number does not exist

EZNC_DATA_TLFTOOL_PARAMERR: Invalid type specified for life control data

EZNC_DATA_TLFTOOL_MAXMINERR: Setting data is out of range

EZNC_DATA_TLFTOOL_OUTOFSPEC: Set tool number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

Parameter table

Value	Tool life type (data range)	
	C70 M system	M700/M800 series M system
1	Tool number (1 to 99999999)	Tool number (1 to 99999999)
2	Status (depends on machine manufacturer specifications)	Status (0x00 to 0xFF)
3	Method (000 to 222)*	Method (000 to 222)*
4	Length dimension (± 99999.999)	Length dimension (± 9999.999)*
5	Radius dimension (± 99999.999)	Radius dimension (± 9999.999)*
6	Life (Time: 0 to 4000, Count: 0 to 9999)	Life (Time: 0 to 4000, Count: 0 to 9999/65000)
7	Used (Time: 0 to 4000, Count: 0 to 9999)	Used (Time: 0 to 4000, Count: 0 to 9999/65000)
8	Auxiliary (0 to 65535, depends on MTB specifications)	Auxiliary (0 to 65535, depends on MTB specifications)
9	Length wear (Reserved: 0)	Length wear (Reserved: 0)
10	Radius wear (Reserved: 0)	Radius wear (Reserved: 0)
11	Group (1 to 99999999)	Group (1 to 99999999)

Value	Tool life type (data range)	
	M700/M800 series L system (TYPE I), C70 L system (TYPE I)	M700/M800 series L system (TYPE II)
1	Application of time management (0 to 995959)	Tool number (1 to 999999)
2	Application of count management (0 to 9999)	Compensation number (0 to 80)
3	Status A (0 to 2)	Used (Time: 0 to 99999999, Count: 0 to 999999)
4	Life of time management (0 to 995959)	ST (0 to 3)
5	Life of count management (0 to 9999)	Method (Time: 0, Count: 1)
6	Status B (depends on MTB specifications)	Life (0 to 999999)

Value	Tool life type (data range)	
	C70 L system (TYPE II)	
1	Tool number (1 to 999999)	
2	Group (1 to 9999)	
3	Method (0: Time, 1: Count)	
4	Compensation number (1 to 80)	
5	Status (0 to 3)	
6	Life (Time: 0 to 999999, Count: 0 to 999999)	
7	Used (Time: 0 to 999999, Count: 0 to 999999)	

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Individually sets life control data for the set tool number. This method is used for updating. To newly add a tool, use the following procedure.

- 1) AddToolLifeGroup()
- 2) AddToolLifeToolNo()
- 3) SetToolLifeValue()

* For the "method" for tool life management data, refer to the installation guide of each Mitsubishi CNC.

□ **Reference** **GetToolLifeValue(), AddToolLifeGroup(), AddToolLifeToolNo()**

□ **Specification** System

2.14.24 IEZNCtool3::SetToolLifeValue2

Set tool life management data

□ Custom call procedure

```

HRESULT SetToolLifeValue2 (
    DWORD dwGroup,           // (I) Group number
    DWORD dwToolNo,         // (I) Tool number
    LPCOLESTR* lppcwszData, // (I) Tool life management data character
                           // string array
    LONG* plRet              // (O) Error code
)

```

□ Automation call procedure

```

Tool_ SetToolLifeValue2 (
    IGroup As LONG           // (I) Group number
    IToolNo As LONG         // (I) Tool number
    vData As VARIANT        // (I) Tool life management data character
                           // string array
) As LONG                   // (O) Error code

```

□ *DwGroup*: Sets the group number for which tool life is set.

Argument

dwToolNo: Sets the tool number for which tool life is set.

lppcwszData: Sets a **UNICODE** character string array for the set type of life data.

Automation argument:

IGroup: Refer to the explanation of *dwGroup*.

IToolNo: Refer to the explanation of *dwToolNo*.

vData: Creates a **UNICODE** character string array for the specified type of life data and sets by substituting it in *vData* (VARIANT type). For examples of substitution, refer to " 2.11.13 WriteFile".

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZNC_DATA_NOT_EXIST: Data does not exist

EZ_ERR_DATA_RANGE: Invalid argument data range (*dwGroup*, *dwToolNo*)

EZ_ERR_NULLPTR: Argument is NULL pointer

EZNC_DATA_TLFGROUP_ADDR: Invalid address (system specification)

EZNC_DATA_TLFGROUP_NONEXIST: Group number does not exist

EZNC_DATA_TLFGROUP_OUTOFSPEC: The set group number is out of specifications

EZNC_DATA_TLFTOOL_NONEXIST: Tool number does not exist

EZNC_DATA_TLFTOOL_MAXMINERR: Setting data is out of range

EZNC_DATA_TLFTOOL_OUTOFSPEC: Set tool number is out of specifications

EZ_ERR_NOT_SUPPORT: Not supported

Parameter table

Array Index	Tool life type (data range)	
	C70 M system	M700/M800 series M system
0	Tool number (1 to 99999999)	Tool number (Reserved: 0)
1	Status (depends on MTB specifications)	Status (0x00 to 0xFF)
2	Method (000 to 222)*	Method (000 to 222)*
3	Length dimension (± 99999.999)	Length dimension (± 9999.999)*
4	Radius dimension (± 99999.999)	Radius dimension (± 9999.999)*
5	Life (Time: 0 to 4000, Count: 0 to 9999)	Life (Time: 0 to 4000, Count: 0 to 65000)
6	Used (Time: 0 to 4000, Count: 0 to 9999)	Usage (Time: 0 to 4000, Count: 0 to 65000)
7	Auxiliary (0 to 65535, depends on MTB specifications)	Auxiliary (0 to 65535, depends on MTB specifications)
8	Length wear (Reserved: 0)	Length wear (Reserved: 0)
9	Radius wear (Reserved: 0)	Radius wear (Reserved: 0)
10	Group (1 to 99999999)	Group (Reserved: 0)

Array Index	Tool life type (data range)	
	M700/M800 series L system (TYPE I), C70 L system (TYPE I)	M700/M800 series L system (TYPE II)
0	Application of time management (0 to 995959)	Tool number (Reserved: 0)
1	Application of count management (0 to 9999)	Compensation number (0 to 80)
2	Status A (0 to 2)	Usage (Time: 0 to 99999999, Number of times: 0 to 999999)
3	Life of time management (0 to 995959)	ST (0 to 3)
4	Life of count management (0 to 9999)	Method (Time: 0, Count: 1)
5	Status B (depends on MTB specifications)	Life (0 to 999999)
6 to 10	-	-

Array Index	Tool life type (data range)	
	C70 L system (TYPE II)	
0	Tool number (1 to 999999)	
1	Group (1 to 9999)	
2	Method (0: Time, 1:Count)	
3	Compensation number (1 to 80)	
4	Status (0 to 3)	
5	Life (Time: 0 to 999999, Count: 0 to 999999)	
6	Usage (Time: 0 to 999999, Count: 0 to 999999)	
7 to 10	-	

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets tool life management data for the set tool number. This method is used for updating. To newly add a tool, use the following procedure.

- 1) AddToolLifeGroup()
- 2) AddToolLifeToolNo()
- 3) SetToolLifeValue2()

For the "method" for tool life management data, refer to the installation guide of each Mitsubishi CNC.

[Example]

```
LPOLESTR* lppwszData;
lppwszData = new LPOLESTR[11];
lppwszData[0] =L"0";
lppwszData[1] =L"1";
lppwszData[2] =L"220";
lppwszData[3] =L"10.000";
lppwszData[4] =L"20.000";
lppwszData[5] =L"40.000";
lppwszData[6] =L"18.000";
lppwszData[7] =L"0";
lppwszData[8] =L"0.000";
lppwszData[9] =L"0.000";
lppwszData[10] =L"0";
hr = pIEZNCtool->SetToolLifeValue2( 1, 100, (LPCOLESTR*)lppwszData, &IRet);
if( S_OK != hr ){
    wprintf(L"HRESULT Code = 0x%x, IRet Code = 0x%x\n", hr, IRet );
}
delete[ ] lppwszData;
```

□ **Reference** **GetToolLifeValue(), AddToolLifeGroup(), AddToolLifeToolNo()**

□ **Specification** System

2.15.1 IEZNCATC3::GetMGNControl **Get ATC tool registration control parameter**


```

□ Custom call procedure
HRESULT GetMGNControl(
    LONG* pData,           // (O) Parameter value
    LONG* pRet            // (O) Error code
)

□ Automation call procedure
ATC_GetMGNControl(
    pData As LONG*       // (O) Parameter value
) As LONG                // (O) Error code
    
```

□ *pData*: Returns a parameter that controls start magazine.

Argument



pRet: Returns an error code. (Upon automation, the return value is used.)

- S_OK**: Normal termination
- EZNC_DATA_READ_READ**: Data is not readable

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the control parameter value for ATC tool registration.

□ **Reference**

□ **Specification**

2.15.2 IEZNCATC3::GetMGNSize

Get total number of sets of magazine pots for ATC tool registration

□ Custom call procedure

```

HRESULT      GetMGNSize(
                  LONG* pSize,           // (O) Total number of sets of magazine pots
                  LONG* pRet           // (O) Error code
                )

```

□ Automation call procedure

```

ATC_GetMGNSize(
  pSize As LONG*           // (O) Total number of sets of magazine pots
) As LONG                 // (O) Error code

```

□ **Argument** *pSize*: Returns the total number of sets of magazine pots.
Value: 0 to 360 (maximum)

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the total number of sets of magazine pots.

□ **Reference**

□ **Specification**

2.15.3 IEZNCATC3::GetMGNSize2

Get number of sets of pots for each magazine for ATC tool registration

□ Custom call procedure

```

HRESULT      GetMGNSize2(
                LONG IMagazineNo,    // (I) Magazine number
                LONG* pSize,         // (O) Number of sets of magazine pots
                LONG* pRet           // (O) Error code
            )

```

□ Automation call procedure

```

ATC_GetMGNSize2(
    IMagazineNo As LONG // (I) Magazine number
    pSize As LONG*      // (O) Number of sets of magazine pots
) As LONG              // (O) Error code

```

□ **Argument** *IMagazineNo*: Set the magazine number.
 Value: 1 to 5 (maximum) M700/M800 series
 Value: 1 to 3 (maximum) C70

pSize: Returns the number of sets of magazine pots.
 Value: 0 to 360 (maximum) M700/M800 series
 Value: 0 to 80 (maximum) C70

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_DATA_RANGE: Invalid argument data range (*IMagazineNo*)

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the number of sets of the set magazine pots.

□ **Reference**

□ **Specification**

2.15.4 IEZNCATC3::GetMGNReady2

Get tool number for ATC tool registration

□ Custom call procedure

```

HRESULT      GetMGNReady2(
                LONG IMagazineNo,           // (I) Magazine number
                LONG IReady,              // (I) On standby
                LONG* pIToolNo,           // (O) Tool number
                LONG* pIRet              // (O) Error code
                )

```

□ Automation call procedure

```

ATC_GetMGNReady2(
  IMagazineNo As LONG           // (I) Magazine number
  IReady As LONG              // (I) On standby
  pIToolNo As LONG*           // (O) Tool number
  ) As LONG                    // (O) Error code

```

□ **Argument** *IMagazineNo*: Sets the magazine number.
Value: 1 to 2 (Even if value is set for M700/M800 series, it is invalid.)

IReady: Sets standby state.

Value	Meaning
0	Tool number to be installed
1	Tool number on standby 1
2	Tool number on standby 2
3	Tool number on standby 3
4	Tool number on standby 4

pIToolNo: Returns the tool number.
Value: 1 to 99999999 (maximum)

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_DATA_RANGE: Invalid argument data range (*IMagazineNo*, *IReady*)

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the tool number for ATC tool registration.

□ **Reference**

□ **Specifica-
tion**

2.15.5 IEZNCATC3::GetMGNPot

Get tool number for magazine pot for ATC
tool registration

□ Custom call procedure

```

HRESULT      GetMGNPot(
                LONG Index,                // (I) Magazine pot number
                LONG* pToolNo,            // (O) Tool number
                LONG* pRet                // (O) Error code
            )

```

□ Automation call procedure

```

ATC_GetMGNPot(
    Index As LONG                // (I) Magazine pot number
    pToolNo As LONG*            // (O) Tool number
) As LONG                        // (O) Error code

```

□ **Argument** *Index*: Sets the magazine pot number.
Value: 1 to 360 (maximum) M700/M800 series
Value: 1 to 80 (maximum) C70

pToolNo: Returns the tool number.
Value: 0 to 99999999 (maximum)

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_DATA_RANGE: Invalid argument data range (*Index*)

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the tool number which is stored in the set pot of the magazine.

□ **Reference** **SetMGNPot(), GetMGNPotEx()**

□ **Specifica-
tion**

2.15.6 IEZNCATC3::GetMGNPot3

Get tool number for each magazine pot for ATC
tool registration

□ Custom call procedure

```

HRESULT      GetMGNPot3(
                LONG IMagazineNo,           // (I) Magazine number
                LONG IIndex,                // (I) Pot number
                LONG* pToolNo,              // (O) Tool number
                LONG* pRet                   // (O) Error code
            )

```

□ Automation call procedure

```

ATC_GetMGNPot3(
    IMagazineNo As LONG           // (I) Magazine number
    IIndex As LONG                // (I) Pot number
    pToolNo As LONG*              // (O) Tool number
) As LONG                         // (O) Error code

```

□ **Argument** *IMagazineNo*: Sets the magazine number.
Value: 1 to 5 (maximum) M700/M800 series
Value: 1 to 3 (maximum) C70

IIndex: Sets the pot number.
Value: 1 to 360 (maximum) M700/M800 series
Value: 1 to 80 (maximum) C70

pToolNo: Returns the tool number.
Value: 0 to 99999999 (maximum)

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

EZ_ERR_DATA_RANGE: Invalid argument data range (*IMagazineNo*, *IIndex*)

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the tool number which is stored in the pot of the set magazine number.

□ **Reference** **SetMGNPot3()**

□ **Specifica-
tion**

2.15.7 IEZNCATC3::SetMGNPot

Set tool number for magazine pots for ATC
tool registration

□ Custom call procedure

```

HRESULT      SetMGNPot(
                LONG lIndex,           // (I) Pot number
                LONG lToolNo,         // (I) Tool number
                LONG* plRet            // (O) Error code
            )

```

□ Automation call procedure

```

ATC_SetMGNPot(
    lIndex As LONG           // (I) Pot number
    lToolNo As LONG         // (I) Tool number
    ) As LONG                // (O) Error code

```

□ **Argument** *lIndex*: Sets the pot number.
Value: 1 to 360 (maximum) M700/M800 series
Value: 1 to 80 (maximum) C70

lToolNo: Sets the tool number.
Value: 1 to 99999999 (maximum)

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZ_ERR_DATA_RANGE: Invalid argument data range (*lIndex*, *lToolNo*)

□ Return value	Value	Meaning
-----------------------	-------	---------

	S_OK	Normal termination
--	-------------	--------------------

	S_FALSE	Communication failure
--	----------------	-----------------------

□ **Function** Sets the tool number to be stored in the magazine pot. Care should be taken to avoid overlaps in tool numbers because double registration of a tool number is not checked. An alarm is raised when double registration is made. Alarm information can be got with GetAlarm().
For the **M700/M800 series**, if the tool number of the Mitsubishi CNC is specified for 4 digits, the lower 4 digits are registered when the number with 5 digits or more is specified, and the 5th digit and higher will be discarded.

□ **Reference** **GetMGNPot()**, **SetMGNPotEx()**, **GetAlarm()**

□ **Specification**

2.15.8 IEZNCATC3::SetMGNPot3

Set tool number for each magazine pot for ATC
tool registration

□ Custom call procedure

```

HRESULT      SetMGNPot3(
                LONG IMagazineNo,           // (I) Magazine number
                LONG IIndex,               // (I) Pot number
                LONG IToolNo,             // (I) Tool number
                LONG* pIRet                // (O) Error code
            )

```

□ Automation call procedure

```

ATC_SetMGNPot3(
    IMagazineNo As LONG           // (I) Magazine number
    IIndex As LONG                // (I) Pot number
    IToolNo As LONG              // (I) Tool number
) As LONG                        // (O) Error code

```

□ **Argument** *IMagazineNo*: Sets the magazine number.
Value: 1 to 5 (maximum) M700/M800 series
Value: 1 to 3 (maximum) C70

IIndex: Sets the pot number.
Value: 1 to 360 (maximum) M700/M800 series
Value: 1 to 80 (maximum) C70

IToolNo: Sets the tool number.
Value: 1 to 99999999 (maximum)

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_WRITE: Data is not writable

EZ_ERR_DATA_RANGE: Invalid argument data range (*IMagazineNo*, *IIndex*, *IToolNo*)

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets the tool number to be stored in the pot of the set magazine number. Care should be taken to avoid overlaps in tool numbers because double registration of a tool number is not checked. An alarm is raised when double registration is made. Alarm information can be got with GetAlarm(). If the tool number of the Mitsubishi CNC is specified for 4 digits, the lower 4 digits are registered when the number with 5 digits or more is specified, and the 5th digit and higher will be discarded.

□ **Reference** **GetMGNPot3()**, **GetAlarm()**

□ **Specification**

2.15.9 IEZNCATC3::GetMGNAux

Get user PLC interface for ATC tool registration

□ Custom call procedure

```

HRESULT      GetMGNAux(
                LONG* pData,           // (O) Data
                LONG* pRet            // (O) Error code
            )

```

□ Automation call procedure

```

ATC_GetMGNAux(
    pData As LONG*           // (O) Data
) As LONG                   // (O) Error code

```

□ **Argument** *pData*: Returns sequence processing data for user programmable controller.
Value: 0 to 65535

pRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Returns sequence processing data for user PLC.

□ **Reference**

□ **Specification**

2.15.10 IEZNCATC3::SetMGNAux

Set user PLC interface for ATC tool registration

□ Custom call procedure

```

HRESULT      SetMGNAux(
                LONG IData,           // (I) Data
                LONG* pIRet           // (O) Error code
            )

```

□ Automation call procedure

```

ATC_SetMGNAux(
    IData As LONG           // (I) Data
) As LONG                  // (O) Error code

```

□ **Argument** *IData*: Sets sequence processing data for userPLC.
Value: 0 to 65535

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_READ: Data is not readable

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Sets sequence processing data for user PLC.

□ **Reference**

□ **Specifica-
tion**

2.16.1 IEZNCParameter3::GetParameterData2 **Get parameters**

□ Custom call procedure

```

HRESULT GetParameterData2(
    LONG IGroup, // (I) Group number
    LONG IItem, // (I) First item number
    LONG ISize, // (I) Number of items
    LONG IAxis, // (I) Axis No.
    LPOLESTR* lppwszValue, // (O) Parameter value character string array
    LONG* plRet // (O) Error code
)
    
```

□ Automation call procedure

```

Parameter_GetData2(
    IGroup As LONG // (I) Group number
    IItem As LONG // (I) First item number
    ISize As LONG // (I) Number of items
    IAxis As LONG // (I) Axis No.
    pvValue As VARIANT* // (O) Parameter value character string array
) As LONG // (O) Error code
    
```

□ *IGroup*: Sets the group number of parameter.

Argument	Model	Setting
M700 series		Disabled
C70		Disabled

IItem: Sets the first item number of parameter. This must be set. The parameter number described in setup manuals of each CNC will be this item number.

Model	IB# of parameter manual	Item number to be set	
M700 series	Mitsubishi CNC M700 series	IB-1500123	Parameter number
	Mitsubishi CNC M700VS series	IB-1500905	Parameter number
	Mitsubishi CNC M700VW series	IB-1500932	Parameter number
	Mitsubishi CNC M70 series	IB-1500878	Parameter number
	Mitsubishi CNC M70V series	IB-1500957	Parameter number
C70	IB-1500264	Parameter number	

ISize: Sets the number of items of parameter. The range starts from 1.

IAxis: Sets the axis No. whose parameter is to be got. This argument needs not be set unless the parameter to be got is axis-dependent.

lppwszValue: Gets the parameter value as a **UNICODE** character string array. Though the character string area will internally be allocated in this product, the pointer of the character string (for *ISize*) needs to be reserved by the client. As the character string area is internally allocated in this product, the client using VC++ needs to release the memory area explicitly with **CoTaskMemFree()**.

The parameter value will be got as signed value regardless of its item number. In the case of unsigned SHORT type data "65535", "-1" will be got.

pvValue: See the explanation of *lppwszValue*.

□ **Argument** *plRet*: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting
EZNC_PARAM_FILENOTEXIST: No parameter information file
EZNC_DATA_NOT_EXIST: Data does not exist
EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Gets the parameter.
This function is not supported with the M800 Series. (EZ_ERR_NOT_SUPPORT is returned to plRet.)

□ **Reference** **SetParameterData2()**

□ **Specification**

2.16.2 IEZNCParameter3::GetParameterData3

Get parameters

□ Custom call procedure

```

HRESULT GetParameterData3(
    LONG IGroup,           // (I) Group number
    LONG IItem,           // (I) First item number
    LONG ISize,           // (I) Number of items
    LONG IAxis,           // (I) Aaxis No.
    LPOLESTR* lppwszValue, // (O) Parameter value character string array
    LONG* plRet           // (O) Error code
)

```

□ Automation call procedure

```

Parameter_GetData3(
    IGroup As LONG           // (I) Group number
    IItem As LONG           // (I) First item number
    ISize As LONG           // (I) Number of items
    IAxis As LONG           // (I) Axis No.
    pvValue As VARIANT*    // (O) Parameter value character string array
) As LONG                  // (O) Error code

```

□ *IGroup*: Sets the group number of parameter.

Argument	Model	Setting
	C70	Disabled
	M700/M800 series	Disabled

IItem: Sets the first item number of parameter. This must be set. The parameter number described in setup manuals of each CNC will be this item number.

Model	IB# of parameter manual	Item number to be set	
C70	IB-1500264	Parameter number	
M700 series	Mitsubishi CNC M700 series	IB-1500123	Parameter number
	Mitsubishi CNC M700VS series	IB-1500905	Parameter number
	Mitsubishi CNC M700VW series	IB-1500932	Parameter number
	Mitsubishi CNC M70 series	IB-1500878	Parameter number
	Mitsubishi CNC M70V series	IB-1500957	Parameter number
M800 series	IB-1501265	Parameter number	

ISize: Sets the number of items of parameter. The range starts from 1.

IAxis: Sets the axis whose parameter is to be got. This argument needs not be set unless the parameter to be got is axis-dependent.

lppwszValue: Gets the parameter value as a **UNICODE** character string array. Though the character string area will internally be allocated in this product, the pointer of the character string (for *ISize*) needs to be reserved by the client. As the character string area is internally allocated in this product, the client using VC++ needs to release the memory area explicitly with **CoTaskMemFree()**.

The parameter value will be got as signed value regardless of its item number. In the case of unsigned SHORT type data "65535", "-1" will be got.

pvValue: See the explanation of *lppwszValue*.

Argument *p/Ret*: Returns an error code. (Upon automation, the return value is used.)
S_OK: Normal termination
EZNC_DATA_READ_ADDR: Invalid part system, axis No. setting
EZNC_PARAM_FILENOTEXIST: No parameter information file
EZNC_DATA_NOT_EXIST: Data does not exist

<input type="checkbox"/> Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

Function Gets the parameter.

Reference **SetParameterData3()**

Specification

2.16.3 IEZNCParameter3::SetParameterData2

Set parameters

□ Custom call procedure

```

HRESULT      GetParameterData2(
                LONG IGroup,           // (I) Group number
                LONG IItem,           // (I) First item number
                LONG ISize,           // (I) Number of items
                LONG IAxis,           // (I) Axis No.
                LPOLESTR* lppwszValue, // (O) Parameter value character string array
                LONG* plRet            // (O) Error code
            )

```

□ Automation call procedure

```

Parameter_GetData2(
    IGroup As LONG           // (I) Group number
    IItem As LONG           // (I) First item number
    ISize As LONG           // (I) Number of items
    IAxis As LONG           // (I) Axis No.
    pvValue As VARIANT*    // (O) Parameter value character string array
) As LONG                  // (O) Error code

```

□ *IGroup*: Sets the group number of parameter.

Argument	Model	Setting
	C70	Disabled
	M700 series	Disabled

IItem: Sets the first item number of parameter. This must be set. The parameter number described in setup manuals of each CNC will be this item number.

Model	IB# of parameter manual	Item number to be set
C70	IB-1500264	Parameter number
M700 series	Mitsubishi CNC M700 series	Parameter number
	Mitsubishi CNC M700VS series	Parameter number
	Mitsubishi CNC M700VW series	Parameter number
	Mitsubishi CNC M70 series	Parameter number
	Mitsubishi CNC M70V series	Parameter number

ISize: Sets the number of items of parameter. The range starts from 1.

IAxis: Sets the axis whose parameter is to be got. This argument needs not be set unless the parameter to be got is axis-dependent.

lppwszValue: Gets the parameter value as a **UNICODE** character string array.

Automation argument:

vValue: See the explanation of *lppwszValue*.

□ *plRet*: Returns an error code. (Upon automation, the return value is used.)

Argument	Value
	S_OK : Normal termination
	EZNC_DATA_READ_ADDR : Invalid part system, axis No. setting
	EZNC_PARAM_FILENOTEXIST : No parameter information file
	EZNC_DATA_NOT_EXIST : Data does not exist
	EZ_ERR_NOT_SUPPORT : Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	<p data-bbox="311 333 550 367">Gets the parameter.</p> <p data-bbox="311 371 1476 450">When setting the machine parameters, the NC must be set to the machine parameter setting mode state. Refer to the Setup Manual for each CNC for details on setting the machine parameter setting mode.</p> <p data-bbox="311 454 1476 504">This function is not supported with the M800 Series. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)</p>	
□ Reference	SetParameterData2()	
□ Specification		

2.16.4 IEZNCParameter3::SetParameterData3

Set Parameters

□ Custom call procedure

```

HRESULT SetParameterData3(
    LONG IGroup,           // (I) Group number
    LONG IItem,           // (I) First item number
    LONG ISize,           // (I) Number of items
    LONG IAxis,           // (I) Axis No.
    LPCOLESTR* lppcwszValue, // (I) Parameter value character string array
    LONG* plRet           // (O) Error code
)

```

□ Automation call procedure

```

Parameter_SetData3(
    IGroup As LONG           // (I) Group number
    IItem As LONG           // (I) First item number
    IAxis As LONG           // (I) Axis No.
    vValue As VARIANT       // (I) Parameter value character string array
) As LONG                  // (O) Error code

```

□ *IGroup*: Sets the group number of parameter.

Argument	Model	Setting
	C70	Disabled
	M700/M800 series	Disabled

IItem: Sets the first item number of parameter. This must be set. The parameter number described in setup manuals of each CNC will be this item number.

Model	IB# of parameter manual	Item number to be set
C70	IB-1500264	Parameter number
M700 series	Mitsubishi CNC M700 series	Parameter number
	Mitsubishi CNC M700VS series	Parameter number
	Mitsubishi CNC M700VW series	Parameter number
	Mitsubishi CNC M70 series	Parameter number
	Mitsubishi CNC M70V series	Parameter number
M800 series	IB-1501265	Parameter number

ISize: Sets the number of items of parameter. The range starts from 1.

IAxis: Sets the axis whose parameter is to be got. This argument needs not be set unless the parameter to be got is axis-dependent.

lppcwszValue: Sets the parameter value as a **UNICODE** character string array.

vValue: See the explanation of *lppcwszValue*.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_WRITE_ADDR: Invalid part system, axis No.setting

EZNC_PARAM_FILENOTEXIST: No parameter information file

EZNC_DATA_NOT_EXIST: Data does not exist

□ Return value	Value	Meaning
	S_OK S_FALSE	Normal termination Communication failure
□ Function	Sets the parameter. To set a machine parameter, the NC needs to be in the machine parameter setting mode. For how to set the NC to the machine parameter setting mode, see the setup manual of the Mitsubishi CNC.	
□ Reference	GetParameterData3()	
□ Specification		

2.17.1 IEZNCOperation::Search

Operation search

□ Custom call procedure

```

HRESULT Search(
    LPCOLESTR IpcwszSelectProgram, // (I) Program file name
    LONG ISequenceNo, // (I) Sequence number
    LONG IBlockNo, // (I) Block number
    LONG* pIRet // (O) Error code
)

```

□ Automation call procedure

```

Operation_Search(
    IpcwszSelectProgram As STRING // (I) Program file name
    ISequenceNo As LONG // (I) Sequence number
    IBlockNo As LONG // (I) Block number
) As LONG // (O) Error code

```

□ **Argument** *IpcwszSelectProgram*: Sets the program file name for operation search as a **UNICODE** character string.

ISequenceNo: Sets the sequence number to be searched.

IBlockNo: Sets the block number to be searched.

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_OPE_SELECTPRG_ADDR: Invalid system specification

EZNC_OPE_SELECTPRG_FILESYSTEM: File system error

EZNC_OPE_SELECTPRG_NOPRG: No program file

EZNC_OPE_SELECTPRG_PRGFORMAT: Invalid program file name format

EZNC_OPE_SELECTPRG_RUNNING: Program operation in progress

□ **Return value**

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function**

Executes operation search.

Use *IpcwszSelectProgram* to set the program file name whose operation is to be started.

The name of the program files in the \PRG\USER\ directory of NC control unit or in the M□:IC1\ directory of NC's CF card or NC's SD card (M800S/M80: at the front panel SD card slot, M800W: at the rear panel SD card slot #2) can be set.

Note that the file name of the program file in the \PRG\USER\ directory of NC control unit does not need to contain the drive name and directory path.

Use a character string as below to specify the program file name.

C70: "<program number>.PRG" Example) "1000.PRG"

M700/M800 series: "<program file name>" Example) "1000"

M700/M800 series: "M□:IC1<program file name>" Example) "M01:IC1\1000"

ISequenceNo or *IBlockNo* can be used to set the sequence number or block number whose operation is to be started. Set 0 in *ISequenceNo* and *IBlockNo* when operation is to be started from the top of the program.

□ **Reference**

IEZNCProgram::CurrentBlockRead()

□ **Specification**

System

2.17.2 IEZNCOperation::Run

Start PLC program

□ Custom call procedure

```
HRESULT Run(
    LONG* pIRet           // (O) Error code
)
```

□ Automation call procedure

```
Operation_Run( ) As LONG           // (O) Error code
```

□ *pIRet*: Returns an error code. (Upon automation, the return value is used.)

□ **Argument** **S_OK**: Normal termination
 EZNC_OPE_ACTPLC_ADDR: Invalid NC control unit

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Starts the PLC program.

□ **Reference** **Stop()**

□ **Specifica-
tion**

2.17.3 IEZNCOperation::Stop

Stop PLC program

□ Custom call procedure

```
HRESULT      Stop(
                LONG* pIRet                // (O) Error code
            )
```

□ Automation call procedure

```
Operation_Stop( ) As LONG                // (O) Error code
```

□ *pIRet*: Returns an error code. (Upon automation, the return value is used.)

Argument **S_OK**: Normal termination
 EZNC_OPE_ACTPLC_ADDR: Invalid NC control unit

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ Stops the PLC program.

Function

□ **Run()**

Reference

□ **Specifica-
tion**

2.18.1 IEZNCDevice::SetDevice

Set device settings

□ Custom call procedure

```

HRESULT SetDevice(
    DWORD dwLength, // (I) Number of device points
    LPCOLESTR* lppcwszDevice, // (I) Device character string
    LPDWORD lpdwDataType, // (I) Data type
    LPDWORD lpdwValue, // (I) Device value array
    LONG* plRet // (O) Error code
)
    
```

□ Automation call procedure

```

Device_SetDevice(
    vDevice As VARIANT, // (I) Device character string
    vDataType As VARIANT, // (I) Data type
    vValue As VARIANT // (I) Device value array
) As LONG // (O) Error code
    
```

□ *dwLength*: Sets the number of device points to be set. The maximum value is 1K points.

Argument

lppcwszDevice: Sets the array of the device character string to be set. The device character string needs to be specified as UNICODE string. However if word format (or double word format) is set in the data type, the device character string needs to be set in multiples of 16 (or 32).

lpdwDataType: Sets each data type of the device to be set as an array.

Value	Meaning	Unit in Table 2-4
EZNC_PLC_BIT	Bit	1 bit
EZNC_PLC_WORD	Word	16 bits
EZNC_PLC_DWORD	Double word	32 bits

lpdwValue: Sets the array used to set the device value. When reading, set a dummy value that has the same number of array elements as that of the device character string.

Automation argument:

vDevice: Sets the array of the device character string to be set as **VARIANT**. It needs to be sets as UNICODE character string. However if word format (or double word format) is set in the data type, the device character string needs to be set in multiples of 16 (or 32).

vDataType: Sets the array of the data type of the device value to be set as **VARIANT**.

Value	Meaning	Unit in Table 2-4
EZNC_PLC_BIT	Bit	1 bit
EZNC_PLC_WORD	Word	16 bits
EZNC_PLC_DWORD	Double word	32 bits

vValue: Sets the array of the device value to be set as **VARIANT**. When reading, set a dummy value that has the same number of array elements as that of the device character string.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_DATATYPE: Invalid data type

EZ_ERR_NOT_SUPPORT: Not supported

<input type="checkbox"/> Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
<input type="checkbox"/> Function	Defines the device to be used in the user PLC. The device settings are all based on one-shot operation. The settings for one-shot operation may return to the original state after one cycle of the PLC operation. The settings cannot be retrieved when making the settings next time. This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to plRet.)	
<input type="checkbox"/> Reference	ReadDevice(), WriteDevice(), DeleteDeviceAll()	
<input type="checkbox"/> Specifica- tion		

Table 2-4 Applicable devices list

Device name	Name	Unit	Model	
			M700	M800
B	Counter (fixed counter)	1 bit/16 bits/32 bits	B0~B1FFF (8192 points)	B0~B1BFFF (114688 points)
CI	Counter coil	1 bit/16 bits/32 bits	C0~C1255 (1256 points)	C0~C101023 (101024 points)
D	Data register	16 bits/32 bits	D0~D2047 (2048 points)	D0~D8191 (8192 points)
E	Special relay	1 bit/16 bits/32 bits	E0~E127 (128 points)	E0~E9999 (10000 points)
F	Alarm message interface. Temporary memory.	1 bit/16 bits/32 bits	F0~F1024 (1025 points)	F0~F4095 (4096 points)
G	Temporary memory	1 bit/16 bits/32 bits	G0~G3071 (3072 points)	—
I	I device	1 bit/16 bits/32 bits	I0~I3FF (1024 points)	—
J	J device	1 bit/16 bits/32 bits	J0~J63F (1600 points)	—
L	Latch relay (backup memory)	1 bit/16 bits/32 bits	L0~L511 (512 points)	L0~L2047 (2048 points)
M	Temporary memory	1 bit/16 bits/32 bits	M0~M10239 (10240 points)	M0~M122879 (122880 points)
Q	Q device	1 bit/16 bits/32 bits	Q0~Q1151 (1152 points)	Q0~Q2047 (2048 points)
R	File register *1	16 bits/32 bits	R0~R32767 (32768 points)	R0~R32767 (32768 points)
SM	Special relay *1	1 bit/16 bits/32 bits	SM0~SM127 (128 points)	SM0~SM16383 (16384 points)
SB	Special relay (for link)	1 bit/16 bits/32 bits	SB0~SB1FF (512 points)	SB0~SB7FF (2048 points)
SD	Special register	16 bits/32 bits	SD0~SD127 (128 points)	SD0~SD16383 (16384 points)
ST	Cumulative timer	1 bit/16 bits/32 bits	ST0~ST1063 (1064 points)	ST0~ST1255 (1256 points)
SW	Special register (for link)	16 bits/32 bits	SW0~SWFDF (4064 points)	SW0~SW7FF (2048 points)
TI	10 ms unit timer coil	1 bit	T0~T1703 (1704 points)	T0~104095 (104096 points)
U	For two input signal lines to programmable controller *1	1 bit/16 bits/32 bits	U0~T17F (384 points)	—
V	V device	1 bit/16 bits/32 bits	V0~V255 (256 points)	V0~V1023 (1024 points)
W	For two output signal lines to programmable controller *1	1 bit/32 bits	W0~W1FF (512 points)	W0~W5FFF (24576 points)
X	Input signal to programmable controller *1	1 bit/16 bits/32 bits	X0~X1FFF (8192 points)	X0~X1FFF (8192 points)
Y	Output signal to programmable controller *1	1 bit/16 bits/32 bits	Y0~Y1FFF (8192 points)	Y0~Y1FFF (8192 points)
ZR	File register	16 bits/32 bits		ZR0~ZR32767 (32768 points)

*1: The intended purpose of this device cannot be changed. Do not use any other device (including undefined device) than that corresponding to the I/O signal of the machine.

*2: The devices are read-only.

2.18.2 IEZNCDevice::DeleteDeviceAll

Delete all device settings

□ Custom call procedure

```
HRESULT DeleteDeviceAll(
    LONG* pIRet // (O) Error code
)
```

□ Automation call procedure

```
Device_DeleteAll( ) As LONG // (O) Error code
```

□ *pIRet*: Returns an error code. (Upon automation, the return value is used.)

Argument **S_OK**: Normal termination
EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Deletes all the data set in **SetDevice()**.

This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)

□ **Reference** **SetDevice()**

□ **Specifica-
tion**

2.18.3 IEZNCDevice::ReadDevice

Read device

□ Custom call procedure

```

HRESULT      ReadDevice(
                LPDWORD lpdwLength,           // (O) Number of read device points
                LPDWORD* lppdwValue,         // (O) Array of read device value
                LONG* plRet                   // (O) Error code
                )

```

□ Automation call procedure

```

Device_Read(
    pvValue As VARIANT*           // (O) Device value array
    ) As LONG                       // (O) Error code

```

□ *lpdwLength*: Returns the number of read devices.

Argument

lppdwValue: Returns the array that contains the device value. As the device value array is allocated in this product, the client needs to release it explicitly with **CoTaskMemFree()**.

Automation argument:

pvValue: Returns the array of the device value as **VARIANT**.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_DATATYPE: Invalid data type

EZNC_DATA_READ_READ: Data is not readable.

EZNC_DATA_READ_WRITEONLY: Write-only data

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Reads all the devices set in SetDevice() .	
	This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to <i>plRet</i> .)	
□ Reference	SetDevice() , WriteDevice()	
□ Specification		

2.18.4 IEZNCDevice::WriteDevice

Write device

□ Custom call procedure

```
HRESULT      WriteDevice(
                LONG* pIRet                                // (O) Error code
            )
```

□ Automation call procedure

```
Device_Write( ) As LONG                                // (O) Error code
```

□ *pIRet*: Returns an error code. (Upon automation, the return value is used.)

□ Argument

S_OK: Normal termination
EZNC_DATA_WRITE_DATATYPE: Invalid data type
EZNC_DATA_WRITE_WRITE: Data is not writable.
EZNC_DATA_WRITE_READONLY: Read-only data
EZ_ERR_NOT_SUPPORT: Not supported

□ Return value

Value	Meaning
S_OK	Normal termination
S_FALSE	Communication failure

□ **Function** Writes all the devices **set in SetDevice()**.

This function is not supported with C70. (EZ_ERR_NOT_SUPPORT is returned to pIRet.)

□ Reference

SetDevice(), **ReadDevice()**

□ Specification

2.18.5 IEZNCDevice::ReadBlockDevice

Batch read devices

□ Custom call procedure

```

HRESULT      ReadBlockDevice(
                DWORD dwLength,                // (I) Number of device points
                LPCOLESTR lpcwszDevice,        // (I) Head device character string
                DWORD dwDataType,              // (I) Data type
                LPDWORD* lppdwValues,         // (I) Read device value array
                LONG* plRet                     // (O) Error code
            )

```

□ Automation call procedure

```

Device_ReadBlock(
    lLength As LONG                // (I) Number of device points
    bstrDevice As STRING           // (I) Head device character string
    lDataType As LONG              // (I) Data type
    pvValues As VARIANT*          // (I) Read device value array
) As LONG                          // (O) Error code

```

- **Argument** *dwLength*: Sets the number of device points to be set. (2 or more)
 The maximum number of points that can be got is determined by the data type of the device being got.

Device data type	Maximum number of getting points
EZNC_PLC_BIT	1280 points
EZNC_PLC_BYTE	1280 points
EZNC_PLC_WORD	640 points
EZNC_PLC_DWORD	320 points

lpcwszDevice: Sets the array of the head device character string to be set. The device character string needs to be set as UNICODE string. However if word format (or double word format) is set in the data type, the device character string needs to be set in multiples of 16 (or 32).

dwDataType: Sets each data type of the device to be set.

Value	Meaning	Unit in
EZNC_PLC_BIT	Bit	1 bit
EZNC_PLC_BYTE	Byte	8 bit
EZNC_PLC_WORD	Word	16 bits
EZNC_PLC_DWORD	Double word	32 bits

lppdwValue: Sets the array used to set the device value. The data array is secured on the EZSocket side, so explicitly release it on the client side using CoTaskMemFree().

The values are got in the device corresponds to the size for the data type at the lower end of the array.

Example) Data type: **EZNC_PLC_BYTE**, Set device value: 0x82
 Read device value: 0x00000082

Automation argument:

lLength: See the explanation of *dwLength*.

bstrDevice: See the explanation of *lpcwszDevice*.

lDataType: See the explanation of *lppdwDataType*.

pvValue : Returns the device value array in VARIANT.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_DATATYPE: Invalid data type

EZNC_DATA_READ_READ: Data is not readable.

EZNC_DATA_READ_WRITEONLY: Write-only data

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	A device with continuous device points from the head device character string is read out.	
	This is valid only for the M700V/M70V/M800 series. This function is not supported with C70 and M700/M70 series. (EZ_ERR_NOT_SUPPORT is returned to plRet.)	
□ Reference	WriteBlockDevice()	
□ Specification		

2.18.6 IEZNCDevice::WriteBlockDevice

Batch write devices

□ Custom call procedure

```

HRESULT WriteBlockDevice(
    DWORD dwLength, // (I) Number of device points
    LPCOLESTR lpcwszDevice, // (I) Head device character string
    DWORD dwDataType, // (I) Data type
    LPDWORD lpdwValues, // (I) Write device value array
    LONG* plRet // (O) Error code
)

```

□ Automation call procedure

```

Device_WriteBlock(
    ILength As LONG // (I) Number of device points
    bstrDevice As STRING // (I) Head device character string
    IDataType As LONG // (I) Data type
    vValues As VARIANT // (I) Write device value array
) As LONG // (O) Error code

```

- **Argument** *dwLength*: Sets the number of device points to be set. (2 or more)
 The maximum number of points that can be got is determined by the data type of the device being got.

Device data type	Maximum number of gettable points
EZNC_PLC_BIT	1280 points
EZNC_PLC_BYTE	1280 points
EZNC_PLC_WORD	640 points
EZNC_PLC_DWORD	320 points

lpcwszDevice: Sets the array of the head device character string to be set. The device character string needs to be set as UNICODE string. However if word format (or double word format) is set in the data type, the device character string needs to be set in multiples of 16 (or 32).

dwDataType: Sets each data type of the device to be set.

Value	Meaning	Unit in Table 2-4
EZNC_PLC_BIT	Bit	1 bit
EZNC_PLC_BYTE	Byte	8 bit
EZNC_PLC_WORD	Word	16 bits
EZNC_PLC_DWORD	Double word	32 bits

lpdwValue: Sets the array used to set the device value.

The value set in the device corresponds to the size for the data type at the lower end of the array.

Example) Data type: **EZNC_PLC_BYTE**, Written device value: 0x12345678

Set device value: 0x78

Automation argument:

ILength: See the explanation of *dwLength*.

bstrDevice: See the explanation of *lpcwszDevice*.

IDataType: See the explanation of *lpdwDataType*.

vValue : Returns the device value array in VARIANT.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_DATA_READ_DATATYPE: Invalid data type

EZNC_DATA_WRITE_WRITE: Data is not writable.

EZNC_DATA_WRITE_READONLY: Read-only data

EZ_ERR_NOT_SUPPORT: Not supported

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	A device with continuous device points from the head device character string is read out.	
	This is valid only for the M700V/M70V/M800 series.	
	This function is not supported with C70 and M700/M70 series. (EZ_ERR_NOT_SUPPORT is returned to plRet.)	
□ Reference	ReadBlockDevice()	
□ Specifica- tion		

2.19.1 IEZNCSubFunction3::Changelnit2 **Initialize subfunction**

□ Custom call procedure

```
HRESULT Changelnit2 (
    LONG ISystemType,           // (I) Mitsubishi CNC type
    LONG IReserve1,            // (I) Reservation 1
    LONG IReserve2,            // (I) Reservation 2
    LONG* pIRet                 // (O) Error code
)
```

□ Automation call procedure

```
Changelnit2 (
    ISystemType As LONG        // (I) Mitsubishi CNC type
    IReserve1 As LONG          // (I) Reservation 1
    IReserve2 As LONG          // (I) Reservation 2
) As LONG                     // (O) Error code
```

□ *ISystemType*: Sets the Mitsubishi CNC type.

Argument	Value	Meaning
	EZNC_SYS_MELDASC70	Perform initialization on C70.
	EZNC_SYS_MELDAS700M	Perform initialization on M700 M series.
	EZNC_SYS_MELDAS700L	Perform initialization on M700 L series.
	EZNC_SYS_MELDAS800M	Perform initialization on M800 M series.
	EZNC_SYS_MELDAS800L	Perform initialization on M800 L series.

IReserve1: Not used. (Always set 0.)
IReserve2: Not used. (Always set 0.)

pIRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZ_ERR_DATA_RANGE: Invalid data range

Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure

□ **Function** Initializes **IEZNCSubFunction**.

□ **Reference**

□ **Specifica-
tion**

2.19.2 IEZNCSubFunction3::GetToolWorkOffsetOfFile

Get data from workpiece
offset file

□ Custom call procedure

```

HRESULT      GetToolWorkOffsetOfFile(
                LPCOLESTR lpcwszFileName, // (I) File name containing a path
                LONG lHead, // (I) Part system
                LONG lIndex, // (I) Workpiece coordinate system number
                LPCOLESTR* lppcwszAxis, // (I) Axis name character string array
                LPOLESTR** lpppwszData, // (O) Workpiece coordinate data value
                                                character string array
                LONG* plRet // (O) Error code
                )

```

□ Automation call procedure

```

                GetToolWorkOffsetOfFile(
                bstrFileName As STRING // (I) File name containing a path
                lHead As LONG // (I) Part system
                lIndex As LONG // (I) Workpiece coordinate system number
                vAxis As VARIANT // (I) Axis name character string array
                pvData As VARIANT* // (O) Workpiece coordinate data value
                                                character string array
                ) As LONG // (O) Error code

```

□ **Argument** *lpcwszFileName*: Sets the file name including path of the workpiece offset file as a **UNICODE** character string.

Set the file with absolute path as below.
Drive name + ":" + \directory name\file name

lHead: Sets the system.

lIndex: Sets the workpiece coordinate system number to be read.

Value	Meaning
54	G54 offset
55	G55 offset
56	G56 offset
57	G57 offset
58	G58 offset
59	G59 offset
60	EXT offset
61	P1 offset
62	P2 offset
:	:
108	P48 offset

lppcwszAxis: Sets the axis name as a **UNICODE** character string array. (Example: "X") The number of array elements is 8 (0 to 7). Set a **NULL** character string to the axes not applicable. (A NULL pointer cannot be set.) This is used only in C70. Set a NULL character string to all elements in any other model.

lpppwszData: Returns the workpiece offset data value as a UNICODE character string array. As the data value array is allocated in this product, the client needs to release it explicitly with **CoTaskMemFree ()**.

<i>lpppwszData</i>	Tool change data type	Remarks
0	1st axis	
1	2nd axis	
2	3rd axis	
3	4th axis	
4	5th axis	
5	6th axis	
6	7th axis	
7	8th axis	

The unit is [inch] or [mm] depending on the parameter setting of NC.

Automation argument:

bstrFileName: See the explanation of *lpcwszFileName*.

vAxis: See the explanation of *lppcwszAxis*.

pvData: Returns the workpiece offset data value as VARIANT.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_OPEN_FILENOTEXIST: File does not exist

EZNC_FILE_OPEN_OPEN: File cannot be opened

EZNC_FILE_READFILE_READ: Data is not readable

EZNC_DATA_NOT_EXIST: Data does not exist

EZ_ERR_MEMORY_ALLOC: Memory cannot be allocated.

□ Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
□ Function	Gets the offset value of the workpiece coordinate system of the set part system and axis No.	
□ Reference	OpenFile3(), CloseFile2(), ReadFile2(), WriteFile(), SetToolWorkOffsetFile()	
□ Specification		

2.19.3 IEZNCSubFunction3::SetToolWorkOffsetOfFile Set data to workpiece offset file

□ Custom call procedure

```

HRESULT      SetToolWorkOffsetOfFile(
                LPCOLESTR IpcwszFileName, // (I) File name containing a path
                LONG IMode, // (I) Setting mode
                LONG IHead, // (I) Part System
                LONG IIndex, // (I) Workpiece coordinate system number
                LPCOLESTR* IppcwszAxis, // (I) Axis name string character array
                LPCOLESTR* IppcwszData, // (I) Workpiece coordinate data value
                                                character string array
                LONG* pIRet // (O) Error code
                )

```

□ Automation call procedure

```

                SetToolWorkOffsetOfFile(
                bstrFileName As STRING // (I) File name containing a path
                IMode As LONG // (I) Setting mode
                IHead As LONG // (I) Part system
                IIndex As LONG // (I) Workpiece coordinate system number
                vAxis As VARIANT // (I) Axis name character string array
                vData As VARIANT // (I) Workpiece coordinate data value
                                                character string array
                ) As LONG // (O) Error code

```

□ **Argument** *IpcwszFileName*: Sets the file name including path of the workpiece offset file as a **UNICODE** character string.

Set the file with absolute path as below.
 Drive name + ":" + \directory name\file name

IMode: Sets the setting mode of the tool life management file.

Value	Meaning
EZNC_FILE_CREATE	Creates a new tool life management file.
EZNC_FILE_OPEN	Modifies an existing tool life management file

IHead: Sets the system.

IIndex: Sets the workpiece coordinate system number to be written to.

Value	Meaning
54	G54 offset
55	G55 offset
56	G56 offset
57	G57 offset
58	G58 offset
59	G59 offset
60	EXT offset
61	P1 offset
62	P2 offset
:	:
108	P48 offset

lppcwszAxis: Sets the axis name as a **UNICODE** character string. Set a **NULL** character string to the axes that do not exist. This is used only in C70. Set a NULL character string to all elements in any other model.

lppcwszData: Returns the workpiece offset data as a UNICODE character string. Set a **NULL** character string to the axes that do not exist.
The unit is [inch] or [mm] depending on the parameter setting of CNC.

<i>lppcwszData</i>	Tool change data type	Remarks
0	1st axis	
1	2nd axis	
2	3rd axis	
3	4th axis	
4	5th axis	
5	6th axis	
6	7th axis	
7	8th axis	

Automation argument:

bstrFileName: See the explanation of *lpcwszFileName*.

vAxis: See the explanation of *lppcwszAxis*.

vData: Creates the workpiece offset data as a UNICODE character string and sets it by substituting it in *vData(VARIANT)*. For details of the workpiece offset data, see the explanation of *lppcwszData* and the index above.

plRet: Returns an error code. (Upon automation, the return value is used.)

S_OK: Normal termination

EZNC_FILE_OPEN_FILENOTEXIST: File does not exist

EZNC_FILE_OPEN_OPEN: File cannot be opened

EZNC_FILE_WRITEFILE_WRITE: Data is not writable

EZ_ERR_NULLPTR: Argument is NULL pointer

```

[Example]
LPOLESTR* lppwszAxis;
lppwszAxis = new LPOLESTR[8];
lppwszAxis [0] =L"";
lppwszAxis [1] =L"";
lppwszAxis [2] =L"";
lppwszAxis [3] =L"";
lppwszAxis [4] =L"";
lppwszAxis [5] =L"";
lppwszAxis [6] =L"";
lppwszAxis [7] =L"";
LPOLESTR* lppwszData;
lppwszData = new LPOLESTR[11];
lppwszData[0] =L"-1.000";
lppwszData[1] =L"1.000";
lppwszData[2] =L"3.000";
lppwszData[3] =L"";
lppwszData[4] =L"";
lppwszData[5] =L"";
lppwszData[6] =L"";
lppwszData[7] =L"";
hr = pIEZNCtool->SetToolLifeValueOfFile(L"C:\TEMP\OFFSET.WRK",EZNC_FILE_OPEN, 1, 54,
(LPCOLESTR*)lppwszAxis,(LPCOLESTR*)lppwszData, &IRet);

if( S_OK != hr ){
    wprintf(L"HRESULT Code = 0x%x, IRet Code = 0x%x\n", hr, IRet );
}
delete[ ] lppwszData;

```

<input type="checkbox"/> Return value	Value	Meaning
	S_OK	Normal termination
	S_FALSE	Communication failure
<input type="checkbox"/> Function	Sets the offset value of the workpiece coordinate system of the set part system and axis No.	
<input type="checkbox"/> Reference	OpenFile3(), CloseFile2(), ReadFile2(), WriteFile(), GetToolWorkOffsetFile()	
<input type="checkbox"/> Specification		

3. ERROR CODE LIST

This section provides a list of error codes.

Table 3-1 Error code list

No.	Error code	Number	Description
1.	EZ_ERR_NOT_OPEN	0x80A00101	Communication lines are not open.
2.	EZ_ERR_DOUBLE_OPEN	0x80A00104	Double open error.
3.	EZ_ERR_DATA_TYPE	0x80A00105	Invalid argument data type.
4.	EZ_ERR_DATA_RANGE	0x80A00106	Invalid argument data range.
5.	EZ_ERR_NOT_SUPPORT	0x80A00107	Not supported.
6.	EZ_ERR_CANNOT_OPEN	0x80A00109	Communication line cannot be opened.
7.	EZ_ERR_NULLPTR	0x80A0010A	Argument is NULL pointer.
8.	EZ_ERR_DATA_LENGTH	0x80A0010B	Invalid argument data.
9.	EZ_ERR_OPEN_COMM	0x80A0010C	COMM port handle error.
10.	EZ_ERR_MEMORY_ALLOC	0x80B00101	Memory cannot be allocated.
11.	EZNC_ERR_CANNOT_GETPCERR	0x80B00102	EZSocketPc error cannot be obtained.
12.	EZNC_FILE_OPEN_MODE	0x80B00201	Invalid mode specification.
13.	EZNC_FILE_OPEN_NOTOPEN	0x80B00202	File is not open.
14.	EZNC_FILE_OPEN_FILEEXIST	0x80B00203	File already exists.
15.	EZNC_FILE_OPEN_ALREADYOPENED	0x80B00204	File is already open.
16.	EZNC_FILE_OPEN_CREATE	0x80B00205	Temporary file cannot be created.
17.	EZNC_FILE_WRITEFILE_NOTOPEN	0x80B00206	File is open without write mode specification.
18.	EZNC_FILE_WRITEFILE_LENGTH	0x80B00207	Invalid write data size.
19.	EZNC_FILE_WRITEFILE_WRITE	0x80B00208	Not writable.
20.	EZNC_FILE_READFILE_NOTOPEN	0x80B00209	File is open without read mode specification.
21.	EZNC_FILE_READFILE_READ	0x80B0020A	Not readable.
22.	EZNC_FILE_READFILE_CREATE	0x80B0020B	Temporary file cannot be created.
23.	EZNC_FILE_OPEN_FILENOTEXIST	0x80B0020C	File does not exist (READ mode).
24.	EZNC_FILE_OPEN_OPEN	0x80B0020D	File cannot be opened.
25.	EZNC_FILE_OPEN_ILLEGALPATH	0x80B0020E	Invalid file path.
26.	EZNC_FILE_READFILE_ILLEGALFILE	0x80B0020F	Invalid read file.
27.	EZNC_FILE_WRITEFILE_ILLEGALFILE	0x80B00210	Invalid write file.
28.	EZNC_COMM_CANNOT_OPEN	0x80B00301	Host name for local connection used for automation call is invalid.
29.	EZNC_COMM_NOTSETUP_PROTOCOL	0x80B00302	TCP/IP communication is not configured.
30.	EZNC_COMM_ALREADYOPENED	0x80B00303	Cannot be set because communication is already in progress.
31.	EZNC_COMM_NOTMODULE	0x80B00304	No submodule.
32.	EZNC_COMM_CREATEPC	0x80B00305	EZSocketPc objects cannot be created.
33.	EZNC_DATA_NOT_EXIST	0x80B00401	Data does not exist.
34.	EZNC_DATA_DUPLICATE	0x80B00402	Duplicate data.
35.	EZNC_PARAM_FILENOTEXIST	0x80B00501	No parameter information file.
36.	EZNC_SYSFUNC_IOCTL_ADDR	0x80020190	Invalid NC control unit number.
37.	EZNC_SYSFUNC_IOCTL_NOTOPEN	0x80020102	Device is not open.
38.	EZNC_SYSFUNC_IOCTL_FUNCTION	0x80020132	Invalid command.
39.	EZNC_SYSFUNC_IOCTL_DATA	0x80020133	Invalid communication parameter data range.
40.	EZNC_FILE_DIR_FILESYSTEM	0x80030143	File system error.
41.	EZNC_FILE_DIR_NODIR	0x80030191	Directory does not exist.
42.	EZNC_FILE_DIR_NODRIVE	0x8003019B	Drive does not exist.
43.	EZNC_PCFILE_DIR_NODIR	0x800301A2	Directory does not exist.
44.	EZNC_PCFILE_DIR_NODRIVE	0x800301A8	Drive does not exist.
45.	EZNC_OPE_CURRALM_ADDR	0x80050D90	Invalid system, spindle specification.
46.	EZNC_OPE_CURRALM_ALMTYPE	0x80050D02	Invalid alarm type.
47.	EZNC_OPE_CURRALM_DATAERR	0x80050D03	Error in communication data between NC and personal computer.
48.	EZ_ERR_NOT_OPEN	0x80A00101	Communication lines are not open.
49.	EZ_ERR_DOUBLE_OPEN	0x80A00104	Double open error.
50.	EZ_ERR_DATA_TYPE	0x80A00105	Invalid argument data type.

No.	Error code	Number	Description
51.	EZ_ERR_DATA_RANGE	0x80A00106	Invalid argument data range.
52.	EZ_ERR_NOT_SUPPORT	0x80A00107	Not supported.
53.	EZ_ERR_CANNOT_OPEN	0x80A00109	Communication line cannot be opened.
54.	EZ_ERR_NULLPTR	0x80A0010A	Argument is NULL pointer.
55.	EZ_ERR_DATA_LENGTH	0x80A0010B	Invalid argument data.
56.	EZ_ERR_OPEN_COMM	0x80A0010C	COMM port handle error.
57.	EZ_ERR_MEMORY_ALLOC	0x80B00101	Memory cannot be allocated.
58.	EZNC_ERR_CANNOT_GETPCERR	0x80B00102	EZSocketPc error cannot be obtained.
59.	EZNC_FILE_OPEN_MODE	0x80B00201	Invalid mode specification.
60.	EZNC_FILE_OPEN_NOTOPEN	0x80B00202	File is not open.
61.	EZNC_FILE_OPEN_FILEEXIST	0x80B00203	File already exists.
62.	EZNC_FILE_OPEN_ALREADYOPENED	0x80B00204	File is already open.
63.	EZNC_FILE_OPEN_CREATE	0x80B00205	Temporary file cannot be created.
64.	EZNC_FILE_WRITEFILE_NOTOPEN	0x80B00206	File is open without write mode specification.
65.	EZNC_FILE_WRITEFILE_LENGTH	0x80B00207	Invalid write data size.
66.	EZNC_FILE_WRITEFILE_WRITE	0x80B00208	Not writable.
67.	EZNC_FILE_READFILE_NOTOPEN	0x80B00209	File is open without read mode specification.
68.	EZNC_FILE_READFILE_READ	0x80B0020A	Not readable.
69.	EZNC_FILE_READFILE_CREATE	0x80B0020B	Temporary file cannot be created.
70.	EZNC_FILE_OPEN_FILENOTEXIST	0x80B0020C	File does not exist (READ mode).
71.	EZNC_FILE_OPEN_OPEN	0x80B0020D	File cannot be opened.
72.	EZNC_FILE_OPEN_ILLEGALPATH	0x80B0020E	Invalid file path.
73.	EZNC_FILE_READFILE_ILLEGALFILE	0x80B0020F	Invalid read file.
74.	EZNC_FILE_WRITEFILE_ILLEGALFILE	0x80B00210	Invalid write file.
75.	EZNC_COMM_CANNOT_OPEN	0x80B00301	Host name for local connection used for automation call is invalid.
76.	EZNC_COMM_NOTSETUP_PROTOCOL	0x80B00302	TCP/IP communication is not configured.
77.	EZNC_COMM_ALREADYOPENED	0x80B00303	Cannot be set because communication is already in progress.
78.	EZNC_COMM_NOTMODULE	0x80B00304	No submodule.
79.	EZNC_COMM_CREATEPC	0x80B00305	EZSocketPc objects cannot be created.
80.	EZNC_DATA_NOT_EXIST	0x80B00401	Data does not exist.
81.	EZNC_DATA_DUPLICATE	0x80B00402	Duplicate data.
82.	EZNC_PARAM_FILENOTEXIST	0x80B00501	No parameter information file.
83.	EZNC_SYSFUNC_IOCTL_ADDR	0x80020190	Invalid NC control unit number.
84.	EZNC_SYSFUNC_IOCTL_NOTOPEN	0x80020102	Device is not open.
85.	EZNC_SYSFUNC_IOCTL_FUNCTION	0x80020132	Invalid command.
86.	EZNC_SYSFUNC_IOCTL_DATA	0x80020133	Invalid communication parameter data range.
87.	EZNC_FILE_DIR_FILESYSTEM	0x80030143	File system error.
88.	EZNC_FILE_DIR_NODIR	0x80030191	Directory does not exist.
89.	EZNC_FILE_DIR_NODRIVE	0x8003019B	Drive does not exist.
90.	EZNC_PCFILE_DIR_NODIR	0x800301A2	Directory does not exist.
91.	EZNC_PCFILE_DIR_NODRIVE	0x800301A8	Drive does not exist.
92.	EZNC_OPE_CURRALM_ADDR	0x80050D90	Invalid system, spindle specification.
93.	EZNC_OPE_CURRALM_ALMTYPE	0x80050D02	Invalid alarm type.
94.	EZNC_OPE_CURRALM_DATAERR	0x80050D03	Error in communication data between NC and personal computer.
95.	EZNC_DATA_TLFTOOL_PARAMERR	0x80041194	Invalid type specified for life control data.
96.	EZNC_DATA_TLFTOOL_MAXMINERR	0x80041195	Setting data is out of range.
97.	EZNC_DATA_TLFTOOL_UNMACH	0x80041196	Specified tool number mismatch.
98.	EZNC_DATA_TLFTOOL_OUTOFSPEC	0x80041197	Specified tool number is out of specifications.
99.	EZNC_DATA_READ_ADDR	0x80040190	Invalid system, spindle specification.
100.	EZNC_DATA_READ_SECT	0x80040191	Invalid section number.

No.	Error code	Number	Description
101.	EZNC_DATA_READ_SUBSECT	0x80040192	Invalid subsection number.
102.	EZNC_DATA_READ_DATASIZE	0x80040196	Application does not fit into prepared buffer.
103.	EZNC_DATA_READ_DATATYPE	0x80040197	Invalid data type.
104.	EZNC_DATA_READ_READ	0x8004019D	Data is not readable.
105.	EZNC_DATA_READ_WRITEONLY	0x8004019F	Write-only data.
106.	EZNC_DATA_READ_AXIS	0x800401A0	Invalid axis specification.
107.	EZNC_DATA_READ_DATANUM	0x800401A1	Invalid data number.
108.	EZNC_DATA_READ_NODATA	0x800401A3	Read data not found
109.	EZNC_DATA_READ_VALUE	0x8004019A	Invalid read data range.
110.	EZNC_DATA_WRITE_ADDR	0x80040290	Invalid system, spindle specification.
111.	EZNC_DATA_WRITE_SECT	0x80040291	Invalid section number.
112.	EZNC_DATA_WRITE_SUBSECT	0x80040292	Invalid subsection number.
113.	EZNC_DATA_WRITE_DATASIZE	0x80040296	Application does not fit into prepared buffer.
114.	EZNC_DATA_WRITE_DATATYPE	0x80040297	Invalid data type.
115.	EZNC_DATA_WRITE_READONLY	0x8004029B	Read-only data.
116.	EZNC_DATA_WRITE_WRITE	0x8004029E	Data is not writable.
117.	EZNC_DATA_WRITE_AXIS	0x800402A0	Invalid axis specification.
118.	EZNCDATA_WRITE_SAFETYPWLOCK	0x8004024D	Safety password locked.
119.	EZNCDATA_WRITE_UOPEN_FORMAT	0x800402A2	Formatting canceled because of invalid SRAM open parameter.
120.	EZNCDATA_WRITE_EDTFILE_REGIST	0x800402A4	Cannot register edit file (already being edited).
121.	EZNCDATA_WRITE_EDTFILE_RELEASE	0x800402A5	Cannot release edit file.
122.	EZNCDATA_WRITE_NODATA	0x800402A3	No data at write destination.
123.	EZNCDATA_WRITE_VALUE	0x8004029A	Invalid write data range.
124.	EZNCDATA_WRITE_SAFE_NOPASSWD	0x800402A6	Safety password not set.
125.	EZNCDATA_WRITE_SAFE_CHECKERR	0x800402A7	Safety data consistency check error
126.	EZNCDATA_WRITE_SAFE_DATATYPE	0x800402A9	Safety data type invalid
127.	EZNCDATA_WRITE_SORT	0x800402A8	Cannot write while sorting tool data.
128.	EZNC_DATA_MDLCANCEL_NOTREGIST	0x80040501	Not registered for fast read.
129.	EZNC_DATA_MDLREGIST_PRIORITY	0x80040402	Invalid priority specification.
130.	EZNC_DATA_MDLREGIST_REGIST	0x80040401	Exceeded the limit of registrations.
131.	EZNC_DATA_MDLREGIST_ADDR	0x80040490	Invalid address.
132.	EZNC_DATA_MDLREGIST_SECT	0x80040491	Invalid section number.
133.	EZNC_DATA_MDLREGIST_SUBSECT	0x80040492	Invalid subsection number.
134.	EZNC_DATA_MDLREGIST_DATATYPE	0x80040497	Invalid data type.
135.	EZNC_DATA_MDLREGIST_READONLY	0x8004049B	Read-only data.
136.	EZNC_DATA_MDLREGIST_READ	0x8004049D	Data is not readable.
137.	EZNC_DATA_MDLREGIST_WRITEONLY	0x8004049F	Write-only data.
138.	EZNC_DATA_MDLREGIST_AXIS	0x800404A0	Invalid axis specification.
139.	EZNC_DATA_RETHREADWRITE_NODATA	0x80040BA3	Rethread cut position not set.
140.	EZNC_FILE_DIR_ALREADYOPENED	0x80030101	A different directory is already opened.
141.	EZNC_FILE_DIR_DATASIZE	0x80030103	Exceeded maximum data size.
142.	EZNC_FILE_DIR_NAMELENGTH	0x80030148	File name is too long.
143.	EZNC_FILE_DIR_ILLEGALNAME	0x80030198	Invalid file name format.
144.	EZNC_FILE_DIR_NOTOPEN	0x80030190	Not open.
145.	EZNC_FILE_DIR_READ	0x80030194	File information read error.
146.	EZNC_PCFILE_DIR_ALREADYOPENED	0x80030102	A different directory is already opened (personal computer only).
147.	EZNC_PCFILE_DIR_NOTOPEN	0x800301A0	Not open.
148.	EZNC_PCFILE_DIR_NOFILE	0x800301A1	File does not exist.
149.	EZNC_PCFILE_DIR_READ	0x800301A5	File information read error.
150.	EZNC_FILE_COPY_BUSY	0x80030447	Copying is disabled (during operation).

No.	Error code	Number	Description
151.	EZNC_FILE_COPY_ENTRYOVER	0x80030403	Exceeded the limit of registrations.
152.	EZNC_FILE_COPY_FILEEXIST	0x80030401	Copy destination file already exists.
153.	EZNC_FILE_COPY_FILESYSTEM	0x80030443	File system error.
154.	EZNC_FILE_COPY_NAMELENGTH	0x80030448	File name is too long.
155.	EZNC_FILE_COPY_ILLEGALNAME	0x80030498	Invalid file name format.
156.	EZNC_FILE_COPY_MEMORYOVER	0x80030404	Memory capacity exceeded.
157.	EZNC_FILE_COPY_NODIR	0x80030491	Directory does not exist.
158.	EZNC_FILE_COPY_NODRIVE	0x8003049B	Drive does not exist.
159.	EZNC_FILE_COPY_NOFILE	0x80030442	File does not exist.
160.	EZNC_FILE_COPY_PLCRUN	0x80030446	Copying is disabled (PLC in operation).
161.	EZNC_FILE_COPY_READ	0x80030494	Transfer source file is not readable.
162.	EZNC_FILE_COPY_WRITE	0x80030495	Transfer destination file is not writable.
163.	EZNC_FILE_COPY_PROTECT	0x8003044A	Copying is disabled (protected).
164.	EZNC_FILE_COPY_DIFFER	0x80030405	Verification error.
165.	EZNC_FILE_COPY_NOTSUPPORTED	0x80030449	Verification function is not supported.
166.	EZNC_FILE_COPY_EXECUTING	0x8003044C	Copying file.
167.	EZNC_FILE_COPY_NOTOPEN	0x80030490	File is not open.
168.	EZNC_FILE_COPY_WRITE_WARNING	0x80030495	Transfer destination file is not writable.
169.	EZNC_FILE_COPY_SAFETYPWLOCK	0x8003044D	Safety password locked.
170.	EZNC_FILE_COPY_ILLEGALFORMAT	0x8003049D	Invalid file format.
171.	EZNC_FILE_COPY_WRONGPASSWORD	0x8003049E	Password is wrong.
172.	EZNC_PCFILE_COPY_CREATE	0x800304A4	File cannot be created (personal computer only).
173.	EZNC_PCFILE_COPY_OPEN	0x800304A3	File cannot be opened (personal computer only).
174.	EZNC_PCFILE_COPY_FILEEXIST	0x80030402	Copy destination file already exists.
175.	EZNC_PCFILE_COPY_ILLEGALNAME	0x800304A7	Invalid file name format.
176.	EZNC_PCFILE_COPY_NODIR	0x800304A2	Directory does not exist.
177.	EZNC_PCFILE_COPY_NODRIVE	0x800304A8	Drive does not exist.
178.	EZNC_PCFILE_COPY_NOFILE	0x800304A1	File does not exist.
179.	EZNC_PCFILE_COPY_READ	0x800304A5	Transfer source file is not readable.
180.	EZNC_PCFILE_COPY_WRITE	0x800304A6	Transfer destination file is not writable.
181.	EZNC_PCFILE_COPY_MEMORYOVER	0x80030406	Disk space exceeded.
182.	EZNC_PCFILE_COPY_NOTOPEN	0x800304A0	File is not open.
183.	EZNC_FILE_DEL_NOTDELETE	0x80030201	File cannot be deleted.
184.	EZNC_FILE_DEL_NOFILE	0x80030242	File does not exist.
185.	EZNC_FILE_DEL_FILESYSTEM	0x80030243	File system error.
186.	EZNC_FILE_DEL_BUSY	0x80030247	Deletion is disabled (during operation).
187.	EZNC_FILE_DEL_NAMELENGTH	0x80030248	File name is too long.
188.	EZNC_FILE_DEL_PROTECT	0x8003024A	Deletion is disabled (protected).
189.	EZNC_FILE_DEL_NODIR	0x80030291	Directory does not exist.
190.	EZNC_FILE_DEL_ILLEGALNAME	0x80030298	Invalid file name format.
191.	EZNC_FILE_DEL_NODRIVE	0x8003029B	Drive does not exist.
192.	EZNC_PCFILE_DEL_NOTDELETE	0x80030202	File cannot be deleted.
193.	EZNC_PCFILE_DEL_ILLEGALNAME	0x800302A7	Invalid file name format.
194.	EZNC_PCFILE_DEL_NODIR	0x800302A2	Directory does not exist.
195.	EZNC_PCFILE_DEL_NODRIVE	0x800302A8	Drive does not exist.
196.	EZNC_PCFILE_DEL_NOFILE	0x800302A1	File does not exist.
197.	EZNC_FILE_REN_FILEEXIST	0x80030301	New file name already exists.
198.	EZNC_FILE_REN_NOFILE	0x80030342	File does not exist.
199.	EZNC_FILE_REN_FILESYSTEM	0x80030343	File system error.
200.	EZNC_FILE_REN_BUSY	0x80030347	Renaming is disabled (during operation).

No.	Error code	Number	Description
201.	EZNC_FILE_REN_NAMELENGTH	0x80030348	File name is too long.
202.	EZNC_FILE_REN_PROTECT	0x8003034A	Renaming is disabled (protected).
203.	EZNC_FILE_REN_NODIR	0x80030391	Directory does not exist.
204.	EZNC_FILE_REN_ILLEGALNAME	0x80030398	Invalid file name format.
205.	EZNC_FILE_REN_NODRIVE	0x8003039B	Drive does not exist.
206.	EZNC_PCFILE_REN_NOTRENAME	0x80030303	Renaming is disabled.
207.	EZNC_PCFILE_REN_SAMENAME	0x80030305	New and old file names are identical.
208.	EZNC_PCFILE_REN_FILEEXIST	0x80030302	New file name already exists.
209.	EZNC_PCFILE_REN_ILLEGALNAME	0x800303A7	Invalid file name format.
210.	EZNC_PCFILE_REN_NODIR	0x800303A2	Directory does not exist.
211.	EZNC_PCFILE_REN_NODRIVE	0x800303A8	Drive does not exist.
212.	EZNC_PCFILE_REN_NOFILE	0x800303A1	File does not exist.
213.	EZNC_FILE_DISKFREE_NODIR	0x80030691	Directory does not exist.
214.	EZNC_FILE_DISKFREE_NODRIVE	0x8003069B	Drive does not exist.
215.	EZNC_FILE_DISKFREE_FILESYSTEM	0x80030643	File system error.
216.	EZNC_FILE_DISKFREE_NAMELENGTH	0x80030648	File name is too long.
217.	EZNC_FILE_DISKFREE_ILLEGALNAME	0x80030648	Invalid file name format.
218.	EZNC_PCFILE_DISKFREE_NODIR	0x800306A2	Directory does not exist (personal computer only).
219.	EZNC_PCFILE_DISKFREE_NODRIVE	0x800306A8	Drive does not exist (personal computer only).
220.	EZNC_FILE_DRVLIST_DATASIZE	0x80030701	Application does not fit into prepared buffer.
221.	EZNC_FILE_DRVLIST_READ	0x80030794	Drive information read error.
222.	EZNC_ENET_ALREADYOPEN	0x82020001	Already open.
223.	EZNC_ENET_NOTOPEN	0x82020002	Not open.
224.	EZNC_ENET_CARDNOTEXIST	0x82020004	Card does not exist.
225.	EZNC_ENET_BADCHANNEL	0x82020006	Invalid channel number.
226.	EZNC_ENET_BADFD	0x82020007	Invalid file descriptor.
227.	EZNC_ENET_NOTCONNECT	0x8202000A	Not connected.
228.	EZNC_ENET_NOTCLOSE	0x8202000B	Not closed.
229.	EZNC_ENET_TIMEOUT	0x82020014	Time-out.
230.	EZNC_ENET_DATAERR	0x82020015	Invalid data.
231.	EZNC_ENET_CANCELED	0x82020016	Terminated by cancel request.
232.	EZNC_ENET_ILLEGALSIZ	0x82020017	Invalid packet size.
233.	EZNC_ENET_TASKQUIT	0x82020018	Terminated due to by end of task.
234.	EZNC_ENET_UNKNOWNFUNC	0x82020032	Invalid command.
235.	EZNC_ENET_SETDATAERR	0x82020033	Invalid setting data.
236.	EZNC_READ_CACHE_REGIST	0x80060001	Invalid data read cache.
237.	EZNC_READ_CACHE_ADDR	0x80060090	Invalid address.
238.	EZNC_READ_CACHE_SECT	0x80060091	Invalid section number.
239.	EZNC_READ_CACHE_SUBSECT	0x80060092	Invalid subsection number.
240.	EZNC_READ_CACHE_DATATYPE	0x80060097	Invalid data type.
241.	EZNC_READ_CACHE_DATA	0x8006009A	Invalid data range.
242.	EZNC_READ_CACHE_READ	0x8006009D	Data is not readable.
243.	EZNC_READ_CACHE_WRITEONLY	0x8006009F	Invalid data type.
244.	EZNC_READ_CACHE_AXIS	0x800600A0	Invalid axis specification.
245.	EZNC_FS_OPEN_FILE_MALLOC	0x80070140	Work area cannot be allocated.
246.	EZNC_FS_OPEN_FILE_OPEN	0x80070142	File cannot be opened.
247.	EZNC_FS_OPEN_FILE_BUSY	0x80070147	File cannot be opened (during operation).
248.	EZNC_FS_OPEN_FILE_NAMELENGTH	0x80070148	File path is too long.
249.	EZNC_FS_OPEN_FILE_NOTSUPPORTED	0x80070149	Not supported (CF not supported).
250.	EZNC_FS_OPEN_FILE_ALREADYOPEN	0x80070192	Already open.

No.	Error code	Number	Description
251.	EZNC_FS_OPEN_FILE_FILEFULL	0x80070199	Maximum number of open files exceeded.
252.	EZNC_FS_OPEN_FILE_ALREADYOPEN	0x80070192	Already open.
253.	EZNC_FS_OPEN_FILE_SORT	0x8007019F	Cannot open while sorting tool data.
254.	EZNC_FS_OPEN_FILE_SAFE_NOPASSWD	0x800701B0	Safety password not authenticated.
255.	EZNC_FS_CLOSE_FILE_NOTOPEN	0x80070290	File is not open.
256.	EZNC_FS_CREATE_FILE_MALLOC	0x80070340	Work area cannot be allocated.
257.	EZNC_FS_CREATE_FILE_BUSY	0x80070347	File cannot be created (during operation).
258.	EZNC_FS_CREATE_FILE_NAMELENGTH	0x80070348	File path is too long.
259.	EZNC_FS_CREATE_FILE_NOTSUPPORTED	0x80070349	Not supported (CF not supported).
260.	EZNC_FS_CREATE_FILE_ALREADYOPEN	0x80070392	Already created.
261.	EZNC_FS_CREATE_FILE_CREATE	0x80070393	File cannot be created.
262.	EZNC_FS_CREATE_FILE_FILEFULL	0x80070399	Maximum number of open files exceeded.
263.	EZNC_FS_CREATE_FILE_NODRIVE	0x8007039B	Drive does not exist.
264.	EZNC_FS_READ_FILE_NOTOPEN	0x80070490	File is not open.
265.	EZNC_FS_READ_FILE_READ	0x80070494	File information read error.
266.	EZNC_FS_WRITE_FILE_NOTSUPPORTED	0x80070549	Write is not available.
267.	EZNC_FS_WRITE_FILE_NOTOPEN	0x80070590	File is not open.
268.	EZNC_FS_WRITE_FILE_WRITE	0x80070595	File write error.
269.	EZNC_FS_REMOVE_FILE_REMOVEERR	0x80070740	File deletion error.
270.	EZNC_FS_REMOVE_FILE_NOFILE	0x80070742	File does not exist.
271.	EZNC_FS_REMOVE_FILE_BUSY	0x80070747	File cannot be deleted (during operation).
272.	EZNC_FS_REMOVE_FILE_NAMELENGTH	0x80070748	File path is too long.
273.	EZNC_FS_REMOVE_FILE_NOTSUPPORTED	0x80070749	Not supported (CF not supported).
274.	EZNC_FS_REMOVE_FILE_ALREADYOPEN	0x80070792	File is already open.
275.	EZNC_FS_REMOVE_FILE_NODRIVE	0x8007079B	Drive does not exist.
276.	EZNC_FS_RENAME_FILE_NOFILE	0x80070842	File does not exist.
277.	EZNC_FS_RENAME_FILE_NOTRENAME	0x80070843	File cannot be renamed.
278.	EZNC_FS_RENAME_FILE_NAMELENGTH	0x80070848	File path is too long.
279.	EZNC_FS_RENAME_FILE_NOTSUPPORTED	0x80070849	Not supported (CF not supported).
280.	EZNC_FS_RENAME_FILE_ALREADYOPEN	0x80070892	File is already open.
281.	EZNC_FS_RENAME_FILE_FILEFULL	0x80070899	Maximum number of open files exceeded.
282.	EZNC_FS_RENAME_FILE_NODRIVE	0x8007089B	Drive does not exist.
283.	EZNC_FS_IOCTL_FILE_FUNCTION	0x80070944	Invalid command (not supported).
284.	EZNC_FS_IOCTL_FILE_NOTOPEN	0x80070990	Not open.
285.	EZNC_FS_IOCTL_FILE_READ	0x80070994	Read error.
286.	EZNC_FS_IOCTL_FILE_WRITE	0x80070995	Write error.
287.	EZNC_FS_IOCTL_FILE_DATASIZE	0x80070996	Application does not fit into prepared buffer.
288.	EZNC_FS_IOCTL_FILE_DATATYPE	0x80070997	Invalid data type.
289.	EZNC_FS_IOCTL_FILE_NOTSUPPORTED	0x80070949	Not supported (CF not supported).
290.	EZNC_FS_OPEN_DIR_MALLOC	0x80070A40	Work area cannot be allocated.
291.	EZNC_FS_OPEN_DIR_BUSY	0x80070A47	Directory cannot be opened (during operation).
292.	EZNC_FS_OPEN_DIR_NAMELENGTH	0x80070A48	File path is too long.
293.	EZNC_FS_OPEN_DIR_NOTSUPPORTED	0x80070A49	Not supported (CF not supported).
294.	EZNC_FS_OPEN_DIR_NODIR	0x80070A91	Directory does not exist.
295.	EZNC_FS_OPEN_DIR_NOTOPEN	0x80070A92	Already open.
296.	EZNC_FS_OPEN_DIR_FILEFULL	0x80070A99	Maximum number of open directories exceeded.
297.	EZNC_FS_OPEN_DIR_NODRIVE	0x80070A9B	Drive does not exist.
298.	EZNC_FS_READ_DIR_NOTOPEN	0x80070B90	Directory is not open.
299.	EZNC_FS_READ_DIR_NODIR	0x80070B91	Directory does not exist.
300.	EZNC_FS_READ_DIR_DATASIZE	0x80070B96	Application does not fit into prepared buffer.


No.	Error code	Number	Description
301.	EZNC_FS_CLOSE_DIR_NOTOPEN	0x80070D90	Directory is not open.
302.	EZNC_FS_STAT_FILE_NAMELENGTH	0x80070E48	File path is too long.
303.	EZNC_FS_STAT_FILE_NOTSUPPORTED	0x80070E49	Supported (CF not supported).
304.	EZNC_FS_STAT_FILE_STATERR	0x80070E94	File information read error.
305.	EZNC_FS_STAT_FILE_FILEFULL	0x80070E99	Maximum number of open files exceeded.
306.	EZNC_FS_STAT_FILE_NODRIVE	0x80070E9B	Drive does not exist.
307.	EZNC_FS_FSTAT_FILE_NAMELENGTH	0x80070F48	File path is too long.
308.	EZNC_FS_FSTAT_FILE_NOTSUPPORTED	0x80070F49	Not supported (CF not supported).
309.	EZNC_FS_FSTAT_FILE_STATERR	0x80070F94	File information read error.
310.	EZNC_FS_FSTAT_FILE_NOTOPEN	0x80070F90	File is not open.
311.	EZNC_FS_FSTAT_FILE_NODRIVE	0x80070F9B	Drive does not exist.
312.	EZNC_FS_IOCTL_UOPEN_FORMAT	0x8007099C	Formatting canceled because of invalid SRAM open parameter.
313.	Error codes output by NC control unit.	0xF00000FF	Invalid argument.
314.	Error codes output by NC control unit.	0xFFFFFFFF	Data is not readable/writable.
315.	Error codes output by EZSocket (EZSocketPc) for MELSEC programmable controllers (C70 only)	0x01XXXXXX 0x02XXXXXX 0x03XXXXXX 0x04XXXXXX 0x10XXXXXX	For details, refer to the following manuals: <ul style="list-style-type: none"> • EZSocket Standard, Reference Manual (for MELSEC)(BAD-801Q013) • EZSocket Pro-FX CPU-supported Edition, Reference Manual (for MELSEC)(BAD-801Q025)

4. API OPERATING PROCEDURE

4.1 API Operating Procedure

This section provides instructions and procedures for using the product.

Use the product by performing the following steps:



4.2 Initialization for Enabling OLE/COM Interface

The product uses the OLE/COM interface. Thus, the VC++ project must support OLE/COM. For the project that was created without OLE/COM being enabled, it is possible to enable OLE/COM by modifying appropriate parts of the two files created by VC++, as shown below.

Note that a project name is *Project* in the explanation below.

Project.cpp

```
BOOL CProjectApp::InitInstance()
```

```
{
```

```
    // Initialize OLE library.
    if (!AfxOleInit())
    {
        // Show error message.
        return FALSE;
    }
```

```
    // The rest is omitted.
```

```
}
```

Stdafx.h

```
// stdafx.h: Describes standard system include files
```

```
//           or project specific include files that are used frequently
```

```
//           but changed infrequently.
```

```
//
```

```
#define VC_EXTRALEAN           // Excludes rarely-used stuff from Windows headers.
```

```
//
```

```
#include <afxwin.h>           // MFC core and standard components
```

```
#include <afxext.h>          // MFC extensions
```

```
#include <afxdisp.h>         // MFC OLE/COM
```

```
#ifndef _AFX_NO_AFXCMN_SUPPORT
```

```
#include <afxcmn.h>          // MFC support for Windows Common Controls
```

```
#endif // _AFX_NO_AFXCMN_SUPPORT
```

4.3 Object Creation

The product uses the OLE/COM interface; therefore, objects must be created/released in the thread where OLE/COM initialization was performed. This is not a matter of concern if your program is single-threaded.

In the sample below, the application is for displaying position data, and it is display-centric and single-threaded. Thus, objects are created when the View window is created, and released when the window is closed.

First, create an IEZNCCommunication3 communication object by using CoCreateInstance in the COM library. Then, from the created communication object, create an IEZNCPosition object and other objects by using QueryInterface. The following shows how to create IEZNCCommunication3 and IEZNCPosition objects.

Table 4-1 Creation of IEZNCCommunication3 object

Creation of IEZNCCommunication3 communication object	
Calling procedure	<pre> CLSIDs clsid; IEZNCCommunication pComm; HRESULT hr = CLSIDFromProgID(L"EZSocketNc.EZNCCommunication",&clsid); *1 hr = CoCreateInstance(clsid, NULL, CLSCTX_INPROC_SERVER, IID_IEZNCCommunication3, (VOID**)&pComm); </pre>
Return value	S_OK is returned if the object is successfully created, and if not, another value is returned.
Function	Creates a communication object and returns its address in the parameter pComm.

*1 Refer to *2 in "1.8.1 VC++ program flow (1)".

Table 4-2 Creation of IEZNCPosition object

Creation of IEZNCPosition parameter object	
Calling procedure	<pre> IEZNCPosition pPos; HRESUTL hr = pComm->QueryInterface(IID_IEZNCPosition,(void**)&pPos); </pre>
Return value	S_OK is returned if the object is successfully created, and if not, another value is returned.
Function	Creates a parameter object and returns its address in the parameter pPos.

4.4 Include Files

To use the product, include the following header files in the project as necessary.

```

#include "EZSocketNc.h"           ..... Header file for method definitions
#include "EZSocketNcStr.h"       ..... Header file for structure definitions (*)
#include "EZSocketNcDef.h"       ..... Header file for miscellaneous definitions
#include "EZSocketNcErr.h"       ..... Header file for error definitions
#include "EasysocketDef.h"       ..... Header file for miscellaneous definitions (*)
    
```

(*) These are necessary when the product is used in the C70.

4.5 Overview of VB Programming of Automation Interface

This section explains programming with Microsoft Visual Basic (hereinafter referred to as "VB"). The VC++ programs and VB programs can be written in a similar flow; therefore, VB can be used to create a prototype of your application and verify it at an early stage.


VB's functions that assist programming also help make programming efficient.

4.5.1 Using OLE automation interface with VB


(1) Setting references: Check (select) object libraries.

This section describes a way to enable early binding by setting references. Setting references will enable VB's object browsing function.

(Install the product prior to this procedure.)




(2) Object browser: In your programming window, select the EZNCCommunication object.



Object browser

(3) Method browser: In your programming window, select a method for the EZNcCom object and check its argument.




Method browser

(4) Module file: Sets definitions and error code references.

Add a module file so that the definitions of the product and error codes can be used in the VB. Select "Project", "Add a standard module", and then "Existing file" to add EZNcDef.bas, EZNcErr.bas, and EZComErr.bas module files to the project.

Definitions and error codes can now be referred to easily through VB's object browser function.



4.5.2 VB program flow (1)


This section shows the flow of the program that uses early binding. Reference setting in the product is required.

```
Private Sub Command1_Click()  
    'Create object.  
    Dim EZNcCom As New DispEZNcCommunication  
  
    'Open communication.  
    Dim IRet As Long  
    IRet = EZNcCom.Open2(EZNC_SYS_MAGICBOARD64, 1, 1)  
    If IRet <> 0 Then GoTo Error_Proc  
  
    'Processing  
    IRet = EZNcCom.SetHead(1)  
    If IRet <> 0 Then GoTo Error_Proc  
  
    Dim CurPos(1 To 3) As Double  
    For Axis = 1 To 3  
        IRet = EZNcCom.Position_GetCurrentPosition(Axis, CurPos(Axis))  
        If IRet <> 0 Then GoTo Error_Proc  
    Next Axis  
  
    X.Text = CurPos(1)  
    Y.Text = CurPos(2)  
    Z.Text = CurPos(3)  
  
    'Close.  
    IRet = EZNcCom.Close  
    If IRet <> 0 Then GoTo Error_Proc  
  
    GoTo Last_Proc  
Error_Proc:  
    MsgBox ("Error! Code = " + "&H" + CStr(Hex(IRet)))  
Last_Proc:  
    'Release object.  
    Set EZNcCom = Nothing  
End Sub
```

4.5.3 VB program flow (2)

This section shows the flow of the program that uses late binding. Reference setting in the product is not required. Note that the object browser function with VB cannot be used.

```
Private Sub Command1_Click()  
    'Create object.  
    Dim EZNcCom As Object  
    Set EZNcCom = CreateObject("EZNcAut.DispEZNcCommunication","10.20.123.12")  
  
    'Open communication.  
    Dim IRet As Long  
    IRet = EZNcCom.Open2(EZNC_SYS_MAGICBOARD64, 1, 1)  
    If IRet <> 0 Then GoTo Error_Proc  
  
    'Processing  
    IRet = EZNcCom.SetHead(1)  
    If IRet <> 0 Then GoTo Error_Proc  
  
    Dim CurPos(1 To 3) As Double  
    For Axis = 1 To 3  
        IRet = EZNcCom.Position_GetCurrentPosition(Axis, CurPos(Axis))  
        If IRet <> 0 Then GoTo Error_Proc  
    Next Axis  
  
    X.Text = CurPos(1)  
    Y.Text = CurPos(2)  
    Z.Text = CurPos(3)  
  
    'Close.  
    IRet = EZNcCom.Close  
    If IRet <> 0 Then GoTo Error_Proc  
  
    GoTo Last_Proc  
Error_Proc:  
    MsgBox ("Error! Code = " + "&H" + CStr(Hex(IRet)))  
Last_Proc:  
    'Release object.  
    Set EZNcCom = Nothing  
End Sub
```



(Note) For the first argument setting of CreateObject(), refer to *2 in "1.8.1 VC++ program flow (1)".

5. APPLICATION INSTALLATION PROCEDURE

5.1 Overview

To redistribute the application that uses the product and to run it on other computers, it is necessary to copy the user-developed software modules as well as files contained in the product to the computers, and set them properly in their system registry.

This section provides the guideline and the procedure for these steps.

There are two methods to redistribute the product. Choose one that suits your application environment.

- (1) Method to use the redistribution installer contained in the enclosed DVD-ROM.
- (2) Method to use your own installer created according to the redistribution procedure.

<<Tips and Precautions for selecting a method>>

The method (1) above is time saving in that the installer does not need to be created. It is still necessary to add a mechanism to execute the redistribution installer from your application's installer.

For the method (2), the installer created according to the redistribution procedure can be directly and suitably embedded to your application's installer. This method is suitable especially when it is difficult to embed the redistribution installer in your application's installer.

Please be aware that the product may be used by more than one application. When installing/uninstalling your application, please make sure to follow the instructions and procedures specified in this document, to avoid causing problems to the operation of other applications.

<<Installation specifications for different platforms>>

The installation specifications of the product are different for different platforms. The table shows the differences in the specifications.

Table 5-1 Installation specifications for different platforms

Operating environment Specifications	x86 platform	x64 platform
		EZSocket (32-bit)
Destination of installation	Recommended folder (Any folder may be specified.) %ProgramFiles%\EZSocket	Recommended folder (*1) %ProgramFiles%\EZSocket
Actual destination of installation	c:\Program Files └ \EZSocket * This applies when recommended values are specified.	c:\Program Files (x86) └ \EZSocket * This applies when recommended values are specified.
Destination registry	HKEY_LOCAL_MACHINE └ SOFTWARE └ MITSUBISHI └ EZSocketNc	HKEY_LOCAL_MACHINE └ SOFTWARE └ Wow6432Node └ MITSUBISHI └ EZSocketNc

(*1) For x64 platform, install the product in the recommended folder.

5.2 Distribution Method with Redistribution Installer

This section explains the redistribution method that uses the redistribution installer contained in the enclosed DVD-ROM.

Distribution is easy with the redistribution installer because it has been created in compliance with "5.3 Terms of Redistribution".

5.2.1 Location where redistribution installer is stored

The redistribution installer that can be embedded in your product is stored in the following folder on the enclosed DVD-ROM:

EZSocketNc\RedistributableInstaller

5.2.2 Destination where redistribution installer is installed

The product is installed in the location specified in the INI file described in the section 5.2.3. Any location may be specified. (Note that this applies only when the product is installed on the target computer for the first time. If the product already exists on the computer, it must be installed in the existing directory and the new installation overwrites the old one.)

For x64 platform, install the product in the recommended folder, C:\Program Files (x86)\EZSocket.

5.2.3 Specifications for redistribution installer INI file

This file is used for interaction between your product's installer and the redistribution installer.




Section	Key	Description	I/O
USER	Name	User name.	IN
	Company	Company name.	
SETUP	Target	Installation destination folder. The recommended folder is %ProgramFiles%\EZSocket. If this key is not specified, the product is installed in the recommended folder. Example) C:\Program Files\EZSocket Specify the full path of the folder. (Environment variables cannot be used.)	
ERROR	ERROR	Error flag 0: No error 1: Error occurred	OUT
	DETAIL	Error details 0: Other error 1: Insufficient capacity in installation destination * When ERROR=0, this key is not set.	
DOINSTALL	START	1: Start installation	
	END	1: End installation	

5.2.4 Processing flow and specifications of redistribution installer

This section explains the processing flow and specifications of the redistribution installer.

Make sure to perform thorough operation check when embedding the redistribution installer in your product.

No.	Processing flow	Specifications
1	Your product's installer is executed.	<p>Your product's installer should:</p> <p>Create an EZSNCSET.INI file in the folder that can be managed by your product's installer. The specifications of the EZSNCSET.INI file are as follows:</p> <p>[Specifications of EZSNCSET.INI]</p> <div style="border: 1px solid black; padding: 5px;"> <pre>[USER] Name=user name (maximum 256 bytes) Company=user's company name (maximum 256 bytes) [SETUP] Target=path to installation destination</pre> </div> <p>[USER] section: Register the Name value under Name in Table 5-2. Register the Company value under Organization in Table 5-2.</p> <p>[SETUP] section: Register the Target value to InstallPath in Table 5-2. However, if InstallPath is already registered, prioritize it.</p> <p>The product is installed in (Target)\EZSocketNc. It is recommended that the following folder be specified as Target:</p> <p>x86 platform: Target=C:\Program Files\EZSocket</p> <p>x64 platform: Target=C:\Program Files (x86)\EZSocket</p> <p>[Example of EZSNCSET.INI]</p> <div style="border: 1px solid black; padding: 5px;"> <pre>[USER] Name=Taro Mitsubishi Company=Mitsubishi Electric Corporation [SETUP] Target=C:\Program Files\EZSocket</pre> </div>
2	Your product's installer executes the redistribution installer.	<p>Execute the redistribution installer's Setup.exe, which is stored on your product's media (for example, DVD-ROM), with the following command line: Setup.exe△full path to where EZSNCSET.INI is located where the symbol △ means a space.</p> <p>Example) Setup.exe C:\temp Place EZSNCSET.INI in the C:\temp folder.</p>

No.	Processing flow	Specifications
3	<p>The window that indicates that the redistribution installer is preparing is displayed.</p> 	<p>The installation preparation window is displayed. If the language of the operating system is other than Japanese, the display language is English.</p>
4	<p>Make sure that your product's installer refers to the START value of the [DOINSTALL] section of EZSNCSET.INI, and that the redistribution installer has started. (*1)</p>	<p>Set the installation start flag in the EZSNCSET.INI.</p> <p>Specifications of [EZSNCSET.INI]</p> <div style="border: 1px solid black; padding: 5px;"> <pre>[USER] Name=user name (maximum 256 bytes) Company=user's company name (maximum 256 bytes) [SETUP] Target=EZSocket installation folder [DOINSTALL] START=1</pre> </div> <p>[DOINSTALL] section: The redistribution installer sets the START value to 1 when the installation is started, and the END value to 1 when the installation is completed.</p>
5	<p>The "Installing..." window is displayed.</p> 	<p>Perform the installation. If the language of the operating system is other than Japanese, the display language is English.</p>
6	<p>The "Registering registry" window is displayed.</p> 	<p>Register registry information required for this product according to the installation procedure. If the language of the operating system is other than Japanese, the display language is English.</p>
7	<p>When the registry registration is completed, the window closes and the installation finishes.</p>	<p>When the registry registration is completed, the "Registering registry" window closes and the installation finishes.</p>

8	<p>Make sure that your product's installer refers to the END value of the [DOINSTALL] section of EZSNCSET.INI, and that the redistribution installer is completed. (*1)</p> <p>Also, check the ERROR and DETAIL values in the [ERROR] section of EZSNCSET.INI, and perform post-installation processes.</p> <p>If the redistribution installer is abnormally terminated, resolve the error status, and then execute the installer by following the procedure again. For common errors, refer to 5.2.5 Troubleshooting.</p>	<p>After the installer is finished, record results in EZSNCSET.INI.</p> <p>Specifications of [EZSNCSET.INI]</p> <div style="border: 1px solid black; padding: 5px;"> <pre> [USER] Name=user name (maximum 256 bytes) Company=user's company name (maximum 256 bytes) [SETUP] Target=Installation destination folder [DOINSTALL] START=1 END=1 [ERROR] Error=0 *0=completed successfully, 1=terminated abnormally </pre> </div> <p>[ERROR] section: The Error value is set to 0 when the installation is successfully completed, and set to 1 when it is abnormally terminated. When ERROR=1, set error details to the DETAIL key.</p>
9	Your product's installer deletes EZSNCSET.INI.	EZSNCSET.INI must be deleted at the end because it is a common file.

(*1) Refer to "5. 2. 6 Precautions".

5.2.5 Troubleshooting

This section explains how to handle errors that may occur in the installer.


No	Error case	Action
1.	<p>If EZSNCSET.INI is invalid, the window below is displayed. Click [OK] to close. If the language of the operating system is other than Japanese, the display language is English.</p> 	<p>[Possible cause] 1) User name or user company name cannot be obtained. 2) User name/user company name exceeds 256-byte limit.</p> <p>[Action] EZSNCSET.INI</p> <div style="border: 1px solid black; padding: 2px;">[ERROR] Error=1</div> <p>Check the contents of EZSNCSET.INI, and set them correctly. Or, place EZSNCSET.INI in the specified folder.</p>
2.	<p>If the path to the installation destination is incorrect, the window below is displayed. Click [OK] to close. If the language of the operating system is other than Japanese, the display language is English.</p> 	<p>[Possible cause] The read path to the installation destination is incorrect.</p> <p>[Action] EZSNCSET.INI</p> <div style="border: 1px solid black; padding: 2px;">[ERROR] Error=1</div> <p>The path specified in Target of EZSNCSET.INI is incorrect. Set the path correctly.</p>

5.2.6 Precautions

Starting of redistribution installer

If your product's installer uses the `LaunchAppAndWait()` function to start the redistribution installer, it may give a return value before the installation of the product is completed. To avoid this, it is necessary to have your product's installer monitor the completion of the redistribution installer.

For this monitoring, use the `START` and `END` values in the `[DOINSTALL]` section of `EZSNCSET.INI`. For the specifications of the INI file, refer to section 5. 2. 3.



* The installer cannot set the `START` value in the `[DOINSTALL]` section if the cancel button is pressed on the InstallShield initial screen. Make sure to set time-outs for waiting for start.

5.3 Terms of Redistribution

This section describes the terms of redistribution of the product.

5.3.1 Redistributable modules

Modules that can be redistributed are as follows:

- Redistributable files contained in the product

Upon installation of the product on your development machine, these files are installed on the hard disk of the machine. To make sure that the files of the correct version are distributed when redistributing the product, copy the product from the installation DVD-ROM, not from the hard disk, and then embed it in a disk for distribution.

5.3.2 Redistributable files

The following files that are stored on the installation DVD-ROM are redistributable. Make sure to redistribute both the custom and automation interfaces. The following files need to be same version; otherwise, an error may occur.

\\Lib\\EZSocketNc.dll: DLL for custom interface

\\Lib\\EZNcAutxxx.dll: DLL for automation interface

(where xxx in the file name represents a version-specific number.)

\\Lib\\CommServer: Related folder

\\Lib\\Parameter: Related folder

\\Lib\\Ini\\melcfg.ini: Initialization file

5.4 Installation Procedure

5.4.1 Version upgrade of redistributable files

The redistributable files with the same name but with different versions (older or newer) may be distributed by different applications. In such cases, make sure that the newer version overwrites the older version, not the other way around. Normally the setup program performs version check. If the application does not have a setup program, the user needs to manually check the version before embedding the redistribution program. (Note 1) If the initialization file melcfg.ini already exists on the personal computer, do not overwrite it however old it may be.

(Note 2) The DLL file name of the automation interface is different for different versions. Do not delete the automation interface file that has already been installed. It will cause the application compatible with the automation interface that has already been installed to fail-to start.

5.4.2 x86 platform

5.4.2.1 Installation directory for files

When installing the product for the first time, it can be installed in any directory. For the second or later installation, it must be installed in the directory where the product already exists so that more than one product does not exist on the same computer.

To meet this requirement, follow the procedure below.

(1) Determine if it is the first-time installation or not

Check if the following registry key exists and the correct path to the installation directory is registered as its data.

Registry key: HKEY_LOCAL_MACHINE\SOFTWARE\MITSUBISHIEZSocketNc\CurrentVersion\InstallPath

Data (Example): C:\Program Files\EZSocket\EZSocketNc

If the correct path name is registered as registry key data, the product is considered to have been installed once or more, and if not, for instance, the registry key does not exist, or the path name is not registered, the product is considered to have never been installed for the first time. Do not add "\" to the end of the path, or related files cannot be read.

(2) Installing for the first time

Have the user specify the installation directory through a dialog or other appropriate method. Register the directory in the registry as installation directory. Other registry settings also need to be configured at this time. For details about registry settings, refer to "5.4.2.3 Registry settings".

(3) Installing from the second time onward

Install the product in the installation directory that is registered to the registry. If the installation directory does not exist, create one. When copying files, make sure not to overwrite the new version with the old version.


5.4.2.2 Configuration of installation directory

The configuration of the installation directory is shown below:

Copy all files stored on the installation DVD-ROM to the directory as follows:

Installation directory

Path to the installation files in the installation DVD-ROM



5.4.2.3 Registry settings

Registries required for the product to run are listed below:

When installing the product, create the registry structure as shown, and register data accordingly.

Table 5-2 List of registries

Key	Name	Type	Data	Remarks
HKEY_LOCAL_MACHINE				
└ SOFTWARE				
└└ MITSUBISHI				
└└└ EZSocketNc				
└└└└ CurrentVersion	Description	Character string	"EZSocketNc"	Fixed data.
└└└└└ Organization	Organization	Character string	User-specified company name	Register the company name specified by the user at the time of installation.
└└└└└ Name	Name	Character string	User-specified user name	Register the user name specified by the user at the time of installation.
└└└└└ MajorVersion	MajorVersion	DWORD value	Version	
└└└└└ MinorVersion	MinorVersion	Character string	Version	
└└└└└ InstallPath (Note 1)	InstallPath (Note 1)	Character string	"User-specified directory \EZSocketNc"	Register the path specified by the user at the time of installation.
└└└└└ Custom	FileVersion (Note 2)	Character string	Date of EZSocketNc.dll file	YYYY-MM-DD format.
└└└└└└ EZSocketNcName	EZSocketNcName	Character string	"EZSocketNc.dll"	Fixed data.
└└└└└ Automation	FileVersion (Note 2)	Character string	Date of EZNcAut.dll file	YYYY-MM-DD format.
└└└└└└ EZSocketNcName	EZSocketNcName	Character string	"EZNcAutxxx.dll"	xxx are numeric characters.

(Note 1) The data to be registered to "InstallPath" must be "drive: directory specified by the user at the time of package installation + \EZSocketNc".

(Note 2) After copying installation files to the HD, get the time stamp of the specified file, and register this data as "FileVersion".

5.4.2.4 System environment variable settings

The system environment variable required for the product to run is shown below.

When installing the product, register it as an additional system environment variable.

The default value is shown in the list below. If the file is not in the specified path, change the path.

Table 5-3 List of system environment variable

Model	System environment variable (default value)
M700/M800	PATH=installation path of the product (Example: C:\EZSocket\EZSocketNc)

5.4.2.5 COM information registry settings

For EZSocketNc.dll and EZNcAutxxx.dll stored in the installation directory, COM information must be registered to the registry. To register the information, use the redistributable REGSVR32.EXE command, which is shipped with Microsoft Visual C++, at the time of installation. The information is registered as follows:

```
REGSVR32 /s installation directory\EZSocketNc.dll  
REGSVR32 /s installation directory\EZNcAutxxx.dll
```

5.4.2.6 Precautions for uninstallation

The product may be used by more than one application. If that is the case, and if the product is deleted by uninstalling one of the applications that are installed, the operation of the remaining applications will be affected. To avoid this, do not delete the files and the registry of the product by uninstalling the application in which the product is embedded.

5.4.3 x64 platform

5.4.3.1 Installation directory for files

Install the files to %ProgramFiles%\EZSocket.

Register the installation destination directory to the registry as installation directory. Other registry settings also need to be configured at this time. When copying files, make sure not to overwrite the new version with the old version.

Registry key:

HKEY_LOCAL_MACHINE\SOFTWAREWow6432Node\MITSUBISHI\EZSocketNc\CurrentVersion\InstallPath

Data (example): C:\Program Files (x86)\EZSocket\EZSocketNc\


5.4.3.2 Configuration of Installation directory

The configuration of the installation directory is shown below:

Copy all files stored on the installation DVD-ROM to the directory as follows:

Installation directory

Path to the installation files in the installation DVD-ROM



5.4.3.3 Registry settings

Registries required for the product to run are listed below:

When installing the product, create the registry structure as shown, and register data accordingly.

Table 5-4 List of registries

Key	Name	Type	Data	Remarks
HKEY_LOCAL_MACHINE				
└ SOFTWARE				
└─ Wow6432Node				
└─ MITSUBISHI				
└─ EZSocketNc				
CurrentVersion	Description	Character string	"EZSocketNc"	Fixed data.
	Organization	Character string	User-specified company name	Register the company name specified by the user at the time of installation.
	Name	Character string	User-specified user name	Register the user name specified by the user at the time of installation.
	MajorVersion	DWORD value	Version	
	MinorVersion	Character string	Version	
	InstallPath (Note 1)	Character string	"%ProgramFiles%directory\EZSocket\EZSocketNc"	Register the path specified by the user at the time of installation.
Custom	FileVersion (Note 2)	Character string	Date of EZSocketNc.dll file	YYYY-MM-DD format.
	EZSocketNcName	Character string	"EZSocketNc.dll"	Fixed data.
Automation	FileVersion (Note 2)	Character string	Date of EZNcAut.dll file	YYYY-MM-DD format.
	EZSocketNcName	Character string	"EZNcAutxxx.dll"	xxx are numeric characters.

(Note 1) The data to be registered to "InstallPath" must be "%ProgramFiles%\EZSocket\EZSocketNc".

(Note 2) After copying installation files to the HD, get the time stamp of the specified file, and register this data as "FileVersion".

5.4.3.4 System environment variable settings

The system environment variable required for the product to run is shown below.

When installing the product, register it as an additional system environment variable.

The default value is shown in the list below. If the file is not in the specified path, change the path.

Table 5-5 List of system environment variable

Model	System environment variable (default value)
M700/M800	PATH=installation path of the product (Example: C:\Program Files (x86)\EZSocket\EZSocketNc)

5.4.3.5 COM information registry settings

For EZSocketNc.dll and EZNcAutxxx.dll stored in the installation directory, COM information must be registered to the registry. To register the information, use the redistributable REGSVR32.EXE command, which is shipped with Microsoft Visual C++, at the time of installation. The information is registered as follows:

```
REGSVR32 /s installation directory\EZSocketNc.dll  
REGSVR32 /s installation directory\EZNcAutxxx.dll
```

5.4.3.6 Precautions for uninstallation

The product may be used by more than one application. If that is the case, and if the product is deleted by uninstalling one of the applications that are installed, the operation of the remaining applications will be affected. To avoid this, do not delete the files and the registry of the product by uninstalling the application in which the product is embedded.

6. SAMPLE APPLICATION

6.1 Overview of the Sample Application

The sample application that uses this product is provided with compilable project files for Visual C++ Version 6.0 and Visual Basic Version 6.0. The macro sample program using the OLE interface macros that allow custom interfaces to be called easily is also provided. The OLE interface macros are provided as samples.

The sample application includes the following:

- Position data display application: \samples\Vc\Position\Position.dsw
- Monitoring application: \samples\Vb\EZNCAutSample\EZNCAutSample.vbp
- Macro sample program: \samples\Vc\Macros\MacSmp\MacSmp.dsw

6.2 Position Data Display Application

This section explains the sample application for Visual C++ Version 6.0 using this product.

6.2.1 Operating requirements

The sample application operates in the following system configuration:

Operating systems	Windows 2000, Windows XP
Compiler	Microsoft Visual C++ Version 6.0
Controller	Mitsubishi CNC C70, Mitsubishi CNC M700/M700V/M70/M70V, M800/M80
H/W	Personal computer on which the operating systems, compiler, and controllers above can be operated

6.2.2 Installation and uninstallation

This section explains installation and uninstallation of the sample application.

For installation of operating systems and VC++ other than the product as well as operations of hardware, refer to the respective instruction manuals.

(1) Installation

The sample application is created in the samples folder when this product is installed.

The sample application has the subfolders with respective project names and each contains its source code and execution file. The sample application includes the Visual C++ 6.0 project workspace files. Opening the corresponding project workspace file enables Visual C++ to open the project.

(2) Uninstallation

To uninstall the sample application, delete the subfolder with the project name or delete the samples folder.

6.2.3 Executing the sample application

This section explains execution of the sample application.

The execution file is stored under the Debug folder or the Release folder in the sample application folder. To open the position data display application, execute **Position.exe**.

For instructions for using the position data display application, refer to the following sections.

Note that this sample application is a monitor application for the Mitsubishi CNC. Operations such as operation search and cycle start are required for the computerized numerical controller. For details on the operation methods, refer to the instruction manuals.

6.2.4 Function list

This section explains the functions of the sample application.

The position data display application monitors specified position data and displays values obtained as counters.

Table 6-1 Position data display application function list

[File]	[Exit application]	Ends the position data display application.
[Edit]	[Position data]	Edits the position data type to be displayed. <ul style="list-style-type: none">• Current position• Workpiece coordinate position• Machine position• Command remaining distance
[Display]	[Refresh cycle]	Edits the refresh cycle for the display.
[Communication]	[Communication selection]	Selects a communication target. <ul style="list-style-type: none">• CNC C70• CNC M700M (*1)• CNC M700L (*2)• CNC M800M(*3)• CNC M800L(*4)
	[Execution]	Starts/Stops communication.
[Help]	[Version information]	Displays version information of the position data display application.

(*1) A communication target is the Mitsubishi CNC machining center system M700/M700V/M70/M70V.

(*2) A communication target is the Mitsubishi CNC lathe system M700/M700V/M70/M70V.

(*3) A communication target is the Mitsubishi CNC machining center system M800/M80.


(*4) A communication target is the Mitsubishi CNC lathe system M800/M80

6.2.5 Screen structure and functions

This section describes the screen structure for the position data display application and the functions for each menu item.

(1) Basic screen structure

The basic screen is shown below:



(2) File function


In the position data display application, the available file function is the exit of the application only.

There is no file selection function.

(3) Edit function

a. Position data function dialog

Selects the position data types to be displayed.



1) to 4): Explanation omitted. The following explanation is also omitted.

5) Check box to display the current position:

Selects whether to display or hide the relative position to the position at a completion of the dog type zero point return or to the preset position configured by G92/origin set/counter set.

6) Check box to display the workpiece coordinate position:

Selects whether to display or hide the coordinate position in the current workpiece coordinate system.

7) Check box to display the machine position:

Selects whether to display or hide the coordinate position for each axis in the basic machine coordinate system.


8) Check box to display the command remaining distance:

Selects whether to display or hide the remaining distance for the travel command being executed.

(4) Display function

Refresh cycle function dialog

Sets the refresh cycle for the screen display.



1) Edit box to specify the refresh cycle

1) Edit box to specify the refresh cycle:

Specifies the refresh cycle for the position data displayed on the screen.

The range is from 200 to 10000 (ms).

(5) Communication function

Communication selection function dialog

Selects a communication target.



1) Combo box for the remotely connected machine

2) Combo box for communication target selection (*1)

1) Combo box for the remotely connected machine:

Sets the machine name of a personal computer equipped with the NC.

Allows the domain name and IP address to be specified.

2) Combo box for the communication target selection:

Sets an NC control module communication target.

Selection range is as follows: MELDASMAGIC64, MELDAS6x5M, MELDAS6x5L, MELDASC6/C64, CNC C70, CNC M700M, CNC M700L, CNC M800M, CNC M800L.

(6) Execution function

Connects/disconnects the selected communication target.

If connection fails, an error message is output and the message box appears.

(7) Version display

"Help - Version display" displays the dialog box for version information of the position data display application.

6.2.6 Setting project workspaces

This section explains how to set the project workspace used for creating the position data display application. The application project configuration is as follows.

Table 6-2 Project configuration

Setting item	Setting value
Application type	SDI (Single Document Interface).
Database support	Not supported.
Automation support	Supported.
OLE compound document support	Not supported.
Functions to be embedded into the application	Docking toolbar. Initial status bar. 3D control.
MAPI support	Not supported.
Windows Sockets support	Not supported.
Number of the latest files to be displayed.	4 files. (The default value is applied to the advanced settings.)

6.2.7 IEZNCCommunication object

The IEZNCCommunication3 object is used for connection to the communication circuit.

This sample application uses the following methods:

- Open2() Open line method
- Close() Line disconnect method
- SetHead()..... System specification method

6.2.8 IEZNCPosition object

The IEZNCPosition object executes position information acquisition for the opened NC control module. This sample application uses the following methods:

- GetWorkPosition()..... Workpiece coordinate position acquisition method
- GetMachinePosition()... Machine position acquisition method
- GetCurrentPosition()... Current position acquisition method
- GetDistance()..... Command remaining distance acquisition method

6.3 Monitoring Application

This section explains the sample application for Visual Basic Version 6.0 using this product.

6.3.1 Operating requirements

The sample application operates in the following system configuration:

Operating systems	Windows 2000, Windows XP
Compiler	Microsoft Visual Basic Version 6.0
Controller	Mitsubishi CNC C70, Mitsubishi CNC M700/M700V/M70/M70V, M800/M80
H/W	Personal computer on which the operating systems, compiler, and controllers above can be operated

6.3.2 Installation and uninstallation

This section explains installation and uninstallation of the sample application.

For installation of operating systems and VB other than the product as well as operations of hardware, refer to the respective instruction manual.

(1) Installation

The sample application is created in the samples folder when this product is installed.

The sample application has the subfolders with respective project names and each contains its source code and execution file. The sample application includes the Visual Basic 6.0 project workspace files. Opening the corresponding project workspace file enables Visual Basic to open the project.

(2) Uninstallation

To uninstall the sample application, delete the subfolder with the project name or delete the samples folder.

6.3.3 Executing the sample application

This section explains execution of the sample application.

The execution file is stored under the sample application folder. To open the monitoring application, execute **EZNcAutSample.exe**.

For instruction for using the monitoring application, refer to the following sections.

Note that this sample application is a monitor application for the computerized numerical controller. Operations such as operation search and cycle start are required for the computerized numerical controller. For details on the operation methods, refer to the instruction manuals.

6.3.4 Function list

This section explains the functions of the sample application.

The monitoring application monitors the currently-running NC program and the current position, and displays the obtained values as counters.

Table 6-3 Monitoring application function list


Function item	Overview
NC control module communication start/stop	Sets NC control module communication parameters and starts/stops communication. <ul style="list-style-type: none">• Sets the NC control module number.• Sets communication time-out value.• Executes communication.• Displays the NC system version.
Position display	Reads the position data. <ul style="list-style-type: none">• Displays the current coordinate position.• Displays the workpiece coordinate position.• Displays the machine coordinate position.
Alarm display	Displays the current alarm.
Program display	Displays the currently-running program and the ongoing line position. <ul style="list-style-type: none">• Displays the currently-running program list• Displays the running block position and sequence number.
Error display	<ul style="list-style-type: none">• Displays the API error codes for this product.

6.3.5 Screen structure and functions

This section describes the screen structure for the position data display application and the functions for each menu item.

(1) Basic screen structure

The basic screen is shown below:



- 1) Edit box for the connected machine name
Sets the machine name of a personal computer equipped with the NC.
Allows the domain name and IP address to be specified.
- 2) Button for connection/disconnection
Connects/disconnects a specified machine.
- 3) Edit box for the NC control module number
Sets the NC control module number. The NC control module number is determined when setting up the NC control module.
- 4) Edit box for the communication time-out value
Sets the communication time-out value for the NC control module.
- 5) Radio button to start/stop communication
Sets to start or stop communication with the NC control module.
- 6) Execution button to start/stop communication
Executes a communication start or stop after setting 1) to 3).

6.3.6 Setting project workspaces

This section explains how to set the project workspace used for creating the position data display application. The application project configuration is as follows.

This project uses late binding to call methods of this product.

Table 6-4 Project configuration

Setting item	Setting value
Application type	Standard EXE
Addition of the standard module	Select EZNcDef.bas or EZNcErr.bas from [Add standard module] in [Project].

7. CONSOLE PROGRAM SAMPLE

7.1 Console Program to Connect Mitsubishi CNC C70 (via Ethernet)

```
//  
// Simple sample program for the console application  
//  
// Copyright(C) 2008 MITSUBISHI ELECTRIC CORPORATION  
#include "stdafx.h"  
  
#include "stdio.h"  
#include <locale.h>  
  
// EZSocket header file  
#include "EZSocketNc.h"  
#include "EZSocketNcStr.h"  
#include "EZSocketNcDef.h"  
  
#include "EasysocketDef.h"  
  
int main(int argc, char* argv[])  
{  
    HRESULT                hr = S_OK;  
    LONG                   IRet = 0;  
    EZNCST_OPEN           stOpen;  
    LPOLESTR               lpwszBuffer = NULL;  
    HANDLE                 hSampleFile = NULL;  
    BYTE*                  pbData = NULL;  
    const DWORD            dwLength = 256;  
    DWORD                  dwNumRead = 0;  
    DWORD                  dwWrittenSize = 0;  
  
    memset(&stOpen, 0x00, sizeof(stOpen));  
  
    // COM initialization  
    hr = CoInitialize(NULL);  
    if( S_OK != hr ){  
        wprintf(L"Failed in CoInitialize!\n");  
        return 0;  
    }  
  
    setlocale( LC_ALL, "Japanese" );  
    IEZNCCommunication3    *pIEZNCCom = NULL;    // Communication object  
    IEZNCFile6             *pIEZNCFile = NULL;    // File object  
  
    //  
    // EZNcCommunication object creation  
    // For the first argument of CLSIDFromProgID(), refer to *2 in "1.8.1 VC++ program flow (1)".  
    CLSID clsid;  
    CLSIDFromProgID( L"EZSocketNc.EZNcCommunication", &clsid );  
    hr = CoCreateInstance(clsid,  
                          NULL,  
                          CLSCTX_INPROC_SERVER,  
                          IID_IEZNCCommunication3,  
                          (void **)&pIEZNCCom);  
  
    if( S_OK != hr )  
    {  
        wprintf(L"EZSocket is not installed!\n");  
        goto END;  
    }  
  
    //  
    // EZNcFile object creation  
    //  
    if(pIEZNCCom->QueryInterface(IID_IEZNCFile6, (void **)&pIEZNCFile) != S_OK){  
        wprintf(L"EZSocket is not installed!\n");  
        goto END;  
    }  
  
    //  
    // Open parameter setting  
    //  
    stOpen.INetworkNumber        = 0x01;
```

```

stOpen.IStationNumber          = 0x01;
stOpen.IUnitNumber             = 0x00;
stOpen.IConnectUnitNumber     = 0x00;
stOpen.IIONumber               = 0x3E1;
stOpen.ICpuType                = CPU_Q17NNCCPU;
stOpen.IUnitType               = UNIT_QJ71E71;
stOpen.IPacketType             = PACKET_PL1;
stOpen.IProtocolType           = PROTOCOL_UDPIP;
stOpen.IPortNumber             = 0x00;
stOpen.IBaudRate               = 0x00;
stOpen.IDataBits               = 0x00;
stOpen.IParity                 = 0x00;
stOpen.IStopBits               = 0x00;
stOpen.IControl                = 0x00;
stOpen.IpcwszHostAddress       = L"10.20.123.12";
stOpen.ICpuTimeOut             = 0x00;
stOpen.ITimeOut                = 1000;
stOpen.ISumCheck               = FALSE;
stOpen.ISourceNetworkNumber    = 0x01;
stOpen.ISourceStationNumber    = 0x04;
stOpen.IDestinationPortNumber  = 5001;
stOpen.IDestinationIONumber    = 0x00;
stOpen.IConnectChannelNumber   = 0x00;
stOpen.IMultiDropChannelNumber = 0x00;
stOpen.IThroughNetworkType     = 0x00;
stOpen.IIntelligentPreferenceBit = 0x00;
stOpen.IDidPropertyBit         = 0x01;
stOpen.IDsidPropertyBit        = 0x01;

hr = pIEZNCCom->SetMelsecProtocol(&stOpen, &IRet);
if( S_OK != hr ){
    wprintf(L"Can't SetMelsecProtocol! Error Code = 0x%x\n",IRet);
    goto END;
}

// IEZNCCommunication3 open
hr = pIEZNCCom->Open2(EZNC_SYS_MELDASC70, 1, 20, &IRet);
if( S_OK != hr ){
    wprintf(L"Can't Open2! Error Code = 0x%x\n",IRet);
    goto END;
}

//
// File search
//
hr = pIEZNCFile->FindDir2(L"M01:\\PRG\\USER\\", 0x00, &lpwszBuffer, &IRet);
if( S_OK != hr ){
    wprintf(L"Can't FindDir! Error Code = 0x%x\n",IRet);
    goto END;
}

while(IRet >= 1){
    if(wcsncmp(lpwszBuffer, L"10.PRG") == 0){
        break;
    }
    CoTaskMemFree(lpwszBuffer);
    lpwszBuffer = NULL;
    hr = pIEZNCFile->FindNextDir2(&lpwszBuffer, &IRet);
    if( S_OK != hr ){
        wprintf(L"Can't FindNextDir! Error Code = 0x%x\n",IRet);
        goto END;
    }
}
if(IRet == 0){
    wprintf(L"File is not found.\n");
    pIEZNCFile->ResetDir(&IRet);
    goto END;
}
hr = pIEZNCFile->ResetDir(&IRet);
if( S_OK != hr ){
    wprintf(L"Can't ResetDir! Error Code = 0x%x\n",IRet);
    goto END;
}
//

```

```

// File read
//
hr = pIEZNCFile->OpenFile3(L"M01:\\PRG\\USER\\10.PRG", EZNC_FILE_READ, &IRet);
if( S_OK != hr ){
    wprintf(L"Can't OpenFile3! Error Code = 0x%x\n",IRet);
    goto END;
}

hSampleFile = ::CreateFile("C:\\SAMPLE.PRG",
                           GENERIC_WRITE,
                           FILE_SHARE_READ,
                           NULL,
                           OPEN_ALWAYS,
                           FILE_ATTRIBUTE_NORMAL,
                           NULL);
if(hSampleFile == INVALID_HANDLE_VALUE ){
    wprintf(L"Can't create file.\n");
    goto END;
}
do{
    hr = pIEZNCFile->ReadFile2(dwLength, &pbData, &dwNumRead, &IRet);
    if( S_OK != hr ){
        wprintf(L"Can't ReadFile2! Error Code = 0x%x\n",IRet);
        pIEZNCFile->AbortFile2(&IRet);
        ::CloseHandle(hSampleFile);
        goto END;
    }
    if(dwNumRead != 0){
        ::WriteFile(hSampleFile,
                    (LPCVOID)pbData,
                    dwNumRead,
                    &dwWrittenSize,
                    NULL);
        CoTaskMemFree(pbData);
        pbData = NULL;
    }
}while(dwLength == dwNumRead);
::CloseHandle(hSampleFile);

hr = pIEZNCFile->CloseFile2(&IRet);
if( S_OK != hr ){
    wprintf(L"Can't CloseFile2! Error Code = 0x%x\n",IRet);
    goto END;
}
END:
if(lpwszBuffer != NULL){
    CoTaskMemFree(lpwszBuffer);
    lpwszBuffer = NULL;
}
if(pbData != NULL){
    CoTaskMemFree(pbData);
    pbData = NULL;
}

// IEZNCCommunication3 close
if(pIEZNCCom != NULL){
    pIEZNCCom->Close(&IRet);
}

// Object release
if(pIEZNCFile != NULL){
    pIEZNCFile->Release();
    pIEZNCFile = NULL;
}
if(pIEZNCCom != NULL){
    pIEZNCCom->Release();
    pIEZNCCom = NULL;
}

// COM library release
CoUninitialize();
return 0;
}

```

Revision History

Date of revision	Manual No.	Revision details										
Dec.2013	IB-1501209-A	First edition created.										
Jan. 2014	IB-1501209-B	<p>1. Changed the compatible NC models Changed the compatible NC models to be M700 and C70 Corrected the description so that only the compatible models are given in each item.</p> <p>2. Added the descriptions and corrections on C70 Added the compatible methods Added the description and caution on I/F in accordance with the added methods Added a C70 sample program</p> <p>3. Added the description on the compatibility with 64bit OS Added the description and caution on x64 platform</p> <p>4. Corrected the method versions</p> <table border="1" data-bbox="608 808 1385 1178"> <thead> <tr> <th data-bbox="608 808 997 846">Before correction</th> <th data-bbox="997 808 1385 846">After correction</th> </tr> </thead> <tbody> <tr> <td data-bbox="608 846 997 949">IEZNCFile5 FindDir FindNextDir</td> <td data-bbox="997 846 1385 949">IEZNCFile6 FindDir2 FindNextDir2</td> </tr> <tr> <td data-bbox="608 949 997 1014">IEZNCATC2 GetMNGReady</td> <td data-bbox="997 949 1385 1014">IEZNCATC3 GetMNGReady2</td> </tr> <tr> <td data-bbox="608 1014 997 1111">IEZNCParameter2 GetParameter SetParameter</td> <td data-bbox="997 1014 1385 1111">IEZNCParameter3 GetParameter2 SetParameter2</td> </tr> <tr> <td data-bbox="608 1111 997 1178">IEZNCSubFuncton Changelnit</td> <td data-bbox="997 1111 1385 1178">IEZNCSubFuncton2 Changelnit2</td> </tr> </tbody> </table> <p>Applied these version changes also to the other parts of this manual.</p> <p>5. Error codes Added the related error codes to the I/F description Revised the list of error codes</p> <p>6. Others Corrected errors, modified the layout, etc.</p>	Before correction	After correction	IEZNCFile5 FindDir FindNextDir	IEZNCFile6 FindDir2 FindNextDir2	IEZNCATC2 GetMNGReady	IEZNCATC3 GetMNGReady2	IEZNCParameter2 GetParameter SetParameter	IEZNCParameter3 GetParameter2 SetParameter2	IEZNCSubFuncton Changelnit	IEZNCSubFuncton2 Changelnit2
Before correction	After correction											
IEZNCFile5 FindDir FindNextDir	IEZNCFile6 FindDir2 FindNextDir2											
IEZNCATC2 GetMNGReady	IEZNCATC3 GetMNGReady2											
IEZNCParameter2 GetParameter SetParameter	IEZNCParameter3 GetParameter2 SetParameter2											
IEZNCSubFuncton Changelnit	IEZNCSubFuncton2 Changelnit2											
Jul. 2014	IB-1501209-C	<p>1. Corrected the method versions</p> <table border="1" data-bbox="608 1525 1385 1664"> <thead> <tr> <th data-bbox="608 1525 997 1563">Before correction</th> <th data-bbox="997 1525 1385 1563">After correction</th> </tr> </thead> <tbody> <tr> <td data-bbox="608 1563 997 1664">IEZNCParameter3 GetParameter2 SetParameter2</td> <td data-bbox="997 1563 1385 1664">IEZNCParameter3 GetParameter3 SetParameter3</td> </tr> </tbody> </table> <p>2. Others Corrected errors.</p>	Before correction	After correction	IEZNCParameter3 GetParameter2 SetParameter2	IEZNCParameter3 GetParameter3 SetParameter3						
Before correction	After correction											
IEZNCParameter3 GetParameter2 SetParameter2	IEZNCParameter3 GetParameter3 SetParameter3											
Sept. 2015	IB-1501208-D	<p>1. Added information related to M800 series</p> <p>2. Added and corrected information for M700 series and C70 series</p> <p>3. Others Corrected errors, modified the layout, etc.</p>										

Global Service Network

AMERICA

MITSUBISHI ELECTRIC AUTOMATION INC. (AMERICA FA CENTER)

Central Region Service Center
500 CORPORATE WOODS PARKWAY, VERNON HILLS, ILLINOIS 60061, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

Michigan Service Satellite
ALLEGAN, MICHIGAN 49010, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

Ohio Service Satellite
LIMA, OHIO 45801, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650
CINCINNATI, OHIO 45201, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

Minnesota Service Satellite
ROGERS, MINNESOTA 55374, U.S.A.
TEL: +1-847-478-2500 / FAX: +1-847-478-2650

West Region Service Center
16900 VALLEY VIEW AVE., LAMIRADA, CALIFORNIA 90638, U.S.A.
TEL: +1-714-699-2625 / FAX: +1-847-478-2650

Northern CA Satellite
SARATOGA, CALIFORNIA 95070, U.S.A.
TEL: +1-714-699-2625 / FAX: +1-847-478-2650

Pennsylvania Service Satellite
PITTSBURGH, PENNSYLVANIA 15644, U.S.A.
TEL: +1-732-560-4500 / FAX: +1-732-560-4531

Connecticut Service Satellite
TORRINGTON, CONNECTICUT 06790, U.S.A.
TEL: +1-732-560-4500 / FAX: +1-732-560-4531

South Region Service Center
1845 SATELLITE BOULEVARD STE. 450, DULUTH, GEORGIA 30097, U.S.A.
TEL: +1-678-258-4529 / FAX: +1-678-258-4519

Texas Service Satellites
GRAPEVINE, TEXAS 76051, U.S.A.
TEL: +1-678-258-4529 / FAX: +1-678-258-4519
HOUSTON, TEXAS 77001, U.S.A.
TEL: +1-678-258-4529 / FAX: +1-678-258-4519

Tennessee Service Satellite
Nashville, Tennessee, 37201, U.S.A.
TEL: +1-678-258-4529 / FAX: +1-678-258-4519

Florida Service Satellite
WEST MELBOURNE, FLORIDA 32904, U.S.A.
TEL: +1-678-258-4529 / FAX: +1-678-258-4519

Canada Region Service Center
4299 14TH AVENUE MARKHAM, ONTARIO L3R 0J2, CANADA
TEL: +1-905-475-7728 / FAX: +1-905-475-7935

Canada Service Satellite
EDMONTON, ALBERTA T5A 0A1, CANADA
TEL: +1-905-475-7728 / FAX: +1-905-475-7935

Mexico Region Service Center
MARIANO ESCOBEDO 69 TLALNEPANTLA, 54030 EDO. DE MEXICO
TEL: +52-55-3067-7500 / FAX: +52-55-9171-7649

Monterrey Service Satellite
MONTERREY, N.L., 64720, MEXICO
TEL: +52-81-8365-4171

BRAZIL

MELCO CNC do Brasil Comércio e Serviços S.A

Brazil Region Service Center
ACESSO JOSE SARTORELLI, KM 2.1 CEP 18550-000, BOITUVA-SP, BRAZIL
TEL: +55-15-3363-9900 / FAX: +55-15-3363-9911

EUROPE

MITSUBISHI ELECTRIC EUROPE B.V.

GOTHAER STRASSE 10, 40880 RATINGEN, GERMANY
TEL: +49-2102-486-0 / FAX: +49-2102-486-5910

Germany Service Center
KURZE STRASSE, 40, 70794 FILDERSSTADT-BONLANDEN, GERMANY
TEL: +49-711-770598-123 / FAX: +49-711-770598-141

France Service Center DEPARTEMENT CONTROLE NUMERIQUE
25, BOULEVARD DES BOUVETS, 92741 NANTERRE CEDEX FRANCE
TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

France (Lyon) Service Satellite DEPARTEMENT CONTROLE NUMERIQUE
120, ALLEE JACQUES MONOD 69800 SAINT PRIEST FRANCE
TEL: +33-1-41-02-83-13 / FAX: +33-1-49-01-07-25

Italy Service Center
VIALE COLLEONI, 7 - CENTRO DIREZIONALE COLLEONI PALAZZO SIRIO INGRESSO 1
20864 AGRATE BRIANZA (MB), ITALY
TEL: +39-039-6053-342 / FAX: +39-039-6053-206

Italy (Padova) Service Satellite
VIA G. SAVELLI, 24 - 35129 PADOVA, ITALY
TEL: +39-039-6053-342 / FAX: +39-039-6053-206

U.K. Branch
TRAVELLERS LANE, HATFIELD, HERTFORDSHIRE, AL10 8XB, U.K.
TEL: +49-2102-486-0 / FAX: +49-2102-486-5910

Spain Service Center
CTRA. DE RUBI, 76-80-APDO. 420
08173 SAINT CUGAT DEL VALLES, BARCELONA SPAIN
TEL: +34-935-65-2236 / FAX: +34-935-89-1579

Poland Service Center
UL.KRAKOWSKA 50, 32-083 BALICE, POLAND
TEL: +48-12-630-4700 / FAX: +48-12-630-4701

Mitsubishi Electric Turkey A.Ş Ümraniye Şubesi
Turkey Service Center
ŞERİFALİ MAH. NUTUK SOK. NO.5 34775
ÜMRANIYE, İSTANBUL, TURKEY
TEL: +90-216-526-3990 / FAX: +90-216-526-3995

Czech Republic Service Center
KAFKOVA 1853/3, 702 00 OSTRAVA 2, CZECH REPUBLIC
TEL: +420-59-5691-185 / FAX: +420-59-5691-199

Russia Service Center
213, B.NOVODIMITROVSKAYA STR., 14/2, 127015 MOSCOW, RUSSIA
TEL: +7-495-748-0191 / FAX: +7-495-748-0192

MITSUBISHI ELECTRIC EUROPE B.V. (SCANDINAVIA)

Sweden Service Center
HAMMARBACKEN 14 191 49 SOLLENTUNA, SWEDEN
TEL: +46-8-6251000 / FAX: +46-8-966877

Bulgaria Service Center
4 A.LYAPCHEV BOUL., POB 21, BG-1756 SOFIA, BULGARIA
TEL: +359-2-8176009 / FAX: +359-2-9744061

Ukraine (Kharkov) Service Center
APTEKARSKIY LANE 9-A, OFFICE 3, 61001 KHARKOV, UKRAINE
TEL: +380-57-732-7774 / FAX: +380-57-731-8721

Ukraine (Kiev) Service Center
4-B, M. RASKOVOYI STR., 02660 KIEV, UKRAINE
TEL: +380-44-494-3355 / FAX: +380-44-494-3366

Belarus Service Center
OFFICE 9, NEZAVISIMOSTI PR.177, 220125 MINSK, BELARUS
TEL: +375-17-393-1177 / FAX: +375-17-393-0081

South Africa Service Center
5 ALBATROSS STREET, RHODESFIELD, KEMPTON PARK 1619, GAUTENG, SOUTH AFRICA
TEL: +27-11-394-8512 / FAX: +27-11-394-8513

ASEAN**MITSUBISHI ELECTRIC ASIA PTE. LTD. (ASEAN FA CENTER)**

Singapore Service Center
307 ALEXANDRA ROAD #05-01/02 MITSUBISHI ELECTRIC BUILDING SINGAPORE 159943
TEL: +65-6473-2308 / FAX: +65-6476-7439

Malaysia (KL) Service Center
60, JALAN USJ 10/1B 47620 UEP SUBANG JAYA SELANGOR DARUL EHSAN, MALAYSIA
TEL: +60-3-5631-7605 / FAX: +60-3-5631-7636

Malaysia (Johor Baru) Service Center
17 & 17A, JALAN IMPIAN EMAS 5/5, TAMAN IMPIAN EMAS, 81300 SKUDAI, JOHOR MALAYSIA.
TEL: +60-7-557-8218 / FAX: +60-7-557-3404

Philippines Service Center
UNIT NO.411, ALABAMG CORPORATE CENTER KM 25, WEST SERVICE ROAD
SOUTH SUPERHIGHWAY, ALABAMG MUNTINLUPA METRO MANILA, PHILIPPINES 1771
TEL: +63-2-807-2416 / FAX: +63-2-807-2417

VIETNAM**MITSUBISHI ELECTRIC VIETNAM CO.,LTD**

Vietnam (Ho Chi Minh) Service Center
UNIT 01-04, 10TH FLOOR, VINCOM CENTER 72 LE THANH TON STREET, DISTRICT 1,
HO CHI MINH CITY, VIETNAM
TEL: +84-8-3910 5945 / FAX: +84-8-3910 5946

Vietnam (Hanoi) Service Satellite
6th Floor, Detech Tower, 8 Ton That Thuyet Street, My Dinh 2 Ward, Nam Tu Liem District, Hanoi, Vietnam
TEL: +84-4-3937-8075 / FAX: +84-4-3937-8076

INDONESIA**PT. MITSUBISHI ELECTRIC INDONESIA**

Indonesia Service Center (Cikarang Office)
JL.Kenari Raya Blok G2-07A Delta Silicon 5, Lippo Cikarang-Bekasi 17550, INDONESIA
TEL: +62-21-2961-7797 / FAX: +62-21-2961-7794

THAILAND**MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO.,LTD**

Thailand Service Center
12TH FLOOR, SV.CITY BUILDING, OFFICE TOWER 1, NO. 896/19 AND 20 RAMA 3 ROAD,
KWAENG BANGPONGPANG, KHET YANNAWA, BANGKOK 10120, THAILAND
TEL: +66-2-682-6522-31 / FAX: +66-2-682-6020

INDIA**MITSUBISHI ELECTRIC INDIA PVT. LTD.**

India Service Center
2nd FLOOR, TOWER A & B, DLF CYBER GREENS, DLF CYBER CITY,
DLF PHASE-III, GURGAON 122 002, HARYANA, INDIA
TEL: +91-124-4630 300 / FAX: +91-124-4630 399
Ludhiana satellite office
Jamshedpur satellite office

India (Pune) Service Center
EMERALD HOUSE, EL-3, J-BLOCK, MIDC BHOSARI, PUNE – 411 026, MAHARASHTRA, INDIA
TEL: +91-20-2710 2000 / FAX: +91-20-2710 2100
Baroda satellite office
Mumbai satellite office

India (Bangalore) Service Center
PRESTIGE EMERALD, 6TH FLOOR, MUNICIPAL NO. 2,
LAVELLE ROAD, BANGALORE - 560 043, KAMATAKA, INDIA
TEL: +91-80-4020-1600 / FAX: +91-80-4020-1699
Chennai satellite office
Coimbatore satellite office

OCEANIA**MITSUBISHI ELECTRIC AUSTRALIA LTD.**

Australia Service Center
348 VICTORIA ROAD, RYDALMERE, N.S.W. 2116 AUSTRALIA
TEL: +61-2-9684-7269 / FAX: +61-2-9684-7245

CHINA**MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. (CHINA FA CENTER)**

China (Shanghai) Service Center
1-3,5-10,18-23/F, NO.1386 HONG QIAO ROAD, CHANG NING QU,
SHANGHAI 200336, CHINA
TEL: +86-21-2322-3030 / FAX: +86-21-2308-3000

China (Ningbo) Service Dealer
China (Wuxi) Service Dealer
China (Jinan) Service Dealer
China (Hangzhou) Service Dealer
China (Wuhan) Service Satellite

China (Beijing) Service Center
9/F, OFFICE TOWER 1, HENDERSON CENTER, 18 JIANGUOMENNEI DAJIE,
DONGCHENG DISTRICT, BEIJING 100005, CHINA
TEL: +86-10-6518-8830 / FAX: +86-10-6518-8030
China (Beijing) Service Dealer

China (Tianjin) Service Center
UNIT 2003, TIANJIN CITY TOWER, NO 35 YOUYI ROAD, HEXI DISTRICT,
TIANJIN 300061, CHINA
TEL: +86-22-2813-1015 / FAX: +86-22-2813-1017
China (Shenyang) Service Satellite
China (Changchun) Service Satellite

China (Chengdu) Service Center
ROOM 407-408, OFFICE TOWER AT SHANGRI-LA CENTER, NO. 9 BINJIANG DONG ROAD,
JINJIANG DISTRICT, CHENGDU, SICHUAN 610021, CHINA
TEL: +86-28-8446-8030 / FAX: +86-28-8446-8630

China (Shenzhen) Service Center
ROOM 2512-2516, 25/F., GREAT CHINA INTERNATIONAL EXCHANGE SQUARE, JINTIAN RD.S.,
FUTIAN DISTRICT, SHENZHEN 518034, CHINA
TEL: +86-755-2399-8272 / FAX: +86-755-8218-4776
China (Xiamen) Service Dealer
China (Dongguan) Service Dealer

KOREA**MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. (KOREA FA CENTER)**

Korea Service Center
8F, Gangseo Hangang Xi-tower, 401 Yangcheon-ro, Gangseo-gu, Seoul 157-801, KOREA
TEL: +82-2-3660-9602 / FAX: +82-2-3664-8668

Korea Taegu Service Satellite
4F KT BUILDING, 1630 SANGYEOK-DONG, BUK-KU, DAEGU 702-835, KOREA
TEL: +82-53-382-7400 / FAX: +82-53-382-7411

TAIWAN**MITSUBISHI ELECTRIC TAIWAN CO., LTD. (TAIWAN FA CENTER)**

Taiwan (Taichung) Service Center (Central Area)
NO.8-1, INDUSTRIAL 16TH RD., TAICHUNG INDUSTRIAL PARK, SITUN DIST.,
TAICHUNG CITY 40768, TAIWAN R.O.C.
TEL: +886-4-2359-0688 / FAX: +886-4-2359-0689

Taiwan (Taipei) Service Center (North Area)
10F, NO.88, SEC.6, CHUNG-SHAN N. RD., SHI LIN DIST., TAIPEI CITY 11155, TAIWAN R.O.C.
TEL: +886-2-2833-5430 / FAX: +886-2-2833-5433

Taiwan (Tainan) Service Center (South Area)
11F-1., NO.30, ZHONGZHENG S. ROAD, YONGKANG DISTRICT, TAINAN CITY 71067, TAIWAN, R.O.C.
TEL: +886-6-252-5030 / FAX: +886-6-252-5031

Notice

Every effort has been made to keep up with software and hardware revisions in the contents described in this manual. However, please understand that in some unavoidable cases simultaneous revision is not possible.

Please contact your Mitsubishi Electric dealer with any questions or comments regarding the use of this product.

Duplication Prohibited

This manual may not be reproduced in any form, in part or in whole, without written permission from Mitsubishi Electric Corporation.

© 2013-2015 MITSUBISHI ELECTRIC CORPORATION
ALL RIGHTS RESERVED.

MITSUBISHI Communication Software for CNC

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BLDG.,2-7-3 MARUNOUCHI,CHIYODA-KU,TOKYO 100-8310,JAPAN

MODEL	FCSB1224W000
MODEL CODE	-
Manual No.	IB-1501209